



LMV2x Microprocessor-controlled gas - heavy oil burners

MANUAL OF INSTALLATION - USE - MAINTENANCE

CIB UNIGAS

BURNERS - BRUCIATORI - BRULERS - BRENNER - QUEMADORES - ГОРЕЛКИ

M039286CA Rel. 0.2 10/2014

DANGERS, WARNINGS AND NOTES OF CAUTION

THIS MANUAL IS SUPPLIED AS AN INTEGRAL AND ESSENTIAL PART OF THE PRODUCT AND MUST BE DELIVERED TO THE USER.

INFORMATION INCLUDED IN THIS SECTION ARE DEDICATED BOTH TO THE USER AND TO PERSONNEL FOLLOWING PRO-DUCT INSTALLATION AND MAINTENANCE.

THE USER WILL FIND FURTHER INFORMATION ABOUT OPERATING AND USE RESTRICTIONS, IN THE SECOND SECTION OF THIS MANUAL. WE HIGHLY RECOMMEND TO READ IT.

CAREFULLY KEEP THIS MANUAL FOR FUTURE REFERENCE.

1) GENERAL INTRODUCTION

- The equipment must be installed in compliance with the regulations in force, following the manufacturer's instructions, by qualified personnel.
- Qualified personnel means those having technical knowledge in the field of components for civil or industrial heating systems, sanitary hot water generation and particularly service centres authorised by the manufacturer.
- Improper installation may cause injury to people and animals, or damage to property, for which the manufacturer cannot be held liable.
- Remove all packaging material and inspect the equipment for integrity.

In case of any doubt, do not use the unit - contact the supplier.

The packaging materials (wooden crate, nails, fastening devices, plastic bags, foamed polystyrene, etc), should not be left within the reach of children, as they may prove harmful.

- Before any cleaning or servicing operation, disconnect the unit from the mains by turning the master switch OFF, and/or through the cutout devices that are provided.
- Make sure that inlet or exhaust grilles are unobstructed.
- In case of breakdown and/or defective unit operation, disconnect the unit. Make no attempt to repair the unit or take any direct action.

Contact qualified personnel only.

Units shall be repaired exclusively by a servicing centre, duly authorised by the manufacturer, with original spare parts.

Failure to comply with the above instructions is likely to impair the unit's safety.

To ensure equipment efficiency and proper operation, it is essential that maintenance operations are performed by qualified personnel at regular intervals, following the manufacturer's instructions.

- When a decision is made to discontinue the use of the equipment, those parts likely to constitute sources of danger shall be made harmless.
- In case the equipment is to be sold or transferred to another user, or in case the original user should move and leave the unit behind, make sure that these instructions accompany the equipment at all times so that they can be consulted by the new owner and/or the installer.
- For all the units that have been modified or have options fitted then original accessory equipment only shall be used.
- This unit shall be employed exclusively for the use for which it is meant. Any other use shall be considered as improper and, therefore, dangerous.

The manufacturer shall not be held liable, by agreement or otherwise, for damages resulting from improper installation, use and failure to comply with the instructions supplied by the manufacturer. The occurrence of any of the following circustances may cause explosions, polluting unburnt gases (example: carbon monoxide CO), burns, serious harm to people, animals and things:

- Failure to comply with one of the WARNINGS in this chapter

- Incorrect handling, installation, adjustment or maintenance of the burner
- Incorrect use of the burner or incorrect use of its parts or optional supply

2) SPECIAL INSTRUCTIONS FOR BURNERS

- The burner should be installed in a suitable room, with ventilation openings complying with the requirements of the regulations in force, and sufficient for good combustion.
- Only burners designed according to the regulations in force should be used.
- This burner should be employed exclusively for the use for which it

was designed.

- Before connecting the burner, make sure that the unit rating is the same as delivery mains (electricity, gas oil, or other fuel).
- Observe caution with hot burner components. These are, usually, near to the flame and the fuel pre-heating system, they become hot during the unit operation and will remain hot for some time after the burner has stopped.

When the decision is made to discontinue the use of the burner, the user shall have qualified personnel carry out the following operations:

- a Remove the power supply by disconnecting the power cord from the mains.
- b) Disconnect the fuel supply by means of the hand-operated shut-off valve and remove the control handwheels from their spindles.

Special warnings

- Make sure that the burner has, on installation, been firmly secured to the appliance, so that the flame is generated inside the appliance firebox.
- Before the burner is started and, thereafter, at least once a year, have qualified personnel perform the following operations:
- a set the burner fuel flow rate depending on the heat input of the appliance;
- b set the flow rate of the combustion-supporting air to obtain a combustion efficiency level at least equal to the lower level required by the regulations in force;
- c check the unit operation for proper combustion, to avoid any harmful or polluting unburnt gases in excess of the limits permitted by the regulations in force;
- d make sure that control and safety devices are operating properly;
- e make sure that exhaust ducts intended to discharge the products of combustion are operating properly;
- f on completion of setting and adjustment operations, make sure that all mechanical locking devices of controls have been duly tightened;
- g make sure that a copy of the burner use and maintenance instructions is available in the boiler room.
- In case of a burner shut-down, reser the control box by means of the RESET pushbutton. If a second shut-down takes place, call the Technical Service, without trying to RESET further.
- The unit shall be operated and serviced by qualified personnel only, in compliance with the regulations in force.

3) GENERAL INSTRUCTIONS DEPENDING ON FUEL USED

3a) ELECTRICAL CONNECTION

- For safety reasons the unit must be efficiently earthed and installed as required by current safety regulations.
- It is vital that all saftey requirements are met. In case of any doubt, ask for an accurate inspection of electrics by qualified personnel, since the manufacturer cannot be held liable for damages that may be caused by failure to correctly earth the equipment.
- Qualified personnel must inspect the system to make sure that it is adequate to take the maximum power used by the equipment shown on the equipment rating plate. In particular, make sure that the system cable cross section is adequate for the power absorbed by the unit.
- No adaptors, multiple outlet sockets and/or extension cables are permitted to connect the unit to the electric mains.
- An omnipolar switch shall be provided for connection to mains, as required by the current safety regulations.
- The use of any power-operated component implies observance of a few basic rules, for example:
 - do not touch the unit with wet or damp parts of the body and/or with bare feet;
 - do not pull electric cables;

- do not leave the equipment exposed to weather (rain, sun, etc.) unless expressly required to do so;

- do not allow children or inexperienced persons to use equipment;
- The unit input cable shall not be replaced by the user.

In case of damage to the cable, switch off the unit and contact qualified personnel to replace.

When the unit is out of use for some time the electric switch supplying all the power-driven components in the system (i.e. pumps, burner, etc.) should be switched off.

3b) FIRING WITH GAS, LIGHT OIL OR OTHER FUELS GENERAL

- The burner shall be installed by qualified personnel and in compliance with regulations and provisions in force; wrong installation can cause injuries to people and animals, or damage to property, for which the manufacturer cannot be held liable.
- Before installation, it is recommended that all the fuel supply system pipes be carefully cleaned inside, to remove foreign matter that might impair the burner operation.
- Before the burner is commissioned, qualified personnel should inspect the following:
- a the fuel supply system, for proper sealing;
- b the fuel flow rate, to make sure that it has been set based on the firing rate required of the burner;
- c the burner firing system, to make sure that it is supplied for the designed fuel type;
- d the fuel supply pressure, to make sure that it is included in the range shown on the rating plate;
- e the fuel supply system, to make sure that the system dimensions are adequate to the burner firing rate, and that the system is equipped with all the safety and control devices required by the regulations in force.
- When the burner is to remain idle for some time, the fuel supply tap or taps should be closed.

SPECIAL INSTRUCTIONS FOR USING GAS

Have qualified personnel inspect the installation to ensure that:

- a the gas delivery line and train are in compliance with the regulations and provisions in force;
- b all gas connections are tight;
- c the boiler room ventilation openings are such that they ensure the air supply flow required by the current regulations, and in any case are sufficient for proper combustion.
- Do not use gas pipes to earth electrical equipment.
- Never leave the burner connected when not in use. Always shut the gas valve off.
- In case of prolonged absence of the user, the main gas delivery valve to the burner should be shut off.

Precautions if you can smell gas

- a do not operate electric switches, the telephone, or any other item likely to generate sparks;
- b immediately open doors and windows to create an air flow to purge the room;
- c close the gas valves;
- d contact qualified personnel.
- Do not obstruct the ventilation openings of the room where gas appliances are installed, to avoid dangerous conditions such as the development of toxic or explosive mixtures.

DIRECTIVES AND STANDARDS

Gas burners

- European directives:
- Directive 2009/142/EC Gas Appliances;
- Directive 2006/95/EC on low voltage;
- Directive 2004/108/EC on electromagnetic compatibility

Harmonised standards :

-UNI EN 676 (Gas Burners;-EN 55014-1Electromagnetic compatibility - Requirements for household appliances, electric tools and similar apparatus.

-CEI EN 60335-1(Household and similar electrical appliances - Safety. Part 1: General requirements;

-EN 50165 (Electrical equipment of non-electric appliances for household and similar purposes. Safety requirements.

-EN 60335-2-102 (Household and similar electrical appliances. Safety. Particular requirements for gas, oil and solid-fuel burning appliances having electrical connections)

Light oil burners

European directives:

- Directive 2006/95/EC on low voltage;

- Directive 2004/108/EC on electromagnetic compatibility

Harmonised standards : -CEI EN 60335-1(Household and similar electrical appliances - Safety.

Part 1: General requirements;

-UNI 267 Automatic forced draught burners for liquid fuels

-EN 55014-1Electromagnetic compatibility - Requirements for household appliances, electric tools and similar apparatus.

-EN 50165 (Electrical equipment of non-electric appliances for household and similar purposes. Safety requirements.

National standards :

-UNI 7824: Monobloc nebulizer burners for liquid fuels. Characteristics and test methods

Heavy oil burners

European directives:

- Directive 2006/95/EC on low voltage;

- Directive 2004/108/EC on electromagnetic compatibility

Harmonised standards :

-CEI EN 60335-1 Household and similar electrical appliances - SafetyPart 1: General requirements;

-EN 55014-1Electromagnetic compatibility - Requirements for household appliances, electric tools and similar apparatus.

- EN 50165 Electrical equipment of non-electric appliances for household and similar purposes. Safety requirements.

National standards :

-UNI 7824: Monobloc nebulizer burners for liquid fuels. Characteristics and test methods

Gas - Light oil burners

European directives:

- Directive 2009/142/EC - Gas Appliances;

- Directive 2006/95/EC on low voltage;

- Directive 2004/108/EC on electromagnetic compatibility

Harmonised standards :

-UNI EN 676 Gas Burners

-EN 55014-1Electromagnetic compatibility - Requirements for household appliances, electric tools and similar apparatus.

-UNI 267 Automatic forced draught burners for liquid fuels

-CEI EN 60335-1(Household and similar electrical appliances - Safety. Part 1: General requirements;

- EN 50165 Electrical equipment of non-electric appliances for household and similar purposes. Safety requirements.

National standards :

-UNI 7824: Monobloc nebulizer burners for liquid fuels. Characteristics and test methods

Gas - Heavy oil burners

European directives:

- Directive 2009/142/EC Gas Appliances;
- Directive 2006/95/EC on low voltage;
- Directive 2004/108/EC on electromagnetic compatibility

Harmonised standards :

-EN 55014-1Electromagnetic compatibility - Requirements for household appliances, electric tools and similar apparatus.

-UNI EN 676 (Gas Burners;

-CEI EN 60335-1(Household and similar electrical appliances - Safety. Part 1: General requirements;

- EN 50165 Electrical equipment of non-electric appliances for household and similar purposes. Safety requirements.

National standards :

-UNI 7824: Monobloc nebulizer burners for liquid fuels. Characteristics and test methods

Industrial burners

European directives:

- Directive 2009/142/EC - Gas Appliances;

- Directive 2006/95/EC on low voltage;

- Directive 2004/108/EC on electromagnetic compatibility

Harmonised standards :

-EN 55014-1Electromagnetic compatibility - Requirements for household appliances, electric tools and similar apparatus.

-EN 50165 Electrical equipment of non-electric appliances for household and similar purposes. Safety requirements.

-UNI EN 746-2: Industrial thermoprocessing equipment

Burner data plate

Model For the following information, please refer to Year the data plate: S.Number

- burner type and burner model: must be reported in any communication with the Fuel supplier
- burner ID (serial number): must be reported in any communication with the supplier
- date of production (year and month)

WARNING!

DANGER!

WARNING!

Protection information about fuel type and network Drwaing n° pressure P.I.N.

SYMBOLS USED



Failure to observe the warning may result in irreparable damage to the unit or damage to the environment

Туре

Output

. Oil Flow

Category Gas Press

Viscosity EI.Supply EI.Consump.

Fan Motor



Failure to observe the warning may result in serious injuries or death.



Failure to observe the warning may result in electric shock with lethal consequences

PART I: SPECIFICATIONS

1.0 BURNERS FEATURES

Туре	KPBY72	Model	MH.	PR.	S.	*.	Α.	8.	50.	EC	;	
	(1)		(2)	(3)	(4)	(5)	(6)	(7)	(8)	(9	9)	
(1) BUI	RNER TYPE						КРВΥ	(70 -	KPB	Y72		
(2) FUI	ΞL						E - He D - He P - Pe	eavy eavy eavy etrole	oil, vi oil, vi oil, v oil, v	isco: isco: /iscc viscc	sity sity sity	y <= 50cSt (7° E) @ 50° C y <= 110cSt (15°E) @ 50° C ty <= 400cSt (50° E) @ 50° C ty 89cSt (12° E) @ 50° C y <= 4000cSt (530°E) a 50°C
(3) OP	ERATION (Avai	lable vers	sions)				PR - F MD -				ng	
(4) BLA	AST TUBE						S - St	anda	ard			
(5) DE	STINATION CO	UNTRY					* - see	e dat	a plat	te		
(6) BUI	RNER VERSIO	N					A - St	anda	ard			
(7) EQ	UIPMENT											s proving system s proving system + maximum gas pressure switch
(8) GA	S CONNECTIO	N					50 = [DN5(D, 65 :	= DN	165	5, 80 = DN80
(9) MIC	RO-PROCESS	OR CON	ITROL									control, without inverter control, with inverter

Burners are identified by burner type and model. Burner model identification is described as follows.

1.1 Technical specifications

Burners are identified by burner type and model. Burner model identification is described as follows.

BURNER TYPE		KPBY70	KPBY72
Output	min - max kW	270 - 970	290 - 1530
Fuel		Natural gas	s - Heavy oil
Category		(see next	paragraph)
Gas rate	minmax. (Stm ³ /h)	29 - 103	31 - 162
Heavy oil rate	min max. kg/h	24 - 85	25 - 133
Motor power supply		400V 3	N~ 50Hz
Fan motor power consumption	kW	1.5	2.2
Pre-heater resistors	kW	4.5	8
Pump motor (Cucchi)	kW	0.75	0.75
Pump motor (Kral)	kW	0.37	0.37
Total power consumption (with Cucchi pump)	kW	7.25	11.45
Total power consumption (with Kral pump)	kW	6.87	11.07
Protection		IF	240
Operation		Prog	ressive
Gas train 50	ØValves Connection	F	Rp2
Gas train 65	ØValves Connection	D	N65
Gas train 80	ØValves Connection	D	N80
Operating temperature	°C	-10 -	÷ +50
Storage Temperature	°C	-20 -	÷ +60
Working service		Inter	mitent
Approx. weight	kg	2	50

* NOTE ON THE WORKING SERVICE: the control box automatically stops after 24h of continuous working. The control box immediately starts up, automatically.


Note1:	All gas flow rates are referred to Stm ³ /h (1013 mbar absolute pressure, 15 °C temperature) and are valid for G20 gas (net calorific value H _i = 34.02 MJ/Stm ³);
Note2:	Maximum gas pressure = 360mbar (with Dungs MBDLE)
	Maximum gas pressure = 500mbar (with Siemens VGD)
	Minimum gas pressure = see gas curves.


1.2 Country and usefulness gas categories


GAS CATEGORY												cc	DUNT	RY											
I _{2H}	AT	ES	GR	SE	FI	IE	HU	IS	NO	CZ	DK	GB	IT	PT	CY	EE	LV	SI	MT	SK	BG	LT	RO	TR	СН
I _{2E}	LU	PL	-	-	-	-	-	-	-	-	-	1	-	-	-	1	-	-	-	1	-	-	-	-	-
I _{2E(R)B}	BE	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
I _{2L}	NL	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
I _{2ELL}	DE	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
I _{2Er}	FR	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-

KPBY70

 $\overline{}$










Burner flange

KPBY72








PART I: SPECIFICATIONS

Boiler recommended drilling template

Burner flange

8



	LEGEND
POS	OIL TRAIN
1	Filter
2	Pump with electromotor
3	Flexible hose
4	Maual valve
5	Pressure gauge
6	Pressure governor
7	Maual valve
8	Temperature probe - Pb3
9	Temperature probe - Pb1
10	Temperature probe - Pb4
11	Electrical preheater tank
12	Temperature gauge
13	Pneumatic valve
14	Metering valve
15	Burner
	COMBUSTION AIR TRAIN
37	Air damper with actuator
38	Remote draught fan with electromotor
39	Pressure switch - PA

	COMPRESSED AIR TRAIN
16	Pressure governor with filter
17	Solenoid valve
18	Pressure switch
19	One-way valve
20	Metering valve
21	Manual valve
22	Pressure gauge
23	Flexible hose
24	Solenoid valve
37	Pressure governor
38	Pressure gauge
	MAIN GAS TRAIN
25	Filter
26	Pressure switch - PGMIN
27	Safety valve with built in gas governor
28	Proving system
29	Pressure switch - PGMAX
30	Butterfly valve

10

1.4 How to read the burner "Performance curve"

To check if the burner is suitable for the boiler to which it must be installled, the following parameters are needed:

- furnace input, in kW or kcal/h (kW = kcal/h / 860);
- backpressure (data are available on the boiler ID plate or in the user's manual).


Example:

Furnace input: 600kW


Backpressure: 4mbar

In the "Performance curve" diagram, draw a vertical line matching the furnace input value and an horizontal line matching the backpressure value. The burner is suitable if the intersection point A is inside the performance curve.

Data are referred to standard conditions: atmospheric pressure at 1013mbar, ambient temperature at 15° C.



Performance Curves




To get the input in kcal/h, multiply value in kW by 860.

Data are referred to standard conditions: atmospheric pressure at 1013mbar, ambient temperature at 15°C

NOTE: The performance curve is a diagram that represents the burner performance in the type approval phase or in the laboratory tests, but does not represent the regulation range of the machine. On this diagram the maximum output point is usually reached by adjsuting the combustion head to its "MAX" position (see paragraph "Adjusting the combustion head"); the minimum output point is reached setting the combustion head to its "MIN" position. During the first ignition, the combustion head is set in order to find a compromise between the burner output and the generator specifications, that is why the minimum output may be different from the Performance curve minimum.

PART I: SPECIFICATIONS

1.5 Pressure in the Network / gas flow rate curves





Caution: the gas rate value is quoted on the x-axis, the related network pressure is quoted on the y-axis (pressure value in the combustion chamber is not included). To know the minimum pressure at the gas train inlet, necessary to get the requested gas rate, add the pressure value in the combustion chamber to the value read on the y-axis.

2.0 MOUNTING AND CONNECTING THE BURNER




ATTENTION! The burner must be installed in compliance with the regulations in force. In the case of oil feeding plants, please refer to the chapter "recommendations to design heavily oil feeding plants"

2.1 Matching the burner to the boiler

The burners described in this manual have been tested with combustion chambers that comply with EN676 regulation and whose dimensions are described in the diagram. In case the burner must be coupled with boilers with a combustion chamber smaller in diameter or shorter than those described in the diagram, please contact the supplier, to verify that a correct matching is possible, with respect of the application involved. To correctly match the burner to the boiler verify the type of the blast tube. Verify the necessary input and the pressure in combustion chamber are included in the burner performance curve; otherwise the choice of the burner must be revised consulting the burner manufacturer. To choose the blast tube lenght follow the instructions of the boiler manufacturer. In absence of these consider the following:

- Cast-iron boilers, three pass flue boilers (with the first pass in the rear part): the blast tube must protrude no more than Dist = 100 mm into the combustion chamber. (Fig. 2)
- Pressurised boilers with flame reversal: in this case the blast tube must penetrate Dm 50 ÷ 100 mm into combustion chamber in respect to the tube bundle plate. (Fig. 3)




The length of the blast tubes does not always allow this requirement to be met, and thus it may be necessary to use a suitably-sized spacer to move the burner backwards or to design a blast tube tha suites the utilisation (please, contact the manifacturer).

2.2 Fitting the burner to the boiler

To install the burner into the boiler, proceed as follows:

- 1 make a hole on the closing door of the combustion chamber as described on paragraph "Overall dimensions")
- 2 place the burner to the boiler: lift it up and handle it according to the procedure described on paragraph "Handling the burner";
- 3 place the 4 stud bolts (5) on boiler's door, according to the burner drilling template described on paragraph "Overall dimensions";
- 4 fasten the 4 stud bolts;
- 5 place the gasket on the burner flange;
- 6 install the burner into the boiler;
- 7 fix the burner to the stud bolts, by means of the fixing nuts, according to the next picture.
- 8 After fitting the burner to the boiler, ensure that the gap between the blast tube and the refractory lining is sealed with appropriate insulating material (ceramic fibre cord or refractory cement).



Keys


- 1 Burner
- 2 Fixing nut
- 3 Washer
- 4 Sealing gasket
- 5 Stud bolt
- 7 Blast tube

2.3 Handling the burner



ATTENTION! The Ihandling operations must be carried out by specialised and trained personnel. If these operations are not carried out correctly, the residual risk for the burner to overturn and fall down still persists. To move the burner, use means suitable to support its weight (see paragraph "Technical specifications"). The unpacked burner must be lifted and moved only by means of a fork lift truck.

The burner is mounted on a stirrup provided for handling the burner by means of a fork lift truck: the forks must be inserted into the A anb B ways. Remove the stirrup only once the burner is installed to the boiler.



The burner is provided with eye-bolts for lifting.

3.0 GAS TRAIN CONNECTIONS

The diagrams show the components of the gas trai included in the delivery and which must be fitted by the installer. The diagrams are in compliance with the current laws.



ATTENTION: BEFORE EXECUTING THE CONNECTIONS TO THE GAS PIPE NETWORK, BE SURE THAT THE MANUAL CUTOFF VALVES ARE CLOSED.

3.1 Gas Filter

The gas filters remove the dust particles that are present in the gas, and prevent the elements at risk (e.g.: burner valves, counters and regulators) from becoming rapidly blocked. The filter is normally installed upstream from all the control and on-off devices.



ATTENTION: it is reccomended to install the filter with gas flow parallel to the floor in order to prevent dust fall on the safety valve during maintenance operation.

3.2 Assembling the gas grain

Fig. 4 - Example of gas train

1-a) in case of threaded joints: use proper seals according to the gas used;

1-b) in case of flanged joints: place a gasket (no. 1A..1E - Fig. 4) between the elements


NOTE: the bellows unit, the manual valve and the gaskets are not part of the standard supply.



ATTENTION: once the gas train is mounted according to the diagram on Fig. 4, the gas proving test mus be performed, according to the procedure set by the laws in force.

Mounting

- 1. Mount flange onto tube lines: use appropriate sealing agent (see Fig. 7);
- 2. insert MB-DLE: note position of O rings (see Fig. 7);
- 3. tighten screws A, B, C and D (Fig. 5 Fig. 6), accordind to the mounting positions (Fig. 8);
- 4. after installation, perform leakage and functional test;
- 5. disassembly in reverse order.




The procedures of installation fo the gas valves are showed in the next paragraphs, according to the gas train used:

3.4 MULTIBLOC DUNGS MB-DLE 415..420

Mounting

- 1. Loosen screws A and B do not unscrew (Fig. 9 Fig. 10).
- 2. unscrew screws C and D (Fig. 9 Fig. 10).
- 3. Remove MultiBloc between the threaded flanges (Fig. 10).
- 4. After mounting, perform leakage and functional tests.



3.5 Siemens VGD20.. and VGD40.. gas valves - with SKP2.. (pressure governor)


Mounting

- When mounting the VGD.. double gas valve, two flanges are required (as for VGD20.. model, the flanges are threaded); to prevent
 cuttings from falling inside the valve, first fit the flanges to the piping and then clean the associated parts;
- install the valve;
- the direction of gas flow must be in accordance with the direction of the arrow on the valve body;
- ensure that the bolts on the flanges are properly tightened;
- ensure that the connections with all components are tight;
- make certain that the O-rings and gaskets between the flanges and the double gas valve are fitted.
- Connect the reference gas pipe (**TP** in figure; 8mm-external size pipe supplied loose), to the gas pressure nipples placed on the gas pipe, downstream the gas valves: gas pressure must be measured at a distance that must be at least 5 times the pipe size.

Leave the blowhole free (**SA** in figure). Should the spring fitted not permit satisfactory regulation, ask one of our service centres for a suitable replacement.

Caution: the SKP2 diaphragm D must be vertical (see Fig. 16).

WARNING: removing the four screws BS causes the device to be unserviceable!



Siemens VGD valves with SKP actuator :

The pressure adjusting range, upstream the gas valves group, changes according to the spring provided with the valve group.

Performance range (mbar)	0 - 22	15 - 120	100 - 250
Spring colour	neutral	yellow	red



ATTENTION: once the gas train is mounted according to the diagram on Fig. 4, the gas proving test mus be performed, according to the procedure set by the laws in force.

The pump provided with the burner must be installed according to the hydraulic diagram.

Kral KF-10 pumps

Capacity: 500 l/h Power consumption: 0.37 kW Speed: 1500 rpm Max outlet pressure: 10bar Max inlet pressure: 2bar NPSH: 2 mWC For further details see the manifacturer documentation.

Cucchi pumps FMG25

Capacity: 1500 l/h Power consumption: 0.75 kW Speed: 1400 rpm Max outlet pressure: 10bar Max inlet pressure: 2bar For further details see the manifacturer documentation.

4.1 About the use of fuel pumps


- Do not use fuel with additives to avoid the possible formation over time of compounds which may deposit between the gear teeth, thus obstructing them.
- After filling the tank, wait before starting the burner. This will give any suspended impurities time to deposit on the bottom of the tank, thus avoiding the possibility that they might be sucked into the pump.
- On initial commissioning a "dry" operation is foreseen for a considerable length of time (for example, when there is a long suction line to bleed). To avoid damages inject some lubrication oil into the vacuum inlet.
- Care must be taken when installing the pump not to force the pump shaft along its axis or laterally to avoid excessive wear on the joint, noise and overloading the gears.
- Pipes should not contain air pockets. Rapid attachment joint should therefore be avoided and threaded or mechanical seal junctions preferred. Junction threads, elbow joints and couplings should be sealed with removable sg component. The number of junctions should be kept to a minimum as they are a possible source of leakage.
- Do not use PTFE tape on the suction and return line pipes to avoid the possibility that particles enter circulation. These could deposit on the pump filter or the nozzle, reducing efficiency. Always use O-Rings or mechanical seal (copper or aluminium gaskets) junctions if possible.
- An external filter should always be installed in the suction line upstream the fuel unit.

4.2 Connecting the oil flexible hoses to the pump

To connect the flexible oil hoses to the pump, proceed as follows, according to the pump provided:


- 1 remove the closing nuts **A** (on the pump inlet) and **B** (from pump to the burner);
- 1 screw the rotating nut of the two flexible hoses on the pump **being careful to avoid exchanging the lines**: see the arrows marked on the pump.

For further information, refer to the technical documentation of the pump.



4.3 Connecting the compressed air hoses


To connect the compressed air supply, refer to the following pictures



4.4 Oil heaters connections

To connect the flexible oil hoses to the pump, proceed as follows, according to the pump provided:

- 1 remove the closing nuts **H** (on the heater) and **R** (on the oil pressure governor) of the inlet and return connections;
- 2 screw the rotating nut of the two flexible hoses on the burner **being careful to avoid exchanging the inlet and return lines**: see the arrows marked that show the inlet and the return.




4.5 Hydraulic connections to the combustion head



ATTENTION: do not reverse gas and oil connection!

- Key G Gas (pilot)
- A Compressed Air
- O Oil







Respect the basic safety rules. make sure of the connection to the earthing system. do not reverse the phase and neutral connections. fit a differential thermal magnet switch adequate for connection to the mains.

ATTENTION: before executing the electrical connections, pay attention to turn the plant's switch to OFF and be sure that the burner's main switch is in 0 position (OFF) too. Read carefully the chapter "WARNINGS", and the "Electrical connections" section.

To execute the electrical connections, proceed as follows:

- 1 remove the cover from the electrical board, unscrewing the fixing screws;
- 2 execute the electrical connections to the supply terminal board as shown in the attached wiring diagrams;
- 3 check the direction of the fan motor (see next paragraph);
- 4 refit the panel cover.

Refer to the attached document "RECOMMENDATIONS FOR LMV5x CONNECTIONS" and to the file "LMV5- EMC-Recommendatins, earthing shielding cabeling 2012-05-30" on the LMV5 CD attached to this manual.



WARNING: It is recommended to install a shunt trip disconnect switch. This device acts on the preheater unit supply line and avoids the oil overheating / resistance damage in case of a malfunction of the resistance contactor. Inside the electric board a free contact is provided (terminals 507 - 508) for this purpose.

5.1 Rotation of electric motor

Once the electrical connection of the burner is executed, remember to check the rotation of the electric motor. The motor should rotate according to the "arrow" symbol on the body. In the event of wrong rotation, reverse the three-phase supply and check again the rotation of the motor.




CAUTION: check the motor thermal cut-out adjustment


NOTE: the burners are supplied for three-phase 400V supply, and in the case of three-phase 230V supply it is necessary to modify the electrical connections into the terminal box of the electric motor and replace the overload tripped relay.

5.2 Note on elecrtical supply


If the power supply to the burner is 230V three-phase or 230V phase-phase (without a neutral), with the Siemens control box, between the terminal 2 (terminal X3-04-4 in case of LMV2x, LMV3x, LMV5x, LME7x) on the board and the earth terminal, an RC Siemens RC466890660 filter must be inserted.




Don't invert the wiring of the photocel connection to the LMV in order to don't damage the burner control device (LMV5).











6.0 Recommendations to design heavy oil feeding plants

This paragraph is intended to give some suggestions to make feeding plants for heavy oil burners. To get a regular burner operation, it is very important to design the supplying system properly. Here some suggestions will be mentioned to give a brief description.

The term "heavy oil" is generic and summarises several chemical-physical properties, above all viscosity. The excessive viscosity makes the oil impossible to be pumped, so it must be heated to let it flow in the pipeline; because of the low-boiling hydrocarbons and

dissolved gases, the oil must be also pressurised. The pressurisation is also necessary to feed the burner pump avoiding its cavitation because of the high suction at the inlet. The supplying system scope is to pump and heat oil.

The oil viscosity is referred in various unit measures; the most common are: °E, cSt, Saybolt and Redwood scales. Table 3 shows the various unit convertions (e.g.: 132 cSt viscosity corresponds to 17.5°E viscosity).

The diagram in Fig. 24 shows how the heavy oil viscosity changes according to its temperature.


Example: an oil with 22°E viscosity at 50°C once heated to 100°C gets a 3 °E viscosity.

As far as the pumping capability, it depends on the type of the pump that pushes the oil even if on diagram in Fig. 24 a generic limit is quoted at about 100 °E, so it is recommended to refer to the specifications of the pump provided.

Usually the oil minimum temperature at the oil pump inlet increases as viscosity does, in order to make the oil easy to pump. Referring to the diagram on Fig. 25, it is possible to realise that to pump an oil with 50°E viscosity at 50°C, it must be heated at about 80°C.

24





3ID0024	KEYS
POS	OIL TRAIN
1	Main tank
	OIL PUMPING UNIT
2	Manual valve
3	Filter
4	Pump coupled to electrical motor
5	Safety valve
6	One-way valve
7	Manual valve
8	Pressure gauge
9	High pressure switch - PO MAX
	DAILY TANK
10	Daily tank
11	Heating device
12	Electrical resistor
13	Pressure gauge
14	High pressure switch - PO MAX

Low pressure switch - PO MIN

Low thermostat - TCN

High thermostat - TRS

Thermometer

Thermostat - TR

Manual valve

Manual valve

15

16

17

18 19

20

21

PRESSURE GOVERNOR UNIT

22	Pressure gauge
23	Manual valve
24	Pressure governor
25	Needle valve

7.1 Pipe heating system

Pipe heating system must be provided, that is a system to heat pipes and plant components to mantain the viscosity in the pumping limits. Higher the oil viscosity and lower the ambient temperature, more necessary the pipe heating system.

7.2 Inlet minimum pressure of the pump (both for supplying system and burner)

A very low pressure leads to cavitation (signalled by its peculiar noise): the pump manifacturer declares the minimum value. Therefore, check the pump technical sheets.

By increasing the oil temperature, also the minimum inlet pressure at the pump must increase, to avoid the gassification of the oil lowboiling products and the cavitation. The cavitation compromises the burner operation, it causes the pump to break too. The diagram on Fig. 26 roughly shows the inlet pump pressure according to the oil temperature.

7.3 Pump operating maximum pressure (both for the supplying system and burner)

Remember that pumps and all the system components through which the oil circulates, feature an upper limit. Always read the technical documentation for each component. Schemes on and are taken from UNI 9248 "liquid fuel feeding lines from tank to burner" standard and show how a feeding line should be designed. For other countries, see related laws in force. The pipe dimensioning, the execution and the winding dimensioning and other construcitve details must be provided by the installer.

Viscosity units conversion table

Cinematics viscosity Centistokes (cSt)	Engler Degrees (°E)	Saybolt Seconds Universal (SSU)	Saybolt Seconds Furol (SSF)	Redwood Seconds no.1 (Standard)	Redwood Seconds no2 (Admiralty)
1	1	31		29	
2.56	1.16	35		32.1	
4.3	1.31	40		36.2	5.1
7.4	1.58	50		44.3	5.83
10.3	1.88	60		52.3	6.77
13.1	2.17	70	12.95	60.9	7.6
15.7	2.45	80	13.7	69.2	8.44
18.2	2.73	90	14.44	77.6	9.3
20.6	3.02	100	15.24	85.6	10.12
32.1	4.48	150	19.3	128	14.48
43.2	5.92	200	23.5	170	18.9
54	7.35	250	28	212	23.45
65	8.79	300	32.5	254	28
87.6	11.7	400	41.9	338	37.1
110	14.6	500	51.6	423	46.2
132	17.5	600	61.4	508	55.4
154	20.45	700	71.1	592	64.6
176	23.35	800	81	677	73.8
198	26.3	900	91	762	83
220	29.2	1000	100.7	896	92.1
330	43.8	1500	150	1270	138.2
440	58.4	2000	200	1690	184.2
550	73	2500	250	2120	230
660	87.6	3000	300	2540	276
880	117	4000	400	3380	368
1100	146	5000	500	4230	461
1320	175	6000	600	5080	553
1540	204.5	7000	700	5920	645
1760	233.5	8000	800	6770	737
1980	263	9000	900	7620	829
2200	292	10000	1000	8460	921
3300	438	15000	1500	13700	
4400	584	20000	2000	18400	

Tab. 8

8.1 Adjusting the supplying oil ring

According to the heavy oil viscosity used, in the table below indicative temperature and pressure values to be set are shown. **Note:** the temperature and pressure range allowed by the supplying ring components must be checked in the specifications table of the components themselves.

According to the heavy oil viscosity used, in the table below indicative temperature and pressure values to be set are shown.

Note: the temperature and pressure range allowed by the supplying ring components must be checked in the specifications table of the components themselves.

HEAVY OIL VISC	COSITY AT 50 °C	PIPELINE PRESSURE	PIPELINE TEMPERATURE
cSt	(°E)	bar	°C
	< 50 (7)	1-2	20
> 50 (7)	< 110 (15)	1- 2	50
> 110 (15)	< 400 (50)	1- 2	65
> 400 (50)	< 4000 (530)	1- 2	100

Tab. 1 - Supply pipeline hydraulic scheme 3ID0024, pump n.4




Fig. 24

Indicative diagram showing the oil temperature at burner pump inlet vs. oil viscosity

Example: if the oil has a 50°E @ 50°C viscosity, the oil temperature at the pump inlet should be 80°C (see diagram).





Fig. 25

Indicative diagram showing the oil pressure according to its temperature





PART III: OPERATION

LIMITATIONS OF USE: PLEASE REFER TO THE CHAPTER "WARNINGS" AT THE BEGINNING OF THIS MANUAL.

9.0 PRELIMINARY OPERATIONS



Before starting up the burner, make sure that the return pipe to the tank is not obstructed. Any obstruction would cause the pump seal to break.



ATTENTION: before starting the burner up, be sure that the manual cutoff valves are open. Be sure that the mains switch is closed.


The figure below shows nozzle flow valve. Before turn on the burner, open the manual valve.



manual valve

9.1 Air vent

Before to give tension to the eletrical resistance, release the air inside the heaters throught the SA connection acting on the T cap.



9.2 Oil thermostat adjustment

Progressive and fully modulanting oil burners are equipped with electronic multi-thermostat Danfoss MCX, whose operation is controlled by thyristor. (for details refer to the attached technical documentation)



Fig. 27 - Danfoss MCX




Fig. 28 - Probe connections (Danfoss MCX)


ſ	Menu pa	th		C	° کا viscosity at 50	C according to the burner model	eletter shown in th	e
				Р	Ν	E	D	Н
				89 cSt	< 50 cSt	> 50 cSt	> 110 cSt	> 400 cSt
						< 110 cSt	< 400 cSt	< 4000 cSt
				12 °E	< 7°E	> 7 °E	> 15 °E	> 50 °E
						< 15 °E	< 50 °E	< 530 °E
Par								
rEG	Pb1	tr	Oil heater temperature probe		р	arameter not visib	le	
	Pb2	tCl	Plant consent temperature probe	20 °C	70 °C	70 °C	70 °C	
	DLO	0.1	(when installed)					
	Pb3	Oil	oil heater output temperature	60-70 °C	110-120 °C	120-130 °C	130-140 °C	140-150 °C
			probe (PID regulation);					
		SP0	Set-point oil heater with oil pump	45 °C	120 °C	130 °C	140 °C	150 °C
			stopped (stand-by)	43 0	120 0	130 0	140 0	150 0
	Pb4	tcn	Oil heater consent temperature	40 °C	100 °C	100 °C	110 °C	120 °C
			probe	40 0	100 °C	100 °C	10.0	120 0
		trS	Safety temperature tank resistors	100.00	100 200 %C	100 200 %C	100 200 %C	100 200 %
			(manual reset)	120 °C	190-200 °C	190-200 °C	190-200 °C	190-200 °C


The oil viscosity at the nozzle, should be about 1,5 °E, which guarantees correct and safe functioning of the burner. The above temperature values are suggested and refer to a plant designed according to the prescriptions in the burner user manual. The suggested values can change in reference to the fuel oil specifications.


9.3 Oil Flow Rate Settings

The light oil flow rate can be adjusted choosing a pneumatic nozzle that suits the boiler/utilisation output and setting the delivery and return pressure values according to the ones quoted on the following charts.

FLUIDICS 12AG 70Kg/h







PART III: OPERATION

Nozzle - Pressure fuel flow diagram

VISCOSITY AT 50 °C		OIL PRESSURE AFTER BURNER PUMP		OIL PRESSURE AFTER OIL METERING VALV	
		min	max	min	max
°cSt (°E)		bar		Ó°	
	< 50 (7)	7	9	1	6
> 50 (7)	< 110 (15)	7	9	1	6
> 110 (15)	< 400 (50)	7	9	1	6
> 400 (50)	<4000 (530)	7	9	1	6
			Tab. 3		

The pressure values shown in the table are intended as working range. In order to obtain a more accurate indication, please refer to the nozzle pressure-flow diagrams.

9.4 Air valve for gun cleaning


As the flame is off, the purge valve 24 opens automatically the compressed air to clean the gun. With this operation, the oil between the valves and the nozzle is drained. The air pressure value for the gun cleaning must be setted to the pressure value of the atomization medium, regulated in low flame (generally 1 bar), and should be adjusted throught the item 37. (see hydraulic diagram of the burner)



Fig. 29



ATTENTION: before starting the burner up, be sure that the manual cutoff valves are open and check that the pressure upstream the gas train complies the value quoted on paragraph "Technical specifications". Be sure that the mains switch is closed.



Key

- A High flame mode indicating light
- B Low flame mode indicating light
- C Ignition transformer operation
- D Fan motor overload tripped intervention
- E Burner lockout iindicationg light
- F Stand-by mode indicating light
- G Gas valve EV2 operation
- H Gas valve EV1 operation
- I Gas pressure switch consent
- IRA Pre-heater resistor switch
- L Oil solenoid valve operation
- M Gas proving system intervention
- N Flame monitor device reset pushbutton
- O Gas proving system device reset pushbutton
- P Pre-heating resistors safety thermostat
- Q Pre-heating oil tank
- R AZL2x
- CM Main switch/operation mode
 - Gas / Oil

11.1 Adjustments - brief description

To change the burner setting during the testing in the plant, follow the next procedure.

Adjust the air and gas flow rates at the maximum output ("high flame") first, by means of the air damper and the adjusting cam respectively.

- Check that the combustion parameters are in the suggested limits.
- Check the flow rate measuring it on the fuel counter.
- Then, adjust the combustion values corresponding to the points between maximum and minimum, according to the procedure described on the "LMV5xx Service manual".
- Set, now, the low flame output (according to the procedure described on the "LMV5xx Service manual") in order to avoid the low
 flame output increasing too much or that the flues temperature gets too low to cause condensation in the chimney.

The heavy oil flow rate can be adjusted choosing a nozzle that suits the boiler/utilisation output and setting properly the delivery pressure values.



.ATTENTION: During commissioning operations, do not let the burner operate with insufficient air flow (danger of formation of carbon monoxide); if this should happen, make the fuel decrease slowly until the normal combustion values are achieved.

Δ


IMPORTANT! the combustion air excess must be adjusted according to the values in the following chart.

Recommended combustion parameters					
Fuel	Recommended (%) CO ₂	Recommended (%) O ₂			
Heavy oil	11 ÷ 12.5	4.7 ÷ 6.7			
Natural gas	9 ÷ 10	3 ÷ 4.8			

Now adjust the pressure switches (see next par.).

11.2 User interface

The AZL2x.. display is shown below: The keys functions are the following:





Key F

Used to adjust the "fuel" actuator position (Fuel): : While pressing the F key, the "fuel" actuator position can be changed by means of the + and - keys.



Key A

Key F + A

Used to adjust the "air" actuator position (Air):

While pressing the A key, the "air" actuator position can be changed by means of the + and - keys.

While pressing the two keys contemporarly, the code message will appear: by entering the proper

≗nfo

Info and Enter keys

Used for Info and Service menues

- Used as Enter key in the setting modes
- Used as Reset key in the burner operation mode

password it is possible to access the Service mode.

Used to enter a lower level menu

-Key -

Used to decrease a a value

Used to enter Info and Serivce during the curve adjustments

+Kev +

Used to increase a a value

Used to enter Info and Serivce during the curve adjustments



Keys (+ & -)= ESC

By pressing + and - at the same time, the ESCAPE function is perfomed:

to erase a entered value

to enter a lower level menu

PART III: OPERATION

The display will show these data:

Lock+unlock codes

Flame

Open valves Ignition transformers energised

Fan motor energised

Oil pre-heater energised Plant heat request

Parametere setting mode

Info mode


Service mode

Closing actuator

Opening actuator

Unit measure

The display will show these data:



11.3 Setting menu

The setting menu is divided into different blocks:

Bloc.	Descrizione	escrizione Description			
100	Informazioni generali	General	OEM / Service / Info		
200	Controllo bruciatore	Burner control	OEM / Service		
400	Curve rapporto	Ratio curves	OEM / Service		
500	Controllo rapporto	Ratio control	OEM / Service		
600	Servocomandi	Actuators	OEM / Service		
700	Storico errori	Error history	OEM / Service / Info		
900	Dati di processo	Process data	OEM / Service / Info		

The accesses to the various blocks are allowed by passwords. Passwords are divided into three levels:

- User level (info): no password needed
- Service level (Service)
- Manifacturer level (OEM)


11.4 PHASES LIST

During operation, the following program phases are shown. The meaning for each phase is quoted in the table below

Phase	Funzione	Function		
Ph00	Fase blocco	Lockout phase		
Ph01	Fase di sicurezza	Safety phase		
Ph10	t10 = tempo raggiungimento posizione riposo	t10 = home run		
Ph12	Pausa	Standby (stationary)		
Ph22	t22 = tempo di salita ventilatore (motore ventilatore = ON, valvola intercettazione di sicurezza = ON)	t22 = fan ramp up time (fan motor = ON, safety shutoff valve = ON)		
Ph24	Verso posizione preventilazione	Traveling to the prepurge position		
Ph30	t1 = tempo preventilazione	t1 = prepurge time		
Ph36	Verso posizione accensione	Traveling to the ignition position		
Ph38	t3 = tempo preaccensione	t3 = preignition time		
Ph40	TSA1 = primo tempo sicurezza (trasformatore accen- sione ON)	TSA1= 1st safety time (ignition transformer ON)		
Ph42	TSA1 = primo tempo sicurezza (trasformatore accen- sione OFF)	TSA1 = 1st safety time (ignition transformer OFF)		
		t42 = preignition time OFF		
Ph44	t44 = intervallo 1	t44 = interval 1		
Ph50	TSA2 = secondo tempo sicurezza	TSA2 = 2nd safety time		
Ph52	t52 = intervallo2	t52 = interval 2		
Ph60	Funzionamento 1 (stazionario)	Operation 1 (stationary)		
Ph62	t62 = massimo tempo bassa fiamma (funzionamento 2, in preparazione per spegnimento, verso bassa fiamma)	t62 = max. time low-fire (operation 2, prepa- ring for shutdown, traveling to low-fire)		
Ph70	t13 = tempo postcombustione	t13 = afterburn time		
Ph72	Verso posizione postcombustione	Traveling to the postpurge position		
Ph74	t8 = tempo postventilazione	t8 = postpurge time		
Ph80	t80 = tempo evacuazione controllo tenuta valvole	t80 = valve proving test evacuation time		
Ph81	t80 = tempo perdita pressione atmosferica, prova atmo- sferica	t81 = leakage time test time atmospheric pressure, atmospheric test		
Ph82	t82 = test perdita, test riempimento	t82 = leakage test filling test, filling		
Ph83	t80 = tempo perdita pressione gas, test pressione	t83 = leakage test time gas pressure, pres sure test		
Ph90	Tempo attesa "mancanza gas"	Gas shortage waiting time		

11.5 Entering the Parameter levels

By means of a proper use of the keys, it is possible to enter the various level parameters, as shown in the following flow chart:



The burner and consequently the LMV2x.. are factory set; the air and fuel curves as set as well.

11.6 Info level

To enter the Info level, proceed as follows:

1 in any menu position, press keys + and - at the same time, then the program will start again: the display will show OFF.



2 until the display will show InFo, Press the enter (InFo) key


		WW	\bigcirc	œ	Zł	p		
Р	īĀ	Ā	Ē	Ā	Π	Ā	Ā	M
1 L	Ð.	.0.	Ð.	П	Ш.	0	, [],	Ø
2	∇	\triangle	V	h	min	s	%	¥

- 3 then il will show the first code (167) flashing, on the right side it will show the data entered. By pressing + or it is possible to scroll (up or down) the parameter list.
- 4 If a dot-line is shown on the right, there is no enough room for complete visualisation: press enter again the data will be completely shown for 1 to 3 seconds. By pressing enter or + and- at the same time, the system will exit the parameter visualisation and go back to the flashing number.

The Info level shows some basic parameters as:

Parameter	Description
167	Cubic meters of fule (resettable)
162	Operating hours (resettable)
163	Device operating hours
164	Burners start-ups (resettable)
166	Total number of start-ups
113	Burner number (i.e. serial number)
107	Software version
102	Software date
103	Device serial number
104	Parameter set preassignment: Customer code
105	Parameter set preassignment: Version
143	Free

5 Example: choose parameter 102 to show the date



the display shows parameter **102** flashing on the left and characters .___ on the right.

- 6 press InFo for 1-3 seconds: the date will appear
- 7 press InFo to go back to parameter "102"
- 8 by pressing + / -, it is possible to scroll up/down the parameter list (see table above), or, by pressing ESC or InFo for more seconds, the display will show
- 9 Once the last parameter is accessed (143) by pressing +, the End message will flash.

	\sum	2WW	CN.	on I	1 M	p		
Ρ	13	ā	2		5	R	a	1
ñ	H	-	H۰	П	H.	H	H	日
S			Ξ,					
	∇	\triangle	V	Ы	nNn	s	%	¥


10 Press InFo info for more than three seconds or for more than three seconds orto return to the normal display.

	Σ	WW/	C	œ	Zł	p		
Ρ	ī	ī	ī	Ā	ī	Ē		M
ñ a	H	. П .	D.	۵	:П	۳.	Ľ.	Ø
~	-			_				_
	∇	\triangle	V	h	min	s	%	¥

If a message like the one below is shown during operation,



it means that the burner is locked out and the Errore code is shown (in the example "error code:4"); this message is alternating with another message



Diagnostic code (in the example "diagnostic code:3"). Record the codes and find out the fault in the Error table. To perform the reset, press InFo for one second:

	Σ		WW/	C	œ	ZX	Þ		
P î	Ī	1.	ρ	Q	P	Ē.	Ā.	Ā	2
Ś	Ľ	J.				<u>ш</u> .	Щ.		
	\sim	7	\triangle	V	h	min	s	%	¥

The unit displays an event which does not lead to shutdown.

The display shows current error code c: alternating with diagnostic code d:

		PWW	\Box	œ	Zł	p		
P °ĩ √	B	8	Ē	8	0.	8	8	7
2	∇	\triangle	V	h	min	s	%	

Press **InFo** to return to the display of phases. Example: Error code **111** / diagnostic code 0

		ww	C	œ		p		
P î	B	0	E.	8	UIII.	Ø.	8	7
~								-
	∇	\triangle	V	h	min	s	%	X

To reset, press InFo for a second. Record the codes and check the Error List to find the type of faults.

11.7 Service level

To enter the Service mode, press InFo until the display will show:



The service level shows all the information about flame intensity, actuators position, number and lock codes:

Parameter	Description
954	Flame intensity
121	% output, if set = automatic operation
922	Actuators position, 00=combustibile; 01= aria
161	Lock-outs number
701725	Lock-outs History (see chapter 23 in the LMV2x manual)



- 1 the first parameter will be "954": the percentage of flame is shown on the right. By pressinf + or it is possible to scroll up/down the parameter list.
- 2 Once the last parameter is accessed (143) by pressing + , the **End** message will blink.

P = = = *	1.5
ñ 📭 🖛 🖛 🖛 🖛 🖛	10 10
⊽∆ v ⁰ h nyn s %	6 ≮

3 Press InFo info for more than three seconds or for more than three seconds orto return to the normal display.

	Σ	M	Mr	C	œ	ZY	p		
Ρ		ī	٦	Ē	Ā	ī	Ē		1
Ĭ N		ů	l.°	D.	۵		ĴŪ.	D.	Ø
	U		_						
	∇	' Z	7	V	h	min	s	%	¥

For further nformation, see tha LMV2 related manual.

11.8 Calibration of air pressure switch

To calibrate the air pressure switch, proceed as follows:

- Remove the transparent plastic cap.
- Once air and fuel setting have been accomplished, startup the burner.
- During the pre-purge phase o the operation, turn slowly the adjusting ring nut **VR** in the clockwise direction (to increase the adjusting pressure) until the burner lockout, then read the value on the pressure switch scale and set it to a value reduced by 15%.
- Repeat the ignition cycle of the burner and check it runs properly.
- Refit the transparent plastic cover on the pressure switch.

11.9 Calibration of low gas pressure switch

As for the gas pressure switch calibration, proceed as follows:

- Be sure that the filter is clean.
- Remove the transparent plastic cap.
- While the burner is operating at the maximum output, test the gas pressure on the pressure port of the minimum gas pressure switch.
- Slowly close the manual cutoff valve (placed upstream the pressure switch, see gas train installation diagram), until the detected
 pressure is reduced by 50%. Pay attention that the CO value in the flue gas does not increase: if the CO values are higher than the
 limits laid down by law, slowly open the cutoff valve as to get values lower than these limits.
- Check that the burner is operating correctly.
- Clockwise turn the pressure switch adjusting ring nut (as to increase the pressure value) until the burner stops.
- Slowly fully open the manual cutoff valve.
- Refit the transparent plastic cover on the pressure switch.

11.10 Adjusting the maximum gas pressure switch (when provided)

To calibrate the maximum pressure switch, proceed as follows according to its mounting position:

- 1 remove the pressure switch plastic cover;
- 2 if the maximum pressure switch is mounted upstreaam the gas valves: measure the gas pressure in the network, when flame is off; by means of the adjusting ring nut **VR**, set the value read, increased by the 30%.
- 3 if the maximum pressure switch is mounted downstream the "gas governor-gas valves" group and upstream the butterfly valve: light the burner, adjust it according to the procedure in the previous paragrph. Then, measure the gas pressure at the operating flow rate, downstream the "gas governor-gas valves" group and upstream the butterfly valve; by means of the adjusting ring nut VR, set the value read on step 2, increased by the 30%;
- 4 replace the plastic cover.

11.11 PGCP Gas leakage pressure switch (witn Siemens LDU burner control/Siemens LMV Burner Management System)

- remove the pressure switch plastic cover;
- adjust the PGCP pressure switch to the same value set for the minimum gas pressure switch;
- replace the plastic cover.



Fig. 30

Pressure adjustment


Remove cap-nut 1 and the gasket 2, unscrew the lock nut 4. To increase pressure, twist adjusting screw 3 clockwise.

To decrease the pressure, twist screw counterclockwise. Tight the lock nut 4, refit the gasket 2 and the cap nut 1.

Key

- 1 Cap nut
- 2 Gasket
- 3 Adjusting screw
- 4 Lock nut
- 5 Gasket

Λ







11.13 Setting the combustion head position

CAUTION: perform these adjustments once the burner is turned off and cooled.

The burner is factory-set with the combustion head "fully-ahead" that refers to the maximum output. As for "fully-ahead" position, it means that the head is towards the boiler, "fully-backward" position means that the head is towards the operator. **G1:** move diffuser, gas nozzle and oil nozzle together

G2: move oil nozzle






11.14 Center head holes gas flow regulation

To adjust the gas flow, partially close the holes, as follows:

- 1 loosen the three **V** screws that fix the adjusting plate **D**;
- 2 insert a screwdriver on the adjusting plate notches and let it move CW/CCW as to open/close the holes;
- 3 once the adjustmet is performed, fasten the V screws.

The adjusting plate correct position must be regulated in the plant during the commissioning.




Multibloc MB-DLE


The multibloc unit is a compact unit consisting of two valves, gas pressure switch, pressure stabilizer and gas filter.

The valve is adjusted by means of the **RP** regulator after slackening the locking screw **VB** by a number of turns. By unscrewing the regulator RP the valve opens, screwing the valve closes. To set the fast opening remove cover T, reverse it upside down and use it as a tool to rotate screw VR. Clockwise rotation reduces start flow rate, anticlockwise rotation increases it.

Do not use a screwdriver on the screw VR!

The pressure stabilizer is adjusted by operating the screw VS located under the cover C. By screwing down the pressure is increased and by unscrewing it is reduced. Note: the screw VSB must be removed only in case of replacemente of the coil.





Key

- 1 Electrical connection for valves
- 2 Operation display (optional)
- 3 Pressure governor closing tap
- 4 Start setting cap
- 5 Hydraulic brake and rate regulator
- 6 Coil
- 7 Test point connection G 1/8
- 8 Test point connection G 1/8 downstream of valve 1, on both sides 18 Pressure switch electric connection

- 9 Output flange
- 10 Test point connection M4 downstream of valve 2
- 11 Gas flow direction
- 12 Test connection G 1/8 downstream of valve 1, on both sides
- 13 Vent nozzle pressure regulator
- 14 Filter (below cover)
- 15 Input flange
- 17 Pressure switch

PART IV: MAINTENANCE

At least once a year carry out the maintenance operations listed below. In the case of seasonal servicing, it is recommended to carry out the maintenance at the end of each heating season; in the case of continuous operation the maintenance is carried out every 6 months.



WARNING: ALL OPERATIONS ON THE BURNER MUST BE CARRIED OUT WITH THE MAINS DISCONNECTED AND THE FUEL MANAUL CUTOFF VALVES CLOSED!

ATTENTION: READ CAREFULLY THE "WARNINGS" CHAPTER AT THE BEGINNIG OF THIS MANUAL..

12.0 ROUTINE MAINTENANCE

- Clean and examine the gas filter cartridge and replace it if necessary (see next paragraphs);
- Remove and clean the combustion head (see page 45);
- Examine and clean the ignition electrode, adjust and replace it if necessary (see page 61-page 61)
- Examine and clean the detection photoelement, replace it if necessary (see page 50), in case of doubt, check the detection circuit, after the burner start-up (see Fig. 39);
- .Cleaning and greasing of leverages and rotating parts.



ATTENTION: when servicing, if it was necessary to disassemble the gas train parts, remember to execute the gas proving test, once the gas train is reassembled, according to the procedure imposed by the law in force.

12.1 Light oil filter maintenance

For correct and proper servicing, proceed as follows:

- 1 cutoff the required pipe section;
- 2 unscrew the filter cup;
- 3 remove the filtering cartridge, wash it with gasoline; if necessary, replace it; check the tightening O-rings and replace them if necessary;
- 4 replace the cup and restore the pipe line.




12.2 Gas filter maintenance



ATTENTION: Before opening the filter, close the manual cutoff valve downstream the filter and bleed the gas; check that inside the filter there is no pressurised gas.

To clean or remove the filter, proceed as follows:

- 1 remove the cap unscrewing the fixing screws (A);
- 2 remove the filtering cartridge (B), clean it using water and soap, blow it with compressed air(or replace it, if necessary)
- 3 replace the cartridge in its proper position taking care to place it inbetween the guides as not to hamper the cap replacement;
- 4 be sure to replace the "O" ring into its place (C) and replace the cover fastening by the proper screws (A).





12.3 Removing the filter in the MULTIBLOC DUNGS MB-DLE 415 - 420 B01 1" 1/2 - 2"


- Check the filter at least once a year!
- Change the filter if the pressure difference between pressure connection 1 and 2 (Fig. 35-Fig. 36) ∆p> 10 mbar.
- Change the filter if the pressure difference between pressure connection 1 and 2 (Fig. 35-Fig. 36) is twice as high compared to the last check.

You can change the filter without removing the fitting.

- 1 Interrupt the gas supply closing the on-off valve.
- 2 Remove screws $1 \div 6$ (Fig. 37).
- 3 Change filter insert.
- 4 Re-insert filter housing, screw in screws 1 ÷ 6 without using any force and fasten.
- 5 Perform leakage and functional test, p_{max} = 360 mbar.
- 6 Pay attention that dirt does not fall inside the valve.








12.4 Replacing the spring in the gas valve group

To replace the spring in the gas valve group, proceed as follows:

- 1 Carefully twist the protection cap 1 and the O-ring 2.
- 2 remove the "set value" spring 3 from housing 4.
- 3 Replace spring 3.
- 4 Carefully insert the new "set value" spring. Pay attention to mount properly. First insert the spring part with smaller diameter in the housing.
- 5 Place O-ring 2 in protective cap 1. Screw in the protective cap with the O-ring in it.
- 6 Stick the adhesive label for spring identification on the type plate.



SKP Siemens actuator

12.5 Electrodes Adjustment

Important Note: Check the ignition and detection electrodes after removing/adjusting the combustion head.



ATTENTION: avoid the ignition and detection electrodes to contact metallic parts (blast tube, head, etc.), otherwise the boiler's operation would be compromised. Check the electrodes position after any intervention on the combustion head.

Adjust the electrodes position, according to the quotes shown othe next picture




Fig. 38

12.6 Cleaning and replacing the detection photocell


To clean/replace the detection photocell, proceed as follows:

- 1 Disconnect the system from the electrical power supply.
- 2 Shut off the gas supply
- 3 remove the photocell from its slot;
- 4 clean the bulbe if dirty, taking care not to touch it with bare hands;
- 5 if necessary, replace the bulb;
- 6 replace the photocell into its slot.

12.7 Checking the detection current

To check the detection current follow the diagram on Fig. 39. If the signal is less than the value indicated, check the position of the detection electrode or detector, the electrical contacts and, if necessary, replace the electrode or the detector.

Device	Flame detector	Minimum detection signal
Siemens LMV2x/3x	QRA	70 μA (intensity of flame >24%)





ATTENTION: don't invert thw wires, the risk is to damage also the burner control LMV!.

12.8 Seasonal stop

To stop the burner in the seasonal stop, proceed as follows:

- 1 turn the burner main switch to 0 (Off position)
- 2 disconnect the power mains
- 3 close the fuel valve of the supply line

12.9 Burner disposal

In case of disposal, follow the instructions according to the laws in force in your country about the "Disposal of materials".

13.0 WIRING DIAGRAMS

Refer to the attached wiring diagrams.

WARNING

- 1 Electrical supply 230V 50Hz 1 a.c./400V 50Hz 3N a.c.
- 2 Do not reverse phase with neutral3 Ensure burner is properly earthed



C.I.B. UNIGAS S.p.A. Via L.Galvani, 9 - 35011 Campodarsego (PD) - ITALY Tel. +39 049 9200944 - Fax +39 049 9200945/9201269 web site: www.cibunigas.it - e-mail: cibunigas@cibunigas.it

Note: specifications and data subject to change. Errors and omissions exceptd.

AZL2x - LMV2x/3x Burner Management System



Service manual

INDEX

MICROPROCESSOR CONTROLLED SYSTEM	6
User interface	6
Parameters level (heating engineer)	8
Setting menu	9
Block 000: Internal Parameter	10
Block 100: General information	10
Block 200: Burner control	. 13
Block 400: Setting air/fuel ratio curves	25
Block 500: Air/fuel ratio control	. 26
Block 600: Actuators	28
Block 700: Error history	31
Block 900: Process data	32
Actuators references	33
Gas proving system	33
Air-fuel curve points	33
COMMISSIONING THE BURNER	34
Warm setting	38
Cold setting	39
BURNER STARTUP WITH LMV2x ALREADY PROGRAMMED	. 40
Reset / manual lockout	. 42
Timeout for menu operation	42
Entering the Parameter levels	. 43
Info level	44
Service level	. 46
PHASES LIST	. 47
BACKUP PARAMETER WITH AZL2x	48
RESTORE PARAMETER FROM AZL2x TO LMV	. 49
WIRING DIAGRAM	65
Wiring connection for LMV20	65
Wiring variants for LMV27	66
Wiring variants for LMV26	67
Wiring variants for LMV37	68

DANGERS, WARNINGS AND NOTES OF CAUTION

THIS MANUAL IS SUPPLIED AS AN INTEGRAL AND ESSENTIAL PART OF THE PRODUCT AND MUST BE DELIVERED TO THE USER.

INFORMATION INCLUDED IN THIS SECTION ARE DEDICATED BOTH TO THE USER AND TO PERSONNEL FOLLOWING PRO-DUCT INSTALLATION AND MAINTENANCE.

THE USER WILL FIND FURTHER INFORMATION ABOUT OPERATING AND USE RESTRICTIONS, IN THE SECOND SECTION OF THIS MANUAL. WE HIGHLY RECOMMEND TO READ IT.

CAREFULLY KEEP THIS MANUAL FOR FUTURE REFERENCE.

1) GENERAL INTRODUCTION

- The equipment must be installed in compliance with the regulations in force, following the manufacturer's instructions, by qualified personnel.
- Qualified personnel means those having technical knowledge in the field of components for civil or industrial heating systems, sanitary hot water generation and particularly service centres authorised by the manufacturer.
- Improper installation may cause injury to people and animals, or damage to property, for which the manufacturer cannot be held liable.
- Remove all packaging material and inspect the equipment for integrity.

In case of any doubt, do not use the unit - contact the supplier.

The packaging materials (wooden crate, nails, fastening devices, plastic bags, foamed polystyrene, etc), should not be left within the reach of children, as they may prove harmful.

- Before any cleaning or servicing operation, disconnect the unit from the mains by turning the master switch OFF, and/or through the cutout devices that are provided.
- Make sure that inlet or exhaust grilles are unobstructed.
- In case of breakdown and/or defective unit operation, disconnect the unit. Make no attempt to repair the unit or take any direct action.

Contact qualified personnel only.

Units shall be repaired exclusively by a servicing centre, duly authorised by the manufacturer, with original spare parts.

Failure to comply with the above instructions is likely to impair the unit's safety.

To ensure equipment efficiency and proper operation, it is essential that maintenance operations are performed by qualified personnel at regular intervals, following the manufacturer's instructions.

- When a decision is made to discontinue the use of the equipment, those parts likely to constitute sources of danger shall be made harmless.
- In case the equipment is to be sold or transferred to another user, or in case the original user should move and leave the unit behind, make sure that these instructions accompany the equipment at all times so that they can be consulted by the new owner and/or the installer.
- For all the units that have been modified or have options fitted then original accessory equipment only shall be used.
- This unit shall be employed exclusively for the use for which it is meant. Any other use shall be considered as improper and, therefore, dangerous.

The manufacturer shall not be held liable, by agreement or otherwise, for damages resulting from improper installation, use and failure to comply with the instructions supplied by the manufacturer. The occurrence of any of the following circustances may cause explosions, polluting unburnt gases (example: carbon monoxide CO), burns, serious harm to people, animals and things:

- Failure to comply with one of the WARNINGS in this chapter

- Incorrect handling, installation, adjustment or maintenance of the burner
- Incorrect use of the burner or incorrect use of its parts or optional supply

2) SPECIAL INSTRUCTIONS FOR BURNERS

- The burner should be installed in a suitable room, with ventilation openings complying with the requirements of the regulations in force, and sufficient for good combustion.
- Only burners designed according to the regulations in force should be used.
- This burner should be employed exclusively for the use for which it

was designed.

- Before connecting the burner, make sure that the unit rating is the same as delivery mains (electricity, gas oil, or other fuel).
- Observe caution with hot burner components. These are, usually, near to the flame and the fuel pre-heating system, they become hot during the unit operation and will remain hot for some time after the burner has stopped.

When the decision is made to discontinue the use of the burner, the user shall have qualified personnel carry out the following operations:

- a Remove the power supply by disconnecting the power cord from the mains.
- b) Disconnect the fuel supply by means of the hand-operated shut-off valve and remove the control handwheels from their spindles.

Special warnings

- Make sure that the burner has, on installation, been firmly secured to the appliance, so that the flame is generated inside the appliance firebox.
- Before the burner is started and, thereafter, at least once a year, have qualified personnel perform the following operations:
- a set the burner fuel flow rate depending on the heat input of the appliance;
- b set the flow rate of the combustion-supporting air to obtain a combustion efficiency level at least equal to the lower level required by the regulations in force;
- c check the unit operation for proper combustion, to avoid any harmful or polluting unburnt gases in excess of the limits permitted by the regulations in force;
- d make sure that control and safety devices are operating properly;
- e make sure that exhaust ducts intended to discharge the products of combustion are operating properly;
- f on completion of setting and adjustment operations, make sure that all mechanical locking devices of controls have been duly tightened;
- g make sure that a copy of the burner use and maintenance instructions is available in the boiler room.
- In case of a burner shut-down, reser the control box by means of the RESET pushbutton. If a second shut-down takes place, call the Technical Service, without trying to RESET further.
- The unit shall be operated and serviced by qualified personnel only, in compliance with the regulations in force.

3) GENERAL INSTRUCTIONS DEPENDING ON FUEL USED

3a) ELECTRICAL CONNECTION

- For safety reasons the unit must be efficiently earthed and installed as required by current safety regulations.
- It is vital that all saftey requirements are met. In case of any doubt, ask for an accurate inspection of electrics by qualified personnel, since the manufacturer cannot be held liable for damages that may be caused by failure to correctly earth the equipment.
- Qualified personnel must inspect the system to make sure that it is adequate to take the maximum power used by the equipment shown on the equipment rating plate. In particular, make sure that the system cable cross section is adequate for the power absorbed by the unit.
- No adaptors, multiple outlet sockets and/or extension cables are permitted to connect the unit to the electric mains.
- An omnipolar switch shall be provided for connection to mains, as required by the current safety regulations.
- The use of any power-operated component implies observance of a few basic rules, for example:
 - do not touch the unit with wet or damp parts of the body and/or with bare feet;
 - do not pull electric cables;

- do not leave the equipment exposed to weather (rain, sun, etc.) unless expressly required to do so;

- do not allow children or inexperienced persons to use equipment;
- The unit input cable shall not be replaced by the user.

In case of damage to the cable, switch off the unit and contact qualified personnel to replace.

When the unit is out of use for some time the electric switch supplying all the power-driven components in the system (i.e. pumps, burner, etc.) should be switched off.

3b) FIRING WITH GAS, LIGHT OIL OR OTHER FUELS GENERAL

- The burner shall be installed by qualified personnel and in compliance with regulations and provisions in force; wrong installation can cause injuries to people and animals, or damage to property, for which the manufacturer cannot be held liable.
- Before installation, it is recommended that all the fuel supply system pipes be carefully cleaned inside, to remove foreign matter that might impair the burner operation.
- Before the burner is commissioned, qualified personnel should inspect the following:
- the fuel supply system, for proper sealing; а
- the fuel flow rate, to make sure that it has been set based on the b firing rate required of the burner;
- the burner firing system, to make sure that it is supplied for the desiс gned fuel type;
- the fuel supply pressure, to make sure that it is included in the range d shown on the rating plate;
- the fuel supply system, to make sure that the system dimensions are e adequate to the burner firing rate, and that the system is equipped with all the safety and control devices required by the regulations in force.
- When the burner is to remain idle for some time, the fuel supply tap or taps should be closed.

SPECIAL INSTRUCTIONS FOR USING GAS

Have gualified personnel inspect the installation to ensure that:

- the gas delivery line and train are in compliance with the regulations а and provisions in force;
- all gas connections are tight; b
- the boiler room ventilation openings are such that they ensure the air с supply flow required by the current regulations, and in any case are sufficient for proper combustion.
- Do not use gas pipes to earth electrical equipment.
- Never leave the burner connected when not in use. Always shut the gas valve off.
- In case of prolonged absence of the user, the main gas delivery valve to the burner should be shut off.

Precautions if you can smell gas

- do not operate electric switches, the telephone, or any other item likely to generate sparks;
- immediately open doors and windows to create an air flow to purge b the room;
- close the gas valves; С
- contact qualified personnel. d
- Do not obstruct the ventilation openings of the room where gas appliances are installed, to avoid dangerous conditions such as the development of toxic or explosive mixtures.

DIRECTIVES AND STANDARDS

Gas burners

- European directives:
- Directive 2009/142/EC Gas Appliances;
- Directive 2006/95/EC on low voltage;
- Directive 2004/108/EC on electromagnetic compatibility

Harmonised standards :

-UNI EN 676 (Gas Burners;-EN 55014-1Electromagnetic compatibility -Requirements for household appliances, electric tools and similar apparatus.

-CEI EN 60335-1(Household and similar electrical appliances - Safety. Part 1: General requirements;

-EN 50165 (Electrical equipment of non-electric appliances for household and similar purposes. Safety requirements.

-EN 60335-2-102 (Household and similar electrical appliances. Safety. Particular requirements for gas, oil and solid-fuel burning appliances having electrical connections)

Light oil burners

European directives:

- Directive 2006/95/EC on low voltage;

- Directive 2004/108/EC on electromagnetic compatibility

Harmonised standards : -CEI EN 60335-1(Household and similar electrical appliances - Safety.

Part 1: General requirements; -UNI 267 Automatic forced draught burners for liquid fuels

-EN 55014-1Electromagnetic compatibility - Requirements for household appliances, electric tools and similar apparatus.

-EN 50165 (Electrical equipment of non-electric appliances for household and similar purposes. Safety requirements.

National standards :

-UNI 7824: Monobloc nebulizer burners for liquid fuels. Characteristics and test methods

Heavy oil burners

European directives:

- Directive 2006/95/EC on low voltage;

- Directive 2004/108/EC on electromagnetic compatibility

Harmonised standards :

-CEI EN 60335-1 Household and similar electrical appliances - SafetyPart 1: General requirements;

-EN 55014-1Electromagnetic compatibility - Requirements for household appliances, electric tools and similar apparatus.

- EN 50165 Electrical equipment of non-electric appliances for household and similar purposes. Safety requirements.

National standards :

-UNI 7824: Monobloc nebulizer burners for liquid fuels. Characteristics and test methods

Gas - Light oil burners

European directives:

- Directive 2009/142/EC - Gas Appliances;

- Directive 2006/95/EC on low voltage;

- Directive 2004/108/EC on electromagnetic compatibility

Harmonised standards :

-UNI EN 676 Gas Burners

-EN 55014-1Electromagnetic compatibility - Requirements for household appliances, electric tools and similar apparatus.

-UNI 267 Automatic forced draught burners for liquid fuels

-CEI EN 60335-1(Household and similar electrical appliances - Safety. Part 1: General requirements;

- EN 50165 Electrical equipment of non-electric appliances for household and similar purposes. Safety requirements.

National standards :

-UNI 7824: Monobloc nebulizer burners for liquid fuels. Characteristics and test methods

Gas - Heavy oil burners

European directives:

- Directive 2009/142/EC Gas Appliances;
- Directive 2006/95/EC on low voltage;
- Directive 2004/108/EC on electromagnetic compatibility

Harmonised standards :

-EN 55014-1Electromagnetic compatibility - Requirements for household appliances, electric tools and similar apparatus.

-UNI EN 676 (Gas Burners;

-CEI EN 60335-1(Household and similar electrical appliances - Safety. Part 1: General requirements;

- EN 50165 Electrical equipment of non-electric appliances for household and similar purposes. Safety requirements.

National standards :

-UNI 7824: Monobloc nebulizer burners for liquid fuels. Characteristics and test methods

Industrial burners

European directives:

- Directive 2009/142/EC - Gas Appliances;

- Directive 2006/95/EC on low voltage;

- Directive 2004/108/EC on electromagnetic compatibility

Harmonised standards :

-EN 55014-1Electromagnetic compatibility - Requirements for household appliances, electric tools and similar apparatus.

-EN 50165 Electrical equipment of non-electric appliances for household and similar purposes. Safety requirements.

-UNI EN 746-2: Industrial thermoprocessing equipment

Burner data plate

Model For the following information, please refer to Year the data plate: S.Number

- burner type and burner model: must be reported in any communication with the Fuel supplier
- burner ID (serial number): must be reported in any communication with the supplier

 date of production (year and month)
--	---

WARNING!

DANGER!

WARNING!

Protection information about fuel type and network • Drwaing n° pressure P.I.N.

SYMBOLS USED



Failure to observe the warning may result in irreparable damage to the unit or damage to the environment

Туре

Output

. Oil Flow

Category Gas Press

Viscosity EI.Supply EI.Consump.

Fan Motor




Failure to observe the warning may result in serious injuries or death.



Failure to observe the warning may result in electric shock with lethal consequences

MICROPROCESSOR CONTROLLED SYSTEM

The control system is made of the Siemens LMV central unit that performs all the burner control functions and of the Siemens AZL local programming unit that interfaces the system with the user.




Keys

- 1 Burner
- 2 AZL2..
- 3 Air actuator
- 4 Fuel actuator
- 5 LMV2..

User interface

The AZL2x.. display/programming unit is shown below:



The keys functions are the following:

Key F

Used to adjust the "fuel" actuator position (Fuel): :

While pressing the **F** key, the "fuel" actuator position can be changed by means of the **+** and **-** keys.

Key A

Used to adjust the "air" actuator position (Air): While pressing the A key, the "air" actuator position can be changed by means of the + and - keys.

Key F + A

While pressing the two keys contemporarly, the code message will appear: by entering the proper password it is possible to access the Service mode.

Info and Enter keys

Used for Info and Service menues Used as Enter key in the setting modes Used as Reset key in the burner operation mode Used to enter a lower level menu -Key -Used to decrease a a value Used to enter Info and Serivce during the curve adjustments +Key + Used to increase a a value

Used to enter Info and Serivce during the curve adjustments

Keys (+ & -)= ESC

By pressing + and - at the same time, the ESCAPE function is perfomed:

to enter a lower level menu

The display will show these data:

Lock+unlock codes

Flame

Open valves

Ignition transformers energised

Fan motor energised

Oil pre-heater energised

Plant heat request


Parametere setting mode

Info mode

Service mode

- Closing actuator
- Opening actuator

IUnit measure





nfo










Parameters level (heating engineer)



Setting menu

The seeting menu is divided into different blocks:

Bloc.	Descrizione	Description	Password
000		Internal parameters	OEM / Service
100	Informazioni generali	General	OEM / Service / Info
200	Controllo bruciatore	Burner control	OEM / Service
300	Controllo bruciatore (solo LMV26)	Burner control (LMV26 only)	OEM / Service
400	Curve rapporto	Ratio curves	OEM / Service
500	Controllo rapporto	Ratio control	OEM / Service
600	Servocomandi	Actuators	OEM / Service
700	Storico errori	Error history	OEM / Service / Info
900	Dati di processo	Process data	OEM / Service / Info

The access to the various blocks is allowed by passwords. Passwords are divided into three levels:

- User level (info): no password needed
- Service level (Service)
- Manifacturer level (OEM)

Block 000: Internal Parameter

Param.	Descrizione	Description	Password
041	Password livello assistenza (ingegnere del calore)	Password heating engineer (4 characters)	OEM
042	Password livello OEM (costruttore del brucia- tore)	Password OEM (5 characters)	OEM
050	Start backup/restore via AZL2x/PC	Start backup / restore via AZL2/ PC sof- tware (set parameter to 1) Index 0: Create backup Index 1: Execute restore Error dia- gnostics via negative values	SO
		(see error code 137)	
055	Identificazione bruciatore (backup dati)	Burner identification of AZL2 backup data set	SO
056		ASN extraction of AZL2 backup data set	SO
057	Versione software creata dal set dati backup	Software version when creating the AZL2 backup data set	Service / Info

Block 100: General information

Param.	Descrizione	Description	Password	LMV20 LMV27	LMV26	LMV37
102	Data produzione (in gg-mm-aa)	Identification date (yy-mm-dd)	Service / Info	х	х	х
103	Numero identificativ	Identification number	Service / Info	х	х	х
104	Set di parametri preimpostati: codice cliente	Preselected parameter set: customer code	Service / Info	х	х	х
105	Set di parametri preimpostati: versione	Preselected parameter set: version	Service / Info	х	х	х
107	Versione softwar	Software version	Service / Info	х	х	х
108	Variante software	Software variant	Service / Info	х	х	х
113	Identificativo bruciatore	Burner identification	Service / Info SO password for writing	x	x	x
121	Potenza manuale Valore "Undefined = automatico Impostare un valore inferiore a = in modo che il display mostri altrimenti, il controllore rimarrà sempre in stand-by e il display mostrerà la scritta OFF lampeggiante.	Manual output Undefined = automatic mode	Service / Info	x	x	x

125	Frequenza di rete 0 = 50 Hz	Mains frequency 0 = 50 Hz	Service / Info	x	x	x
	1 = 60 Hz	1 = 60 Hz				
126	Luminosità display	Display brightness	Service / Info	х	х	х
127	Tempo dopo il quale, se non viene premuto nessun tast il software esce dalla modalita programmazione (valore fabbrica = 60min - range impostazione: 10 - 120 min)	Timeout for menu operation (default value = 60min - range: 10 - 120 min)	OEM	x	x	x
130	Azzeramento Storico errori Impostare prima il parametro a 1 e poi a 2; se compare "0" = lo Storico è stato azzerato se compare "-1" = scaduto tempo sequ. 1_2	Delete display of error history To delete display : set to 1 then to 2; return value "0" = error history deleted return value "-1" = timeout of 1_2 sequence	OEM / Service	x	x	x
141	Attivazione comunicazione bus 0 = off 1 = Modbus 2 = riserva	Operating mode BACS 0 = off 1 = Modbus 2 = reserved	OEM / Service		x	x
142	Tempo d'arresto in caso di guasto di comuni- cazione	Setback time in the event of communication breakdown	OEM / Service		x	x
143	Riserva	Reserved	Service / Info		х	х
144	Riserva	Reserved	OEM / Service		х	х
145	Indirizzo dispositivo per Modbus	Device address for Modbus	OEM / Service		х	х
146	Velocità di trasmissione per Modbus	Baud rate for Modbus	OEM / Service		х	х
147	Parità per Modbus	Parity for Modbus	OEM / Service		х	х
148	on una interruzione della comunicazione bus: 0 19.9 = bruciatore spento 20 100 = 20 100% potenza Per il funzionamento multistadio: 0 = bruciatore OFF, P1, P2, P3 non valido = nessun standard di prestazione della LMV.	Performance standard at interruption of com- munication with building automation For modulation operation the setting range is as fol-lows: 019.9 = burner off 20100 = 20100% burner rating For multistage ope- ration apply to setting range: 0 = burner OFF, P1, P2, P3 Invalid = no performance stan- dards of the building auto-mation	OEM / Service		x	x
161	Numero di avarie	Number of faults	Service / Info	х	х	х
162	Ore di esercizio (azzerabile da Service)	Operating hours (resettable by Service)	Service / Info	х	х	х
163	Ore di esercizio (con dispositivo sotto ten- sione)	Operating hours (when unit is live)	Service / Info	х	x	x
164	Numero di partenze (azzerabile da Service)	Number of startups (resettable by Service)	Service / Info	х	х	х
165	Numero di partenze	Number of startups	Service / Info	х	х	х

166	Numero totale di partenze (non azzerabile)	Total number of startups	Service / Info	х	х	х
167	Volume combustibile (azzerabile da OEM)	Fuel volume (resettable by OEM)	Service / Info	х	х	х
172	Fuel 1(secondo combustibile)Ore di eserci- zio (azzerabile da Service)	Fuel 1: Operation hours resettable	Service / Info		х	
174	Fuel 1 (secondo combustibile) Numero di partenze (azzerabile da Service)	Fuel 1: Number of startups resettable	Service / Info		х	
175	Fuel 1 (secondo combustibile) Numero di partenze	Fuel 1: Number of startups	Service / Info		х	
177	Fuel 1 (secondo combustibile) Volume com- bustibile (azzerabile da OEM)	Fuel 1: Fuel volume resettable (m³, l, ft³, gal)	Service / Info		x	

Block 200: Burner control

Param.	Descrizione	Description	Password	LMV20 LMV27	LMV26	LMV37
201	 comandi, ecc.) = non definito (cancellazione curve) 1 = accensione diretta a gas (G mod) 2 = accensione tramite pilota gas con attacco tra le due elettrovalvole EV1/EV2 del gas (Gp1 mod) 	 Burner operating mode (fuel train, modulating / multistage, actuators, etc) = undefined (delete curves) 1 = gas direct ignition (G mod) 2 = ignition by gas pilot connected between the two gas solenoid valves EV1/EV2 (Gp1 mod) 3 = ignition by gas pilot connected upstream the gas EV1 (Gp2 mod) 4 = light oil ignition - modulating (Lo mod) 5 = light oil ignition - double stage (Lo 2 stage) 6 = light oil ignition - three stage (Lo 3 stage) 7 = gas direct ignition - pneumatic regulation (G mod pneu) 8 = ignition by gas pilot connected between the two gas solenoid valves EV1/EV2 - pneumatic regulation (Gp1 mod pneu) 9 = ignition by gas pilot connected upstream the gas EV1 - pneumatic regulation (Gp2 mod pneu) 	OEM / Service	x	x	x
	 10 = olio modulante con accensione tramite pilota (LOGp mod) 11 = olio 2 stadi con accensione tramite pilota (LOGp 2-stage) 12 = olio modulante con 2 valvole combustibile (LOmod 2 valvole) 13 = olio modulante con 2 valvole combustibile e con accensione tramite pilota (LOGp 2 valvole) 14 = gas modulante pneumatico senza servomotori (Gmod pneu) 	11 = LoGp 2-stage 12 = Lo mod 2 fuel valves 13 = LoGp mod 2 fuel valves				

	 15 = gas rampa Gp1 modulante pneumatico senza servomotori (Gp1 mod pneu) 16 = gas rampa Gp2 modulante pneumatico senza servomotori (Gp2 mod pneu) 17 = olio LO 2 stadi senza servomotori 18 = olio LO 3 stadi senza servomotori 19 = gas Gmod con solo servomotore gas 20 = gas Gp1 mod con solo servomotore gas 21 = gas Gp2 mod con solo servomotore gas 22 = olio LO mod con solo servomotore olio 	 15 = Gp1 mod pneu without actuator 16 = Gp2 mod pneu without actuator 17 = Lo 2-stage without actuator 18 = Lo 3-stage without actuator 19 = G mod gas actuator only 20 = Gp1 mod gas actuator only 21 = Gp2 mod gas actuator only 22 = Lo mod oil actuator only 				
208	Stop programma 0 = non attivo 1 = posizione preventilazione (Ph24 - fase 24 del programma) 2 = posizione accensione (Ph36 - fase 36 del programma) 3 = intervallo di tempo 1 (Ph44 - fase 44 del programma) 4 = intervallo di tempo 2 (Ph52 - fase 52 del programma)	24)	OEM / Service	x	x	x
210	Allarme impedimento avviamento 0 = non attivo 1 = attivo	Alarm in the event of start prevention 0 = deactivated 1 = activated	OEM / Service	x	x	x
211	Tempo aumento giri ventilatore (valore fab- brica = 2s - range impostazione: 2 - 60 s)	Fan ramp up time (default value = 2s - range: 2 - 60 s)	OEM / Service	x	x	x
212	Tempo massimo raggiungimento bassa fiamma (valore fabbrica = 45 s - range impo- stazione: 0.2 s - 10 min) Stabilisce il massimo intervallo di tempo durante il quale il bruciatore raggiunge la minima potenza e poi si spegne	Maximum time down to low-fire (default value = 45 s - range: 0.2 s - 10 min) It states the maximum time interval during which the burner drives to the low output and then turns off	OEM / Service		x	
213	Tempo minimo raggiungimento posizione di stand by (valore fabbrica = 2 s - range impo- stazione: 2 - 60 s)	Min. time home run (default value = 2 s - range: 2 - 60 s)	OEM	x	x	x
214	Tempo massimo inizio partenza	Max. time start release	OEM	х	х	х
215	Limite ripetizioni catena di sicurezza (valore fabbrica = 16 - range impostazione:1 - 16)	Repetition limit safety loop (default value = 16 - range: 1 - 16)	OEM / Service	х	х	x
217	Tempo massimo per rilevazione segnale (valore fabbrica = 30s - range impostazione: 5s - 10 min)	Max. time to detector signal (default value = 30s - range: 5s - 10 min)	OEM	х	x	x

221	Gas: sonda rilevazione fiamma attivo (valore fabbrica = 1)	Gas: active detector flame evaluation (default value = 1) 0 = QRB/QRC 1 = ION / QRA	OEM / Service	x	x	x
222	EN676 rende obbligatoria la preventilazione. In ambito industriale, vedere i casi in cui la norma EN746-2 prevede la possibilità di non fare la preventilazione. In questi ultimi casi il bruciatore deve essere costruito obbligatoriamente con controllo di tenuta e valvole gas in classe A	can be avoided according to the stands EN746-2 If the prepurge is not performed, the burner must be equipped with two valves and the proving system.	OEM / Service	x	x	x
223	Limite ripetizioni pressostato gas di minima pressione (valore fabbrica = 16 - range impo- stazione:1 - 16)	Repetition limit pressure switch-min-gas (default value = 16 - range:1 - 16)	OEM / Service	x	x	x
225	Gas: tempo di preventilazione (valore fab- brica = 20s - range impostazione:20s - 60min)	Gas: Prepurge time (default value = 20s - range:20s - 60min)	OEM / Service	х	х	х
226	Gas: tempo di preaccensione (valore fab- brica = 2s - range impostazione:0.2s - 60min)	Gas: Preignition time (default value = 2s - range: 0.2s - 60min)	OEM / Service	x	х	х
227	Gas: tempo di sicurezza 1 (TSA1) (valore fabbrica = 3s - range impostazione:0.2 - 10s)	Gas: Safety time 1 (TSA1) (default value = 3s - range: 0.2 - 10s)	OEM	x	х	х
229	Gas: tempo di risposta a cadute di pressione entro TSA1 e TSA2 (valore fabbrica = 1.8s - range impostazione:0.2s - 9.8s)	Gas: time to respond to pressure faults in TSA1 e TSA2 (default value = 1.8s - range: 0.2s - 9.8s)	OEM	x	x	x
230	Gas: Intervallo 1 (valore fabbrica = 2s - range impostazione:0.2s - 60min)	Gas: Interval 1 (default value = 2s - range: 0.2s - 60min)	OEM / Service	х	х	х
231	Gas: tempo di sicurezza 2 (TSA2) (valore fabbrica = 3s - range impostazione:0.2 - 10s)	Gas: Safety time 2 (TSA2) (default value = 3s - range:0.2 - 10s)	OEM	х	х	х
232	Gas: Intervallo 2 (valore fabbrica = 2s - range impostazione:0.2s - 60min)	Gas: Interval 2 (default value = 2s - range:0.2s - 60min)	OEM / Service	х	х	
233	Gas: Tempo postcombustione (valore fab- brica = 8s - range impostazione:0.2s - 60s)	Gas: postcombustion time (default value = 8s - range:0.2s - 60s)	OEM / Service	x	х	x
234	Gas: Tempo postventilazione (valore fab- brica = 0.2s - range impostazione:0.2s - 180min)	Gas: Postpurge time (default value = 0.2s - range:0.2s - 180min)	OEM / Service	x	х	х

236	vola V1)	Gas: Pressure switch-min input 0 = inactive 1 = pressure switch-min (upstream of fuel valve 1 (V1)) 2 = valve proving via pressure switch-min (between fuel valves 1 (V1) and 2 (V2))	OEM / Service	x	x	
237	Gas: Pressostato gas di massima / ingresso- POC 0 = inattivo 1= pressostato gas di massima 2= POC 3 = pressostato controllo perdite	Gas: Pressure switch-max / POC input 0 = inactive 1 = pressure switch-max 2 = POC 3 = pressure switch valve proving			x	x
239	Gas: Forzatura al funzionamento intermit- tente 0 = disattivato 1 = attivato Attenzione : di default questo parametro è attivo = (1); esso è modificabile solo su LMV37. Dal punto di vista della sicurezza, il funzionamento continuo è valido esclusiva- mente per bruciatori di gas con elettrodo di rilevazione.		OEM			x
240	Limite ripetizioni perdita di fiamma (valore fabbrica = 2 - range impostazione:1 - 2)	Repetition limit loss of flame (default value= 2 - range:1 - 2)	OEM	x	x	x
241	Gas: esecuzione controllo tenuta (valore fabbrica = 2) 0 = no controllo tenuta 1 = controllo tenuta in avviamento 2 = controllo tenuta in arresto 3 = controllo tenuta in arresto e in avviamento	 Gas: execution proving test (default value= 2) 0 = no proving test 1 = proving test on startup 2 = proving test on shutdown 3 = proving test on shutdown and on startup 	OEM / Service	x	x	x
242	Gas: tempo evacuazione controllo tenuta (valore fabbrica = 3s - range imposta- zione:0.2s - 10s)	Gas: proving test evacuation time (default value = 3s - range:0.2s - 10s)	OEM	x	x	х

243	Gas: tempo pressione atmosferica controllo tenuta (valore fabbrica = 10s - range impo- stazione:0.2s - 60s)	Gas: proving test time atmospheric pres- sure (default value = 10s - range:0.2s - 60s)	OEM	x	x	x
244	Gas: tempo riempimento controllo tenuta (valore fabbrica = 3s - range imposta- zione:0.2s - 10s)	Gas: proving test filling time (default value = 3s - range:0.2s - 10s)	OEM	x	x	x
245	Gas: tempo test pressione gas (valore fab- brica = 10s - range impostazione:0.2s - 60s)	Gas: proving test time gas pressure (default value = 10s - range:0.2s - 60s)	OEM	х	х	x
246	Gas: tempo attesa consenso pressostato di minima (valore fabbrica = 10s - range impo- stazione:0.2s - 60s) Se la pressione del gas è troppo bassa, in fase 22 non verrà eseguito l'avviamento: il sistema compie un numero impostabile di tentativi finché non si arriva al blocco. Il tempo di attesa tra un tentativo e il succes- sivo viene raddoppiato ad ogni tentativo.	Gas: waiting time gas shortage (default value = 10s - range:0.2s - 60s) If the gas pressure is too low, in phase 22 the startup will not be performed: the system tries for a certain number of times the it locks out. The time interval between two attempts is doubled at each attempt.	OEM	x	x	x
248	Gas: Tempo di post-ventilazione 3 (abortito con regolatore di potenza (LR)-ON	Gas: Postpurge time 3 (abortion with load controller (LR)-ON	OEM / Service	x	x	x
261	Olio: sonda rilevazione fiamma attivo (valore fabbrica = 0) 0 = QRB/QRC 1 = ION / QRA	Oil: active detector flame evaluation (default value = 0) 0 = QRB/QRC 1 = ION / QRA	OEM / Service	x	x	x
262	Olio: preventilazione (valore fabbrica = 1) 1 = attivo 0 = non attivo In ambito civile la norma EN267 rende obbli- gatoria la preventilazione. In ambito indu- striale, vedere i casi in cui la norma EN746-2 prevede la possibilità di non fare la preventila- zione.	Oil: prepurging (default value = 1) 0 = deactivated 1 = activated 0 = deactivated WARNING: in the civil field, the prepurge is mandatory according to the standard EN267. In the industrial fiels, check if the pre purge can be avoided according to the standard EN746-2	OEM / Service	x	x	x
265	Olio: tempo preventilazione (valore fabbrica = 15s - range impostazione:15s - 60min)	Oil: prepurging time (default value = 15s - range:15s - 60min)	OEM / Service	х	x	x
266	Olio: tempo preaccensione (valore fabbrica = 2s - range impostazione:0.2s - 60min)	Oil: preignition time (default value = 2s - range:0.2s - 60min)	OEM / Service	x	х	x
267	Olio: tempo di sicurezza 1 (TSA1) (valore fabbrica = 5s - range impostazione:0.2 - 15s)	Oil: safety time 1 (TSA1) (default value = 5s - range:0.2 - 15s)	OEM	х	х	x
269	Olio: tempo di risposta a cadute di pressione entro TSA1 e TSA2 (valore fabbrica = 1.8s - range impostazione:0.2s - 14.8s)	Oil: time to respond to pressure faults in TSA1 and TSA2 (default value = 1.8s - range:0.2s - 14.8s)	OEM	x	x	x

270	Olio: Intervallo 1 (valore fabbrica = 2s - range impostazione:0.2s - 60min)	Oil: Interval 1 (default value = 2s - range:0.2s - 60min)	OEM / Service	х	х	х
271	Olio: tempo di sicurezza 2 (TSA2) (valore fabbrica = 3s - range impostazione:0.2 - 10s)	Oil: safety time 2 (TSA2) (default value = 3s - range:0.2 - 10s)	OEM	х	х	x
272	Olio: Intervallo 2 (valore fabbrica = 2s - range impostazione:0.2s - 60min)	Oil: Interval 2 (default value = 2s - range:0.2s - 60min)	OEM / Service	х	x	x
273	Olio: Tempo postcombustione (valore fab- brica = 8s - range impostazione:0.2s - 60s)	Oil: Postcombustion time (default value = 8s - range:0.2s - 60s)	OEM / Service	x	x	x
274	Olio: Tempo postventilazione (valore fab- brica = 0.2s - range impostazione:0.2s - 180min)Oil: Postpurging time (default value = 0.2s range:0.2s - 180min)		OEM / Service	x	x	x
276	Olio : Pressostato olio di minima (default = 1) 0 = inattivo 1 = attivo dalla fase 38 2 = attivo dal tempo di sicurezza (TSA)	Oil. Pressure switch-min input 0 = inactive 1 = active from phase 38 2 = active from safety time (TSA)	OEM / Service	x	x	
277	Olio: Pressostato olio di massima / ingresso- POC 0 = inattivo 1= pressostato olio di massima 2= POC	Oil: Pressure switch-max/POC input 0 = inactive 1 = pressure switch-max 2 = POC			х	
279	Olio: Forzatura al funzionamento intermittente 0 = disattivato 1 = attivato Attenzione : di default questo parametro è attivo = (1); esso è modificabile solo su LMV37	vated 1 = activated	OEM		x	x
280	Limite ripetizioni perdita di fiamma (valore fabbrica = 2 - range impostazione:1 - 2)	Repetition limit value loss of flame (default value = 2 - range:1 - 2)	OEM	x	x	x
281	Olio: tempo iniezione olio (valore fabbr. = 1) 0 = preaccensione corta (Ph38 - fase pro- gramma 38) 1 = preaccensione lunga (con ventilatore) (Ph22 - fase programma 22)	Oil: time oil ignition (default value = 1) 0 = short preignition (Ph38-progr. phase 38) 1 = long preignition (with fan) (Ph22 - program phase 22)	OEM / Service	x	x	x
284	Olio: Tempo di post-ventilazione 3 (abortito con regolatore di potenza (LR)-ON	Oil: Postpurge time 3 (abortion with load con- troller (LR)-ON	OEM / Service	х	x	x

Block 300: Burner control (only with LMV26)

Param.	Descrizione	Description	Password	LMV20 LMV27	LMV26	LMV37
	Combustibile 1 : Modalità funzionamento bru- ciatore (rampa combustibile, modulante / multistadio, servocomandi, ecc.)	Fuel 1 : Burner operating mode (fuel train, modulating / multistage, actuators, etc)				
	= non definito (cancellazione curve)	= undefined (delete curves)				
	1 = accensione diretta a gas (G mod)	1 = gas direct ignition (G mod)				
	2 = accensione tramite pilota gas con attacco tra le due elettrovalvole EV1/EV2 del gas (Gp1 mod)	2 = ignition by gas pilot connected between the two gas solenoid valves EV1/EV2 (Gp1 mod)				
		3 = ignition by gas pilot connected upstream the gas EV1 (Gp2 mod)				
	4 = accensione a gasolio - modulante (Lo mod)	4 = light oil ignition - modulating (Lo mod)) OEM / Service			
301	5 = accensione a gasolio - bistadio (Lo 2 stage)	5 = light oil ignition - double stage (Lo 2 stage)			х	
	6 = accensione a gasolio - tristadio (Lo 3 stage)	6 = light oil ignition - three stage (Lo 3 stage)				
	7 = accensione diretta a gas - regolazione pneumatica (G mod pneu)	(G mod pneu)				
	8 = accensione tramite pilota gas con attacco tra le due elettrovalvole EV1/EV2 del gas - regolazione pneumatica (Gp1 mod pneu)	 8 = ignition by gas pilot connected between the two gas solenoid valves EV1/EV2 - pneu- matic regulation (Gp1 mod pneu) 				
	9 = accensione tramite pilota gas con attacco a monte dell'elettrovalvola EV1 del gas regolazione pneumatica (Gp2 mod pneu)	9 = ignition by gas pilot connected upstream the gas EV1 - pneumatic regulation (Gp2 mod pneu)				
	10 = olio modulante con accensione tramite pilota (LOGp mod)	1 0 = LoGp mod				

	 11 = olio 2 stadi con accensione tramite pilota (LOGp 2-stage) 12 = olio modulante con 2 valvole combusti- bile (LOmod 2 valvole) 13 = olio modulante con 2 valvole combusti- bile e con accensione tramite pilota (LOGp 2 valvole) 14 = gas modulante pneumatico senza servo- 	 12 = Lo mod 2 fuel valves 13 = LoGp mod 2 fuel valves 14 = G mod pneu without actuator 			
	motori (Gmod pneu) 15 = gas rampa Gp1 modulante pneumatico senza servomotori (Gp1 mod pneu) 16 = gas rampa Gp2 modulante pneumatico senza servomotori (Gp2 mod pneu)				
	21 = gas Gp2 mod con solo servomotore gas22 = olio LO mod con solo servomotore olio	 17 = Lo 2-stage without actuator 18 = Lo 3-stage without actuator 19 = G mod gas actuator only 20 = Gp1 mod gas actuator only 21 = Gp2 mod gas actuator only 22 = Lo mod oil actuator only 		x	
321	Combustibile 1 - Gas: sonda rilevazione fiamma attivo (valore fabbrica = 1) - 0 = QRB/QRC 1 = ION / QRA	Fuel 1 - Gas: active detector flame evalua- tion (default value = 1) 0 = QRB/QRC 1 = ION / QRA	OEM / Service	x	
322	Combustibile 1 - Gas: Preventilazione (valore fabbrica = 1) 1 = attivo 0 = non attivo ATTENZIONE : In ambito civile la norma EN676 rende obbligatoria la preventilazione. In ambito industriale, vedere i casi in cui la norma EN746-2 prevede la possibilità di non fare la preventilazione. In questi ultimi casi il bruciatore deve essere costruito obbligatoriamente con controllo di tenuta e valvole gas in classe A.	Fuel 1 - Gas: Pre-purging (default value = 1) 1 = active 0 = deactivated WARNING: in the civil field, the prepurge is mandatory according to the standard EN676. In the industrial fiels, check if the pre purge can be avoided according to the stanrds EN746-2 If the prepurge is not performed, the burner must be equipped with two valves and the proving system.	OEM / Service	x	
323	Limite ripetizioni pressostato gas di minima pressione (valore fabbrica = 16 - range impo- stazione:1 - 16)	Repetition limit pressure switch-min-gas (default value = 16 - range:1 - 16)	OEM / Service	x	
325	Combustibile 1 - Gas: tempo di preventila- zione (valore fabbrica = 20s - range imposta- zione:20s - 60min)	Fuel 1 - Gas: Prepurge time (default value = 20s - range:20s - 60min)	OEM / Service	x	

326	Combustibile 1 - Gas: tempo di preaccen- sione (valore fabbrica = 2s - range imposta- zione:0.2s - 60min)	Fuel 1 - Gas: Preignition time (default value = 2s - range: 0.2s - 60min)	OEM / Service	x
327	Combustibile 1 - Gas: tempo di sicurezza 1 (TSA1) (valore fabbrica = 3s - range impo- stazione:0.2 - 10s)	Fuel 1 - Gas: Safety time 1 (TSA1) (default value = 3s - range: 0.2 - 10s)	OEM	x
329	Combustibile 1 - Gas: tempo di risposta a cadute di pressione entro TSA1 e TSA2 (valore fabbrica = 1.8s - range imposta- zione:0.2s - 9.8s)	Fuel 1 - Gas: time to respond to pressure faults in TSA1 e TSA2 (default value = 1.8s - range: 0.2s - 9.8s)	OEM	x
330	Combustibile 1 - Gas: Intervallo 1 (valore fabbrica = 2s - range impostazione:0.2s - 60min)	Fuel 1 - Gas: Interval 1 (default value = 2s - range: 0.2s - 60min)	OEM / Service	x
331	Combustibile 1 - Gas: tempo di sicurezza 2 (TSA2) (valore fabbrica = 3s - range imposta- zione:0.2 - 10s)	Fuel 1 - Gas: Safety time 2 (TSA2) (default value = 3s - range:0.2 - 10s)	OEM	x
332	Combustibile 1 - Gas: Intervallo 2 (valore fabbrica = 2s - range impostazione:0.2s - 60min)	Fuel 1 - Gas: Interval 2 (default value = 2s - range:0.2s - 60min)	OEM / Service	x
333	Combustibile 1 - Gas: Tempo postcombu- stione (valore fabbrica = 8s - range imposta- zione:0.2s - 60s)	Fuel 1 - Gas: postcombustion time (default value = 8s - range:0.2s - 60s)	OEM / Service	x
334	Combustibile 1 - Gas: Tempo postventila- zione (valore fabbrica = 0.2s - range impo- stazione:0.2s - 180min)	Fuel 1 - Gas: Postpurge time (default value = 0.2s - range:0.2s - 180min)	OEM / Service	x
336	Combustibile 1 - Gas: Pressostato gas di minima (default = 1) 0 = inattivo 1 = pressostato gas di minima (a monte val- vola V1) 2 = controllo perditavalvole via pressostato (montato tra le valvole V1 e V2)	2 = valve proving via pressure switch-min	OEM / Service	x
337	Combustibile 1 - Gas: Pressostato gas di massima / ingressoPOC 0 = inattivo 1= pressostato gas di massima 2= POC 3 = pressostato controllo perdite	Fuel 1 - Gas: Pressure switch-max / POC input 0 = inactive 1 = pressure switch-max 2 = POC 3 = pressure switch valve proving		x

	340	Limite ripetizioni perdita di fiamma (valore fabbrica = 2 - range impostazione:1 - 2)	Repetition limit loss of flame (default value= 2 - range:1 - 2)	OEM	x	
	341	Combustibile 1 - Gas: esecuzione controllo tenuta (valore fabbrica = 2) 0 = no controllo tenuta 1 = controllo tenuta in avviamento 2 = controllo tenuta in arresto 3 = controllo tenuta in arresto e in avviamento	 Fuel 1 - Gas: execution proving test (default value= 2) 0 = no proving test 1 = proving test on startup 2 = proving test on shutdown 3 = proving test on shutdown and on startup 	OEM / Service	x	
	342	Combustibile 1 - Gas: tempo evacuazione controllo tenuta (valore fabbrica = 3s - range impostazione:0.2s - 10s)	Fuel 1 - Gas: proving test evacuation time (default value = 3s - range:0.2s - 10s)	OEM	x	
	343	Combustibile 1 - Gas: tempo pressione atmo- sferica controllo tenuta (valore fabbrica = 10s - range impostazione:0.2s - 60s)	Fuel 1 - Gas: proving test time atmospheric pressure (default value = 10s - range:0.2s - 60s)	OEM	x	
	344	Combustibile 1 - Gas: tempo riempimento controllo tenuta (valore fabbrica = 3s - range impostazione:0.2s - 10s)	Fuel 1 - Gas: proving test filling time (default value = 3s - range:0.2s - 10s)	OEM	x	
N	345	Combustibile 1 - Gas: tempo test pressione gas (valore fabbrica = 10s - range imposta- zione:0.2s - 60s)	Fuel 1 - Gas: proving test time gas pres- sure (default value = 10s - range:0.2s - 60s)	OEM	x	
22	346	Combustibile 1 - Gas: tempo attesa consenso pressostato di minima (valore fabbrica = 10s - range impostazione:0.2s - 60s) Se la pressione del gas è troppo bassa, in fase 22 non verrà eseguito l'avviamento: il sistema compie un numero impostabile di tentativi finché non si arriva al blocco. Il tempo di attesa tra un tentativo e il succes- sivo viene raddoppiato ad ogni tentativo.	Fuel 1 - Gas: waiting time gas shortage (default value = 10s - range:0.2s - 60s) If the gas pressure is too low, in phase 22 the startup will not be performed: the system tries for a certain number of times the it locks out. The time interval between two attempts is doubled at each attempt.	OEM	x	
	348	Combustibile 1 - Gas: Tempo di post-ventila- zione 3 (abortito con regolatore di potenza (LR)-ON	Fuel 1 - Gas: Postpurge time 3 (abortion with load controller (LR)-ON	OEM / Service	x	
	361	Combustibile 1 - Olio: sonda rilevazione fiamma attivo (valore fabbrica = 0) 0 = QRB/QRC 1 = ION / QRA	Fuel 1 - Oil: active detector flame evaluation (default value = 0) 0 = QRB/QRC 1 = ION / QRA	OEM / Service	x	

	362	Combustibile 1 - Olio: preventilazione (valore fabbrica = 1) 1 = attivo 0 = non attivo In ambito civile la norma EN267 rende obbli- gatoria la preventilazione. In ambito indu- striale, vedere i casi in cui la norma EN746-2 prevede la possibilità di non fare la preventila- zione.	Fuel 1 - Oil: prepurging (default value = 1) 0 = deactivated 1 = activated 0 = deactivated WARNING: in the civil field, the prepurge is mandatory according to the standard EN267. In the industrial fiels, check if the pre purge can be avoided according to the standard EN746-2	OEM / Service	x	
	365	Combustibile 1 - Olio: tempo preventilazione (valore fabbrica = 15s - range imposta- zione:15s - 60min)	Fuel 1 - Oil: prepurging time (default value = 15s - range:15s - 60min)	OEM / Service	x	
	366	Combustibile 1 - Olio: tempo preaccensione (valore fabbrica = 2s - range imposta- zione:0.2s - 60min)	Fuel 1 - Oil: preignition time (default value = 2s - range:0.2s - 60min)	OEM / Service	x	
	367	Combustibile 1 - Olio: tempo di sicurezza 1 (TSA1) (valore fabbrica = 5s - range impo- stazione:0.2 - 15s)	Fuel 1 - Oil: safety time 1 (TSA1) (default value = 5s - range:0.2 - 15s)	OEM	x	
23	369	Combustibile 1 - Olio: tempo di risposta a cadute di pressione entro TSA1 e TSA2 (valore fabbrica = 1.8s - range imposta- zione:0.2s - 14.8s)	Fuel 1 - Oil: time to respond to pressure faults in TSA1 and TSA2 (default value = 1.8s - range:0.2s - 14.8s)	OEM	x	
	370	Combustibile 1 - Olio: Intervallo 1 (valore fabbrica = 2s - range impostazione:0.2s - 60min)	Fuel 1 - Oil: Interval 1 (default value = 2s - range:0.2s - 60min)	OEM / Service	x	
	371	Combustibile 1 - Olio: tempo di sicurezza 2 (TSA2) (valore fabbrica = 3s - range imposta- zione:0.2 - 10s)	Fuel 1 - Oil: safety time 2 (TSA2) (default value = 3s - range:0.2 - 10s)	OEM	x	
	372	Combustibile 1 - Olio: Intervallo 2 (valore fabbrica = 2s - range impostazione:0.2s - 60min)	Fuel 1 - Oil: Interval 2 (default value = 2s - range:0.2s - 60min)	OEM / Service	x	
	373	Combustibile 1 - Olio: Tempo postcombu- stione (valore fabbrica = 8s - range imposta- zione:0.2s - 60s)	Fuel 1 - Oil: Postcombustion time (default value = 8s - range:0.2s - 60s)	OEM / Service	x	
	374	Combustibile 1 - Olio: Tempo postventila- zione (valore fabbrica = 0.2s - range impo- stazione:0.2s - 180min)	Fuel 1 - Oil: Postpurging time (default value = 0.2s - range:0.2s - 180min)	OEM / Service	x	
	377	Combustibile 1 - Olio: Pressostato olio di massima / ingressoPOC 0 = inattivo 1= pressostato olio di massima 2= POC	Fuel 1 - Oil: Pressure switch-max/POC input 0 = inactive 1 = pressure switch-max 2 = POC		×	

380	Limite ripetizioni perdita di fiamma (valore fabbrica = 2 - range impostazione:1 - 2)	Repetition limit value loss of flame (default value = 2 - range:1 - 2)	OEM	x	
	Combustibile 1 - Olio: tempo iniezione olio (valore fabbr. = 1)	Fuel 1 - Oil: time oil ignition (default value = 1)			
381	0 = preaccensione corta (Ph38 - fase pro- gramma 38)	0 = short preignition (Ph38-progr. phase 38)	OEM / Service	x	
	1 = preaccensione lunga (con ventilatore)(Ph22 - fase programma 22)	1 = long preignition (with fan) (Ph22 - program phase 22)			
384	Combustibile 1 - Olio: Tempo di post-ventila- zione 3 (abortito con regolatore di potenza (LR)-ON	Fuel 1 - Oil: Postpurge time 3 (abortion with load controller (LR)-ON	OEM / Service	x	

Block 400: Setting air/fuel ratio curves

Param.	Descrizione	Description	Password	LMV20 LMV27	LMV26	LMV37
401	Curve controllo servocomando combustibile (F): si accede alla lista dei punti da impostare (da P0 a P9) - consultare paragrafo "Imposta- zione curve"	Ratio control curve fuel actuator (F): it accesses to the parameter list of the points to be set (P0 to P9) - see paragrapf "Setting the curves"	OEM / Service	x	x	x
402	Curve controllo servocomando aria (A): si accede alla lista dei punti da impostare (da P0 a P9) - consultare paragrafo "Impostazione curve"	Ratio control curve air actuator (A): it accesses to the parameter list of the points to be set (P0 to P9) - see paragraph "Setting the curves"	OEM / Service	x	x	x
403	Curve controllo inverter (F + A): si accede alla lista dei punti da impostare (da P0 a P9) - con- sultare paragrafo "Impostazione curve"	Ratio control curves VSD (curve setting only)	SO		x	x
404	Combustibile 1 - Curve controllo servoco- mando combustibile 1 (F): si accede alla lista dei punti da impostare (da P0 a P9) - consul- tare paragrafo "Impostazione curve"	Fuel 1: Ratio control curves fuel actuator (curve setting only)	SO		x	
405	Combustibile 1 - Curve controllo servoco- mando aria (A): si accede alla lista dei punti da impostare (da P0 a P9) - consultare para- grafo "Impostazione curve"	Fuel 1: Ratio control curves air actuator (curve setting only)	SO		x	
406	Combustibile 1 - Curve controllo inverter (F + A): si accede alla lista dei punti da impostare (da P0 a P9) - consultare paragrafo "Imposta- zione curve"	Fuel 1: Ratio control curves VSD (curve set- ting only)	SO		x	

Block 500: Air/fuel ratio control

26

Param.	Descrizione	Description	Password	LMV20 LMV27	LMV26	LMV37
501	Posizione servocomando combustibile in assenza di fiamma (no-flame) Indice 0 = posizione di sosta = 0° Indice 1 = posizione preventilazione = 0° Indice 2 = posizione postventilazione = 15°	No-flame position fuel actuator Index 0 = no-load position = 0° Index 1 = prepurge position = 0° Index 2 = postpurge position = 15°	OEM / Service	x	x	x
502	Posizione servocomando aria in assenza di fiamma (no-flame) Indice 0 = posizione di sosta = 0° Indice 1 = posizione preventilazione = 90° Indice 2 = posizione postventilazione = 45°	No-flame position air actuator Index 0 = no-load position = 0° Index 1 = prepurge position = 90° Index 2 = postpurge position = 45°	OEM / Service	x	x	x
503	 % giri motore con inverter 0% = ventilatore fermo, 100% = ventilatore al massimo della velocità Indice 0 = posizione di sosta = 0% Indice 1 = posizione preventilazione = 100% Indice 2 = posizione postventilazione = 50% 	No-flame speeds VSD Index 0 = no-load speed = 0% Index 1 = prepurge speed = 100% Index 2 = postpurge speed = 50%	OEM / Service		x	x
504	Combustibile 1 - Posizione servocomando combustibile in assenza di fiamma (no- flame) Indice 0 = posizione di sosta = 0° Indice 1 = posizione preventilazione = 0° Indice 2 = posizione postventilazione = 15°	Fuel 1 No-flame position fuel actuator Index 0 = no-load position = 0° Index 1 = prepurge position = 0° Index 2 = postpurge position = 15°	OEM / Service		x	
505	Combustibile 1 - Posizione servocomando aria in assenza di fiamma (no-flame) Indice 0 = posizione di sosta = 0° Indice 1 = posizione preventilazione = 90° Indice 2 = posizione postventilazione = 45°	Fuel 1 No-flame position air actuator Index 0 = no-load position = 0° Index 1 = prepurge position = 90° Index 2 = postpurge position = 45°	OEM / Service		х	
506	Combustibile 1 - % giri motore con inverter 0% = ventilatore fermo, 100% = ventilatore al massimo della velocità Indice 0 = posizione di sosta = 0% Indice 1 = posizione preventilazione = 100% Indice 2 = posizione postventilazione = 50%	Fuel 1 No-flame speeds VSD Index 0 = no-load speed = 0% Index 1 = prepurge speed = 100% Index 2 = postpurge speed = 50%	OEM / Service		x	
522	Tempo rampa di salita inverter	Ramp up	OEM / Service		х	х
523	Tempo rampa di discesa inverter	Ramp down	OEM / Service		х	х

542	Activation of V Width Modulat 0=deactived 1	,	PWM = Pulse-	Activation of V (PWM = Pulse	SD / PWM fan -Width Modulatio	on)	OEM / Service		x	x
				Param	eter 544					I
544			Modulation 32s	Modulation 48s	Modulation 64s	Modulation 80s				
	Actuator	Actuating speed param- eter 613	N	Max. delta between the curve points		OEM / Service	x	x	x	
	Actuator	5s / 90°	31°	46°	62°	77°				
	(<= 5Nm) Actuator SQM33.7	17s / 90°	9° (1)	13°	18°	22°				
1) in thi			(-)							
		position of 90° ca	n't be reached	1	it (default value	- n d				
1) in this 545	Percentuale m	ninima di carico pe ca = n.d range i	in't be reached	1	it (default value 0%)	= n.d	OEM / Service	x	x	x
	Percentuale m (valore fabbric zione:20%-100 Percentuale m	ninima di carico pe ca = n.d range i 0%) nassima di carico fabbrica = n.d ra	er modulazione mposta- per modula-	Lower load lim range:20%-100	0%) nite (default valu		OEM / Service OEM / Service	x	x	×
545	Percentuale m (valore fabbric zione:20%-100 Percentuale m zione (valore f zione:20%-100 Combustibile per modulazio	ninima di carico pe ca = n.d range i 0%) nassima di carico fabbrica = n.d ra	per modulazione per modula- ange imposta- inima di carico ca = n.d	Lower load lim range:20%-100 Higher load lim range:20%-100 Fuel 1	0%) nite (default valu 0%) imit (default v	e = n.d	OEM / Service			

Block 600: Actuators

Param.	Descrizione	Description	Password	LMV20 LMV27	LMV26	LMV37
	Impostazione punto di riferimento Indice 0 = combustibile	Selection of reference point Index 0 = fuel				
601	Indice 1 = aria 0 = chiuso (<0°) 1 = aperto (>90°)	Index 1 = air 0 = closed (<0°) 1 = open (>90°)	OEM	x	х	х
602	Direzione rotazione del servocomando Indice 0 = combustibile Indice 1 = aria 0 = antiorario 1 = orario VEDI MESSAGGIO DI "ATTENZIONE" RIPORTATO SOTTO.	Actuator's direction of rotation Index 0 = fuel Index 1 = air 0 = counterclockwise 1 = clockwise SEE "WARNING" MESSAGE QUOTED BELOW.	OEM	x	x	x
606	Limite tolleranza per monitoraggio posizione (0.1°) Indice 0 = combustibile Indice 1 = aria	Tolerance limit of position monitoring (0.1°) Index 0 = fuel Index 1 = air	OEM / Service	x	x	x
608	Combustibile 1 - Impostazione punto di riferi- mento Indice 0 = combustibile Indice 1 = aria 0 = chiuso (<0°) 1 = aperto (>90°)	Fuel 1 : Selection of reference point Index 0 = fuel Index 1 = air 0 = closed (<0°) 1 = open (>90°)	OEM		x	
609	Combustibile 1 - Direzione rotazione del ser- vocomando Indice 0 = combustibile Indice 1 = aria 0 = antiorario 1 = orario VEDI MESSAGGIO DI "ATTENZIONE" RIPORTATO SOTTO.	Fuel 1 : Actuator's direction of rotation Index 0 = fuel Index 1 = air 0 = counterclockwise 1 = clockwise SEE "WARNING" MESSAGE QUOTED BELOW.	OEM		x	
610	Combustibile 1 - Limite tolleranza per monito- raggio posizione (0.1°) Indice 0 = combustibile Indice 1 = aria	Fuel 1 : Tolerance limit of position monitoring (0.1°) Index 0 = fuel Index 1 = air	OEM / Service		x	

611	Tipo di riferimento dei servocomandi index 0 = fuel (default = 0 (riferimento stan- dard) index 1 = air (default = 0 (riferimento stan- dard) 0 = standard 1 = fermo entro il raggio utile 2 = fermi interni (SQN1) 3 = entrambi	Type of referencing Index 0 = fuel Index 1 = air 0 = standard 1 = stop within usable range 2 = internal stop (SQN1) 3 = both	OEM	x	x	x
612	Combustibile 1 - Tipo di riferimento del servo- comando combustibile 0 = standard 1 = fermo entro il raggio utile 2 = fermi interni (SQN1) 3 = entrambi	Fuel 1: Type of reference for fuel actuator 0 = standard 1 = range stop in the usable range 2 = internal range stop (SQN1) 3 = both	OEM		x	
613	Tipo di servocomando Indice 0 = combustibile Indice 1 = aria 0 = 5s / 90° (1Nm, 1,2Nm, 3Nm) 1 = 10s / 90° (6Nm) 2 = 17s / 90° (10Nm)	Type of actuator Index 0 = fuel Index 1 = air 0 = 5 s / 90° (1Nm, 1,2Nm, 3Nm) 1 = 10 s / 90° (6Nm) 2 = 17 s / 90° (10Nm)	OEM	x	x	x
614	Combustibile 1 :Tipo di servocomando Indice 0 = combustibile Indice 1 = aria $0 = 5s / 90^{\circ} (1Nm, 1,2Nm, 3Nm)$ $1 = 10s / 90^{\circ} (6Nm)$ $2 = 17s / 90^{\circ} (10Nm)$	Fuel 1 : Type of actuator Index 0 = fuel Index 1 = air 0 = 5 s / 90° (1Nm, 1,2Nm, 3Nm) 1 = 10 s / 90° (6Nm) 2 = 17 s / 90° (10Nm)	OEM		x	
641	Attivazione procedura di standardizzazione inverter (riferirsi al codice errore 82) 0 = standardizzazione disattivata 1 = standardizzaione attivata	Control of speed standardization of VSD Error diagnostics of negative values (refer to error code 82)0 = no speed standardization 1 = speed standardization active			x	x

	Configurazione uscita analogica % di carico (valore fabbrica = 0)	Configuration of analog output (default value = 0)		7		
645	0 = DC 010 V	0 = DC 010 V	OEM / Service	IV2	х	х
	1 = DC 210 V	1 = DC 210 V		L		
	2 = DC 0/210 V	2 = DC 0/210 V				



ATTENTION: as for SQM3x actuators, set the direction according to the acutator function. As far as SQN1x actuators, set **always** the counterclockwise direction, independently from the model chosen for the specific function.


Block 700: Error history

Param.	Descrizione	Description	Password
701	Storico errori: 701 - 725.01.codice	Error history: 701 - 725.01.code	Service / Info
0	Storico errori: 701 - 725.02.codice diagnostico	Error history: 701 - 725.02.diagnostic code	Service / Info
0	Storico errori: 701 - 725.03.classe errore	Error history: 701 - 725.03.error class	Service / Info
0	Storico errori: 701 - 725.04.fase	Error history: 701 - 725.04.phase	Service / Info
0	Storico errori: 701 - 725.05.contatore avvii	Error history: 701 - 725.05.startup counter	Service / Info
725	Storico errori: 701 - 725.06.carico	Error history: 701 - 725.06.load	Service / Info

Param.	Descrizione	Description	Password
		Current output (default value = 0% - range =	
903	impostazione = 0-100%)	0-100%)	Service / Info
000	Indice 0 = combustibile Index 0 = fuel		
	Indice 1 = aria		
		Incremental position of actuators (default	
	fabbrica = 0% - range impostazione = -50% - 150%)	value = 0% - range = -50% - 150%)	
922	Indice 0 = combustibile		Service / Info
	Indice 0 – combustibile	Index 0 = fuel	
		Index 1 = air	
935	Giri motore assoluti	Absolute speed	OEM / Service
936	Giri motore in fase standardizzazione	Standardized speed	Service / Info
942	Sorgente potenza attiva	Active load source	OEM / Service
	Solo con LMV26:	Actual fuel	
945	Combustibile attuale	0 = fuel 0	Operations / Info
940	0 = combustibile 0	1 = fuel 1	Service / Info
	1 = combustibile 1		
947	Risultato interrogazione contatti (codifica bit)	Result of contact sensing (bit-coded)	Service / Info
950	Stato relè (codifica bit)	Required relay state (bit-coded)	Service / Info
	Intensità di fiamma (0% ÷ 100%);	Intensity of flame (range = 0% - 100%)	
954	minima corrente 30% = 4µA;	minimum current 30% = 4µA;	Service / Info
304	massima corrente100% = 16µA;	maximum current100% = 16µA;	Service / Inio
	massima corrente ammissibile = 40µA.	maximum current possible = 40µA.	
961	Stato moduli esterni e display	Status of external modules and display	Service / Info
981	Errore memoria: codice	Error memory: code	Service / Info
982	Errore memoria: codice diagnostica	Error memory: diagnostic code	Service / Info
992	Flag di errore	Error Flags	OEM / Service

Actuators references

An incremental transducer is used to ensure position feedback. Referencing of the actuators must be performed after power-on. In addition, at the end of each shutdown in phase 10, the actuators are referenced to ensure that individual stepping errors, which could lead to shutdown, do not accumulate. If a position error occurs, the system switches to the safety phase (phase 01), enabling the actuators with detected position errors to be referenced. During the following phase 10, the only actuators that are referenced are those that were not referenced before in the safety phase (phase 01). The position of the reference point can be selected depending on the type of burner design, either the CLOSED position ($<0^\circ$) or the OPEN position ($>90^\circ$).



Param.	Descrizione	Description	Password
601	Impostazione punto di riferimento	Selection of reference point	
	Indice 0 = combustibile	Index 0 = fuel	
	Indice 1 = aria	Index 1 = air	OEM
	0 = chiuso (<0°)	$0 = \text{closed} (<0^{\circ})$	
	1 = aperto (>90°)	1 = open (>90°)	

If the acutators position is exchanged (error code: 85), the burner will lockout and will try to adjust for three times, then it will lock out.

Gas proving system

Valve proving is only active when firing on gas. This is a leakage test designed to detect leaking gas valves and, if necessary, to prevent the valves from opening or ignition from being switched on. Lockout is initiated. When performing valve proving, the gas valve on the burner side is opened first to bring the test space to atmospheric pressure. Then, the valve is closed whereupon the pressure in the test space must not exceed a certain level, measured by the gas leakage pressure switch (PGCP). Then, the gas valve on the mains side is opened to fill the gas pipe. When the valve is closed again, the gas pressure must not drop below a certain level. Valve proving can be parameterized to take place on startup, shutdown, or on both phases.

Air-fuel curve points

There are 10 air-fuel curve points: T

P0 = ignition position. Only for ignition; after the ignition, the burner works between Point P1 (low flame) and point P9 (high flame) without going back to P0.

P0 can be set everywhere irrespective of all the other points.

COMMISSIONING THE BURNER

The LMV2x complete programming must be performed on units that has never been set before or reset units (e.g. spare parts). The programming procedure is performed by setting the following main parameters:

- 1 if LMV.. is a spare part, insert burner ID (parameter **113**) at least 4 digit.
- 2 type of fuel train (parameter "201")
- 3 air/fuel ratio curvepoints (Block "400")
- 4 maximum load percentage (parameter "546")
- 5 minimum load percentage (parameter "545")



CAUTION: if an error message as "Loc.." appears when the unit is turned to on for the first time, press ENTER (InFo) until the "Reset" message apperas. After few seconds, the message "OffUpr" will be displayed.

This message shows that the unit has not been programmed before or that the operating mode (fuel train) is not set yet or that the unit

has not been completely programmed. Pree keys **F** (Fuel) and **A** (Air) $\int_{r}^{\infty} \int_{a}^{\infty}$ at the same time unit the display shows **code** and next it will show 7 bars the first on the left is flashing. If the display shows "Off", it means that the unit already set, then see the instructions on chapter "Adjusting the burner with LMV2x already programmed").

At the first LMV startup, the AZL display will show




It means that the unit was never set or that no mode was chisen or that some parameters have to be set furthert. Push F (fuel) and A (Air) together until the display shows **code** and then a 7 digit dashed line blinking on the left.



Press the "+" key until the first character of the password (the default password is 9876), then press ENTER (InFo), the character now turn to a bar while the second bar starts flashing. Press "+" until the second character is entered, then press ENTER (InFo). Repeat the procedure until the last character si set, then press ENTER (InFo), then ENTER again until the message PArA appears: then the first parameters block ("400") will be shown:




Press ENTER (InFo) again, to gain access to programming the operating mode (fuel train):




In the example, set configuration **1** = direct gas ignition (G mod). Other possibilities are below listed:

Param.	Descrizione	Description	Password
201	Modalità funzionamento bruciatore (rampa comb., mod. / multistadio, servocom., ecc.) = non definito (cancellazione curve)= 1 = accensione diretta a gas (G mod) 2 = accensione tramite pilota gas con attacco tra le due elettrovalvole EV1/EV2 gas (Gp1 mod) 3 = accens. tramite pilota gas con attacco a monte dell'elettrov. EV1 del gas (Gp2 mod) 4 = accensione a gasolio - modul. (Lo mod) 5 = accens. a gasolio - bistadio (Lo 2 stage) 6 = accens. a gasolio - tristadio (Lo 3 stage)	2 = gas pilot ignition with connection between the two gas solenodi valves EV1/EV2 (Gp1 mod)	OEM / Service



Lo 3-stage



In the example the Gmod gas train has been set (Configuration "1").

Choose the fuel train by pressing ENTER, then press "+" / "-". Press ENTER to confirm: number "1" will appear on the right side of the display.

1 8 .0.9.9.9.9.9.9.9

Press "+" to show the first point to be set P0.

Ρ		1
ñ	┋╊═┦╸┠═┨╸┝═┥╸┝═┽╸┝╤┽╸┝╤┽╸┝╤┽	
Ľ		
	√√√√ ∨ h min s %	X

Press **F** and "+" to increase the opening angle of the fuel actuator "**0F**" until the requested value is reached (for example $12^{\circ} \div 15^{\circ}$, see below) for the ignition point; or press **F** and "-" to decrease the angle:

	R	'I my		œ	Ľ₩	\sim		
Ρ			7			Ā		3
ñ		• –	1-10	н	۰H·	H		
e				<u> </u>		<u> </u>		
	\sim		, N	h	min	s	%	¥

To set the air damper opening angle "0A" in the ignition point (10° for example - see below), press "A" and "+" "A" and "-" at the same time:

		WW	\Box	œ		p		
P •11		B :	Ī.	B.	0:	Ō.		1 %
~								
	\bigtriangledown	\bigtriangleup	V	h	min	S	%	¥

LMV37:

Now the air and fuel quantities are set at the ignition point P0:

By pressing "+", point P9 can be programmed to set the air and fuel values at the maximum output

		> 14
P	' ```	n m.m
ĭ S		1.0.0
0		
	″▽″∆°V h min s	; % ≮


go on as described above to the the opening angles of the air actuator (A) and fuel actuator (F):





CAUTION: at the first burner adjustment, it is recommended to set the maximum output P9 at the same value (or little higher) of the ignition point, in order to safely reach point P9 next (see next paragraph).

By pressing "+" the display will show:



The burner is ready to startup. Now it is possible to re-set the curve points while the burner is operating ("warm setting") by pressing the ENTER (InFo) or while the burner is in stand-by mode ("cold setting") by pressing ENTEF .

Warm setting

- 1 Once pressed button "enter" and the chain thermostats open (X5-03 terminals), the LMV.. show Ph12. Then close the chain termostat and the unit performs the prepurge cycle (see "Phases List") and stops at the ignition point P0 without ignition anyway.
- 2 By pressing "+", the burners lights abd the air/fuel ratio can be properly set in presence of flame.
- 3 By pressing "+" again, the next point P1 is shown (eqaul to P0 as the unit automatically set P0=P1);
- 4 By pressing "+" again, the "Calc" message will be displayed: the unit is processing the sir/fuel ratio curvepoints until point P9, previuosly set. Once the processing is performed the calculated point P2 is shown.By pressing "+" again, the "Calc" message will be displayed: the unit is processing the sir/fuel ratio curvepoints until point P9, previuosly set. Once the processing is performed the calculated point P2 is shown.
- 5 By pressing "+", it is possible to go through the processed curve until point P9 is reached.
- Note: if the point doesn't blink, servomotors are still running.
- 6 n order to set P9 with the gas flow rate according to the generator needs, follow this procedure:

Note: the purpose is to fully open the gas throttle and later on to adjust the gas flow rate through the gas pressure governor.


- Operate smoothly opening by just a few degrees the air damper and later on increasing the gas throttle opening it by a few degrees. Keep monitoring the flue through the flue analyser. Keep the air excess inside normal figures (from 3% to 7% residual O2) operating by means for the air damper servomotor;
- Keep increasing the air damper opening and then the gas throttle, as done in the sequence above, remebering to get the full firing
 rate wih the gas throttle fully open (or the oil pressure regulator at its maximum pressure position).
 See example below:



- If, while opening the gas throttle, the gas flow rate was too high, reduce it only through the gas governor and keep opening the throttle until the 60÷70° position is got.
- If the gas train is equipped with a governor and a valve with an adjustable gas flow rate, fully open also this last valve, smoothly! The gas flow rate is always set by means of the governor.
- 7 As soon as all the devices are fully open, set the gas flow rate through the governor.
- 8 Set the air damper position in order to get the reccomended air excess (3÷4.8% O2 on gas and 2.9÷4.9% on oil).

Note1: on high flame, if the gas flow rate is changed by means of the governor, all the other points below high flame must be checked again.


9 After having set the high flame point P9, keep "-" pressed for some seconds unitl "Calc" is displayed in order to have the LMV recalculating all the points:




- 10 the unit will automatically reach point P8 processed: check the combustion values in this point and, if necessary, change it.
- 11 Press "-" to go down to the lower points and check the combustion values, change the points if necessary.

Note: if in an intermediate point (for example P5), the change of the actuators position is important according to the processed point


P5, keep pressing "-" unitl "Calc" is displayed. The curve will be processed again downwards point P1.



- 12 press "-" to go through the lower points and check the combustion values, if necessary change the points as described above.
- 13 By pressing ESC, at the end of the points adjusments, the parameter "**546**" (setting the maximum load) will be displayed; press ENTER (InFo), then "+" until 100%, then press ENTER (InFo) again, ESC and then "+".



14 The parameter "**545**" (setting the minimum load) is displayed: press ENTER (InFo), then "+" until 20%. Press ENTER, then press ESC for three times. The message "oP" will be displayed as well as the load percentage at the burner is working on.



he hyphen related to the symbol "P" (highlited in the picture) will be off to show that the unit exited the programmig mode. The burner will then work automatically, following the curve set.

.Note1: if the curvepoints settings is quit before end (by pressing ESC or for a faulty shutdown), the message "OFF UPr" (Start prevention) will be diplayed until all the curvepoints will be set.

Note2: if the gas flow rate at high flame point (maximum load) is changed by means of the pressure stabiliser, all the curvepoints must be checked by going through the curve downwards and resetting them if necessary.

Note3: if the point does not flash, it means thet the actuators have not reached the set position yet.

Note4: if an error occurs causing a safety shutdwon during the processing of the curve, the processing itself will be interrupted.

Cold setting

The "cold setting" (without flame) can be performed only when all the curve points values are known (for instance, in case of replacement).



When the burner is off, if you modify one curve set point, when the burner restarts the AZL2x shows OFF UPr (OFF UPr0 or OFF UPr1 for LMV26). The LMV.. then, requires a new "warm" startup (see procedure paragraph "Warm Setting") by checking again all points of curve from P0 to P9.

BURNER STARTUP WITH LMV2x ALREADY PROGRAMMED

Once the LMV turns on, the AZL display will show



The burners is basically factory set. The air/fuel ratio curve is set with the maximum output point P9 a little higher or equal to P0. To adjust the burner on the plant site, adjust the maximum output point to the flow rate values really requested. Then go through the curve-points, by pressing "+" several times to reach point P9: then adjust the air actuator position (for the air damper) and the fuel actuator (for the butterfly valve, in case of gas or the oil pressure governor incase of oil), by adjusting the fuel flow rate by means of the gas pressure stabiliser (for gas) or the oil pressure governor (for oil), checking the combustion values contemporarly. Once the burner is adjusted at the maximum output, press "-" for more than 5 seconds to process the curve downwards. The curve is then a straight line: go on checking the combustion values point by point; change them if necessary and in case linearise the curve again.

Before starting the burner up, press F and A at the same time



enter the password following the procedure on chapter "Programming LMV2x". Press ENTER until the display will show:



Press ENTER again: it will show

	\sum	WW	\bigcirc	œ	\square	p		
P. °= //		0.		0		.	8	Ø
	\bigtriangledown	\bigtriangleup	V	h	min	s	%	¥

press ENTER (InFo)

: the display will show phase 12.

Ph12: *Standby* phase (stationary) Ph12: *Standby* phase (stationary)

By closing the thermostatic series, the burner startup cycle will take place:

- Ph22: Fan ramp up phase (fan motor = ON, safety shutoff valve = ON)
- Ph24: Traveling to prepurge position phase
- Ph30: Prepurge phase
- Ph36: Traveling to ignition position phase
- Ph38: Preignition phase
- Ph40: 1st safety time phase (ignition transformer ON)
- Ph42: 1st safety time phase (ignition transformer OFF), preignition time OFF

Ph44: Interval1

The startup sequence stops at phase 44.

The burners is lit and is in"P1" position (low flame point):




Set the air/fuel ratio curvepoints as described on chapter "Programming the LMV2x"

Note: the other phases are Ph60 = operation (OP= in modulation) Ph62 = travelling to shutdown Ph70 = off but in prepurge after the burntime

- Ph72 = travelling to postpurging
- Ph74 = postpurge (countdown is displayed)

Press ESC $\stackrel{\text{lim}}{\longrightarrow}$ the parameter "546" (Setting the maximum load) is displayed

Then press $\overbrace{-}^{\text{min}}$ to exit the programming mode. The display will show:



Press $\overset{\frown}{\xrightarrow{}}_{+}^{\infty}$ for a second time: the display will show the load percentage the burner is working at.

		WW	\Box	œ	∠ ₹	p		
P îl	8	8	8	8		8	0	7
0							—	
	\bigtriangledown	\triangle	V	h	min	s	%	¥

When the generator reaches the programmed set-point, the burner will be in stand-by: the display will show

	\sum	~~~~	C	œ		p			
P 11	0	E	E			Ō		N	
									Ì
	\bigtriangledown	\bigtriangleup	V	h	min	s	%	¥	

Reset / manual lockout

The system can be manually locked by simultaneously pressing the **ENTER (InFo)** button and **any other button** on the AZL2.... This function allows the user to stop the system from the operating level should an emergency occur. When making a reset, the following actions are carried out:

- Alarm relay and the fault display are off
- the lockout position is cancelled
- the unit performs a reset, then it switches to stand-by

If the unit is in the lockout position, a reset can be made by pressing the **InFo** button for 1...3 seconds. The function is available only when the unit is in the lockout position. Longer or shorter pushes on the button do not produce a reset so that the system maintains the lockout position.

Codice errore / Error code	Codice diagnostico / Diagnostic code	Descrizione / Meaning
167	2	/ Manual lockout via AZL2

Timeout for menu operation


The time for automatically leaving the parameter setting level can be adjusted between 10 and 120 minutes, using the parameter 127 (Timeout for menu operation). If, during that period of time, there is no operation via the AZL2..., the parameter setting level is quit and the password level reset to *Info / Service*.

Caution! In addition, this timeout or interruption of communication between the LMV2.. and the AZL2... during the time the curves are set leads to lockout!

Codice erroreC Error code	Codice diagnostico Diagnostic code	DescrizioneMeaning		
167	8	Manual locking		

Entering the Parameter levels

By means of a proper use of the keys, it is possible to enter the various level parameters, as shown in the following flow chart:



The burner and consequently the LMV2x.. are factory set; the air and fuel curves as set as well.

Info level

To enter the Info level, proceed as follows:

1 in any menu position, press keys + and - at the same time, then the program will start again: the display will show OFF.



2 , until the display will show InFo, Press the enter (InFo) key



- 3 then il will show the first code (167) flashing, on the right side it will show the data entered. By pressing + or it is possible to scroll (up or down) the parameter list.
- 4 If a dot-line is shown on the right, there is no enough room for complete visualisation: press enter again the data will be completely shown for 1 to 3 seconds. By pressing enter or + and- at the same time, the system will exit the parameter visualisation and go back to the flashing number. The Info level shows some basic parameters as:

Parameter	Description
167	Cubic meters of fule (resettable)
162	Operating hours (resettable)
163	Device operating hours
164	Burners start-ups (resettable)
166	Total number of start-ups
113	Burner number (i.e. serial number)
107	Software version
102	Software date
103	Device serial number
104	Customer code
105	Version
143	Free

5 Example: choose parameter 102 to show the date



the display shows parameter 102 flashing on the left and characters ._._ on the right.


- 6 press InFo for 1-3 seconds: the date will appear
- 7 press InFo to go back to parameter "102"
- 8 by pressing + / -, it is possible to scroll up/down the parameter list (see table above), or, by pressing ESC or InFo for more seconds, the display will show
- 9 Once the last parameter is accessed (143) by pressing + , the End message will flash.

PIER	1.5
ñ 📭 🖂 🖉 🖉 🖉 🖓 👘	6
V A W H Nn s %	• ≮ •


10 Press InFo and for more than three seconds or for more than three seconds orto return to the normal display.



If a message like the one below is shown during operation,



it means that the burner is locked out and the Errore code is shown (in the example "error code:4"); this message is alternating with another message




Diagnostic code (in the example "diagnostic code:3"). Record the codes and find out the fault in the Error table To perform the reset, press InFo for one second:



The unit displays an event which does not lead to shutdown.

The display shows current error code c: alternating with diagnostic code d:



Press **InFo** to return to the display of phases. Example: Error code **111** / diagnostic code 0

		****	\bigcirc	œ	\mathbb{Z}	p		
P°⊐∬	B	0	Ē.	8	Ø.		8	2
~				h	min	s	0/2	
	~		v			3	70	\mathcal{F}

To reset, press InFo for a second. Record the codes and check the Error List to find the type of faults.


Service level

To enter the Service mode, press InFo until the display will show:

		100 WW	œ	H 10	B
P	181	7. 0		10	D.M.
1° –	0.0			J. 🛄.	0.0
	∇	ΔV	h m	in s	% ≮

The service level shows all the information about flame intensity, actuators position, number and lock codes:

Parameter	Description
954	Flame intensity
121	% output, if set = automatic operation
922	Actuators position, 00=combustibile; 01= aria
161	Lock-outs number
701725	Lock-outs History (see chapter 23 in the LMV2x manual)



- 1 the first parameter will be "954": the percentage of flame is shown on the right. By pressinf + or it is possible to scroll up/down the parameter list.
- 2 Once the last parameter is accessed (143) by pressing + , the **End** message will blink.

	\sum	WW/	0	on;	T X	20		
Ρ	īħ	Ā	٦		5	R	A	17
ñ	H	E.	H	п	Ц	الل ا:	Ħ	
Z			<u> </u>		2	-		
	\bigtriangledown	\triangle	V	Ы	nNn	s	%	¥

3 Press InFo. for more than three seconds or for more than three seconds orto return to the normal display.

	\sum	WW/	C	œ	Zł	p		
P		ī		h	ī	Ē		ā
ñ	١Ħ	H.	E	П	Н	۲Ľ.	E	G
2		-	_	-	_	_	=	_
	\bigtriangledown	\bigtriangleup	V	h	min	s	%	¥

PHASES LIST

Fase /Phase	Funzione	Function
Ph00	Fase blocco	Lockout phase
Ph01	Fase di sicurezza	Safety phase
Ph10	t10 = tempo raggiungimento posizione riposo	t10 = home run
Ph12	Pausa	Standby (stationary)
Ph22	t22 = tempo di salita ventilatore (motore ventilatore = ON, valvola intercettazione di sicurezza = ON)	t22 = fan ramp up time (fan motor = ON, safety shutoff valve = ON)
Ph24	Verso posizione preventilazione	Traveling to the prepurge position
Ph30	t1 = tempo preventilazione	t1 = prepurge time
Ph36	Verso posizione accensione	Traveling to the ignition position
Ph38	t3 = tempo preaccensione	t3 = preignition time
Ph40	TSA1 = primo tempo sicurezza (trasformatore accensione ON)	TSA1= 1st safety time (ignition transformer ON)
Ph42	TSA1 = primo tempo sicurezza (trasformatore accensione OFF)	TSA1 = 1st safety time (ignition transformer OFF), t42 = preignition time OFF
Ph44	t44 = intervallo 1	t44 = interval 1
Ph50	TSA2 = secondo tempo sicurezza	TSA2 = 2nd safety time
Ph52	t52 = intervallo 2	t52 = interval 2
Ph60	Funzionamento 1 (stazionario)	Operation 1 (stationary)
Ph62	t62 = massimo tempo bassa fiamma (funzionamento 2, in preparazione per spegnimento, verso bassa fiamma)	t62 = max. time low-fire (operation 2, preparing for shutdown, traveling to low-fire)
Ph70	t13 = tempo postcombustione	t13 = afterburn time
Ph72	Verso posizione postcombustione	Traveling to the postpurge position
Ph74	t8 = tempo postventilazione	t8 = postpurge time
Ph80	t80 = tempo evacuazione controllo tenuta valvole	t80 = valve proving test evacuation time
Ph81	t81 = tempo perdita pressione atmosferica, prova atmosferica	t81 = leakage time test time atmospheric pres- sure, atmospheric test
Ph82	t82 = test perdita, test riempimento	t82 = leakage test filling test, filling
Ph83	t83 = tempo perdita pressione gas, test pressione	t83 = leakage test time gas pressure, pressure test
Ph90	Tempo attesa "mancanza gas"	Gas shortage waiting time


BACKUP PARAMETER WITH AZL2x

On the AZL2x you can save the configuration to download on another appliance LMV. To do this:

access up, press F and A at the same time



enter the password following the procedure on chapter "Programming LMV2x". Press ENTER until the display will show:



RESTORE PARAMETER FROM AZL2x TO LMV..


To copy the previously saved configuration on AZL2x proceed as follows: access up, press F and A at the same time





enter the password following the procedure on chapter "Programming LMV2x". Press ENTER until the display will show:





After about 5 seconds the restore process ends and the display shows Now, LMV has the same configuration that was stored on AZL2x.

ERROR CODE TABLE

Error code	Diagnostic code	Meaning for the LMV2x/3x system	Remedy
no Comm		No communication between LMV26 basic unit and AZL2	Check wiring for line interruption/loose contact
2	#	No flame at the end of safety time (TSA)	
	1	No flame at the end of safety time 1 (TSA1)	
	2	No flame at the end of safety time 2 (TSA2)	
3	#	Air pressure failure	
	0	Air pressure off	
	1	Air pressure on	
	4	Air pressure on – prevention of startup	
	20	Air pressure, combustion pressure – start prevention	
	68	Air pressure, POC – start prevention	
	84	Air pressure, combustion pressure, POC – start preven- tion	
4	#	Extraneous light	
	0	Extraneous light during startup	
	1	Extraneous light during shutdown	
	2	Extraneous light during startup – prevention of startup	
	6	Extraneous light during startup, air pressure – start pre- vention	
	18	Extraneous light during startup, combustion pressure – start prevention	
	24	Extraneous light during startup, air pressure, combus- tion pressure – start prevention	
	66	Extraneous light during startup, POC – start prevention	
	70	Extraneous light during startup, air pressure, POC – start prevention	
	82	Extraneous light during startup, combustion pressure, POC – start prevention	
	86	Extraneous light during startup, air pressure, combus- tion pressure, POC – start prevention	
7	#	Loss of flame	
	0	Loss of flame	
	3255	Loss of flame due to TÜV test (loss-of-flame test)	Diagnostics corresponds to the period of time from shutdown of fuel valves to the detection of loss of flame (resolution 0.2 s \rightarrow Value 5 = 1 s)

Error code	Diagnostic code	Meaning for the LMV20 system	Remedy
12	#	Valve proving	
			With valve proving via X5-01 (gas pressure switch-min)
		Fuel valve 1 (V1) leaking	- Check if valve on the burner side is leaking
	0	(fuel valve 2 with valve proving via X5-01)	- Check if pressure switch for valve proving is closed, if gas pressure exist
			- Check wiring for short-circuit
	1	Fuel valve 2 (V2) leaking (fuel valve 1 with valve proving via X5-01)	With valve proving via X5-01 (gas pressure switch-min)
			- Check if valve on the gas side is leaking
			- Check wiring for short-circuit
	2	Valve proving not possible	Valve proving activated, but pressure switch-min selected as input function for X9-04 (check
			parameters 238 and 241)
	3	Valve proving not possible	Valve proving activated, but no input assigned (check parameters 236 and 237)
	4	Valve proving not possible	Valve proving activated, but 2 inputs assigned (set parameter 237 to pressure switch-max or POC)
	5	Valve proving not possible	Valve proving activated, but 2 inputs assigned (check parameters 236 and 237)
			Check to see if the valve on the gas side is leaking
	81	V1 leaking	Check wiring to see if there is an open-circuit
			Check to see if the valve on the burner side is leaking
	83	V2 leaking	Check to see if the pressure switch for the leakage test is closed when gas pressure is present
			Check wiring for short-circuit
14	#	POC	
	0	POC open	Check to see if the valve's closing contact is closed
	1	POC close	Check wiring
			Check to see if the valve's closing contact opens when valve is controlled
	64	POC open - start prevention	Check wiring to see if there is a line interruption.
			Check to see if the valve's closing contact is closed
19	80	Combustion annual DOO atest annualtion	Check to see if pressure switch has closed with no combustion pressure present
19	00	Combustion pressure, POC – start prevention	Check wiring for short-circuit
20	#	Pressure switch-min (Pmin)	
	0	No minimum gas /oil pressure	Check wiring for open-circuit
	1	Gas shortage – start prevention	Check wiring for open-circuit
21	#	Pressure switch-max / POC	
		Pressure switch-max: Max. gas / oil pressure exceeded	Check wiring to see if there is a line interruption.
	0	POC: POC open (software version ≤ V02.00)	POC: Check to see if the valve's closing contact is closed.

Error code	Diagnostic code	Meaning for the LMV2x/3x system	Remedy
22 OFF S	#	Safety loop / burner flange	
	0	Safety loop / burner flange open	
	1	Safety loop / burner flange open - prevention of startup	
	3	Safety loop/burner flange, extraneous light – start pre- vention	
	5	Safety loop/burner flange, air pressure – start preven- tion	
	17	Safety loop/burner flange, combustion pressure – start prevention	
	19	Safety loop/burner flange, extraneous light, combustion pressure – start prevention	
	21	Safety loop/burner flange, air pressure, combustion pressure – start prevention	
	23	Safety loop/burner flange, extraneous light, air pressure, combustion pressure – start prevention	
	65	Safety loop/burner flange, POC – start prevention	
	67	Safety loop/burner flange, extraneous light, POC – start prevention	
	69	Safety loop/burner flange, air pressure, POC – start prevention	
	71	Safety loop/burner flange, extraneous light, air pressure, POC – start prevention	
	81	Safety loop/burner flange, combustion pressure, POC – start prevention	
	83	Safety loop/burner flange, extraneous light, combustion pressure, POC – start prevention	
	85	Safety loop/burner flange, air pressure, combustion pressure, POC – start prevention	
	87	Safety loop/burner flange, extraneous light, air pressure, combustion pressure, POC – start prevention	
50	#	Internal error	Make a reset; if error occurs repeatedly, replace the unit
51	#	Internal error	Make a reset; if error occurs repeatedly, replace the unit
55	#	Internal error	Make a reset; if error occurs repeatedly, replace the unit
56	#	Internal error	Make a reset; if error occurs repeatedly, replace the unit
57	#	Internal error	Make a reset; if error occurs repeatedly, replace the unit

Error code	Diagnostic code	Meaning for the LMV2x/3x system	Remedy
58	#	Internal error	Make a reset; if error occurs repeatedly, replace the unit
61 Fuel Chg	#	Fuel changeover	
Fuel Chg	0	Fuel 0	No error - change to Fuel 0
Fuel Chg	1	Fuel 1	No error - change to Fuel 1
62 Fuel Err	#	Invalid fuel signals / fuel information	
Fuel Err	0	Invalid fuel selection (Fuel 0 + 1 = 0)	Check wiring to see if there is an open-circuit Note Curves cannot be set.
Fuel Err	1	Different fuel selection between the µCs	Make a reset; if error occurs repeatedly, replace the unit
Fuel Err	2	Different fuel signals between the µCs	Make a reset; if error occurs repeatedly, replace the unit
Fuel Err	3	Invalid fuel selection (Fuel 0 + 1 = 1)	Check wiring for short-circuit Note Curves cannot be set. LMV26: Optional press reset button >3 seconds.
65	#	Internal error	Make a reset; if error occurs repeatedly, replace the unit
66	#	Internal error	Make a reset; if error occurs repeatedly, replace the unit
67	#	Internal error	Make a reset; if error occurs repeatedly, replace the unit
70	#	Internal error fuel-air ratio control: Position calcula- tion modulating	
	23	Output invalid	No valid output
	26	Curvepoints undefined	Adjust the curvepoints for all actuators
71	#	Special position undefined	
	0	Home position	Parameterize the home position for all actuators used
	1	Prepurge position	Parameterize the prepurge position for all actuators used
	2	Postpurge position	Parameterize the postpurge position for all actuators used
	3	Ignition position	Parameterize the ignition position for all actuators used
72	#	Internal error fuel-air ratio control	Make a reset; if error occurs repeatedly, replace the unit
73	#	Internal error fuel-air ratio control: Position calcula- tion multistep	
	23	Output invalid	No valid output
	26	Curvepoints undefined	Adjust the curvepoints for all actuators

Error code	Diagnostic code	Meaning for the LMV2x/3x system	Remedy
75	#	Internal error fuel-air ratio control: Data clocking check	
	1	Current output different	
	2	Target output different	
	4	Target positions different	
	16	Different positions reached	Can be caused by different standardized speeds (e.g. after restore of data set) when the VSD is activated \rightarrow standardize again and check adjustment of the fuel-air ratio control system
76	#	Internal error fuel-air ratio control	Make a reset; if error occurs repeatedly, replace the unit
			Basic unit could not correct the difference in speed and reached a control range limit. 1. Basic unit is not standardized for this motor → repeat standardization. Caution! Settings of fuel-air ratio control must be checked.
80	#	Control range limitation of VSD	 Ramp time settings of the VSD are not shorter than those of the basic unit (parameters 522, 523). Characteristic of the VSD is not linear. Configuration of the voltage input at the VSD must accord with that of the basic unit (parameter 645). VSD does not follow quickly enough the changes of the basic unit. Check settings of the VSD (input filter, slippage compensation, hiding different speeds)
	1	Control range limitation at the bottom	VSD speed was too high
	2	Control range limitation at the top	VSD speed was too low
81	1	Interrupt limitation speed input	Too much electromagnetic interference on the sensor line \rightarrow improve EMC

Error code	Diagnostic code	Meaning for the LMV2x/3x system	Remedy
82	#	Error during VSD's speed standardization	
	4	Timeout of standardization (VSD ramp down time too	Timeout at the end of standardization during ramp down of the VSD
	1	long)	\rightarrow ramp time settings of the VSD are not shorter than those of the basic unit (parameter: 523)
	2	Starsage of standardized anoad not suspendful	Error during storage of the standardized speed
	2	Storage of standardized speed not successful	\rightarrow lock the basic unit, then reset it and repeat the standardization
			Basic unit receives no pulses from the speed sensor:
		time information and announ	1. Motor does not turn.
	3	Line interruption speed sensor	2. Speed sensor is not connected.
			3. Speed sensor is not activated by the sensor disk (check distance)
			Motor has not reached a stable speed after ramp up.
			1. Ramp time settings of the VSD are not shorter than those of the basic unit (parameters 522, 523).
		Speed variation / VSD ramp up time too long / speed	2. Characteristic of the VSD is not linear. Configuration of the voltage input at the VSD must
	4	below minimum limit for standardization	accord with that of the basic unit (parameter 645).
			3. VSD does not follow quickly enough the changes of the basic unit. Check settings of the VSD
			(input filter, slippage compensation, hiding different speeds)
			4. Speed of VSD lies below the minimum for standardization (650 1/min)
			Motor's direction of rotation is wrong.
			1. Motor turns indeed in the wrong direction
	5	Wrong direction of rotation	\rightarrow change parameterization of the direction of rotation or interchange 2 live conductors.
			2. Sensor disk is fitted the wrong way
			\rightarrow turn the sensor disk.
			The required pulse pattern (60°, 120°, 180°) has not been correctly identified.
			1. Speed sensor does not detect all tappets of the sensor disk
			\rightarrow check distance
	6	Unplausible sensor signals	2. As the motor turns, other metal parts are detected also, in addition to the tappets → improve mounting.
			3. Electromagnetic interference on the sensor lines
			\rightarrow check cable routing, improve EMC
	-		The standardized speed measured does not lie in the permissible range
	7	Invalid standardized speed	→ motor turns too slowly or too fast
			The speeds of microcomputer 1 and 2 deviated too much. This can be caused by wrong standard
	15	Speed deviation μ C1 + μ C2	ized speeds (e.g. after restoring a data set to a new unit)
		, , , , , , , , , , , , , , , , , , ,	\rightarrow repeat standardization and check the fuel-air ratio

Error code	Diagnostic code	Meaning for the LMV2x/3x system	Remedy
	20	Wrong phase of phase manager	Standardization was made in a wrong phase. Permitted are only phases $\leq 12 \rightarrow$ controller OFF, start standardization again
	21	Safety loop / burner flange open	Safety loop or burner flange is open \rightarrow repeat standardization with safety loop closed
	22	Air actuator not referenced	 Air actuator has not been referenced or has lost its referencing. 1. Check if the reference position can be approached. 2. Check if actuators have been mixed up. 3. If error only occurs after the start of standardization, the actuator might be overloaded and cannot reach its destination.
	23	VSD deactivated	Standardization was started with VSD deactivated → activate the VSD and repeat standardization
	24	No valid operating mode	Standardization was started without valid operating mode → activate valid operating mode and repeat standardization
	25	Pneumatic air-fuel ratio control	Standardization was started with pneumatic air-fuel ratio control → standardization with pneumatic air-fuel ratio control not possible
	128	Running command with no preceding standardization	VSD is controlled but not standardized → make standardization
	255	No standardized speed available	Motor turns but is not standardized → make standardization

Error code	Diagnostic code	Meaning for the LMV2x/3x system	Remedy
3	#	Speed error VSD	Required speed has not been reached
	Bit 0 Valency 1	Lower control range limitation of control	Speed has not been reached because control range limitation has become active \rightarrow for measures, refer to error code 80
	Bit 1 Valency 23	Upper control range limitation of control	Speed has not been reached because control range limitation has become active \rightarrow for measures, refer to error code 80
	Bit 2 Valency 47	Interruption via disturbance pulses	Speed has not been reached due to too much electromagnetic interference on the sensor line → for measures, refer to error code 81
	Bit 3 Valency ≥ 8	Curve too steep in terms of ramp speed	 Speed has not been reached because detected curve slope was too steep. 1. With a LMV26 ramp of 20 s, the curve's slope may be a maximum of 10% speed change between 2 curvepoints in modulating mode. With a LMV26 ramp of 10 s, the curve's slope may be a maximum of 20% speed change between 2 curvepoints in modulating mode. With a LMV26 ramp of 5 s, the curve's slope may be a maximum of 40% speed change between 2 curvepoints in modulating mode. → Between the ignition point (P0) and the low-fire point (P1), the speed change in modulating mode may be a maximum of 40%, independent of the LMV26 ramp. 2. The setting of the VSD ramp must be about 20% faster than the ramps in the basic unit (parameters 522, 523).
	Bit 4 Valency ≥ 16	Interruption of speed signal	No speed detected in spite of control.1. Check if the motor turns.2. Check if the speed sensor delivers a signal (LED / check distance from the sensor disk).3. Check wiring of the VSD.
	Bit 5 Valency ≥ 32	Quick shutdown due to excessive speed deviation	Speed deviation was for about 1 s >10% outside the anticipated range. 1. Check ramp times of the LMV26 and VSD. 2. Check wiring of the VSD.

Error code	Diagnostic code	Meaning for the LMV2x/3x system	Remedy
84	#	Curve slope actuators	
	Bit 0 Valency 1	VSD: Curve too steep in terms of ramp speed	 The curve's slope may be a maximum of 10% speed change between 2 curvepoints in modulating operation, with a LMV26 ramp of 20 seconds The curve's slope may be a maximum of 20% speed change between 2 curvepoints in modulating operation, with a LMV26 ramp of 10 seconds The curve's slope may be a maximum of 40% speed change between 2 curvepoints in modulating operation, with a LMV26 ramp of 10 seconds The curve's slope may be a maximum of 40% speed change between 2 curvepoints in modulating operation, with a LMV26 ramp of 5 seconds → Between the ignition point (P0) and the low-fire point (P1), the speed change in modulating mode may be a maximum of 40%, independent of the LMV26 ramp. Setting of the VSD ramp must be about 20% shorter than the ramps in the basic unit (parameters 522 and 523) Output Description: Description:
	Bit 1 Valency 23	Fuel actuator: Curve too steep in terms of ramp rate	The slope of the curve may be a maximum position change of 31° between 2 curvepoints in modulating mode
	Bit 2 Valency 47	Air actuator: Curve too steep in terms of ramp rate	The slope of the curve may be a maximum position change of 31° between 2 curvepoints in modulating mode
35	#	Referencing error ones actuators	
	0	Referencing error of fuel actuator	Referencing of fuel actuator not successful. Reference point could not be reached. 1. Check to see if actuators have been mixed up. 2. Check to see if actuator is locked or overloaded.
	1	Referencing error of air actuator	Referencing of fuel actuator not successful Reference point could not be reached. 1. Check to see if actuators have been mixed up. 2. Check to see if actuator is locked or overloaded.
	Bit 7 Valency ≥ 128	Referencing error due to parameter change	Parameterization of an actuator (e.g. the reference position) has been changed. To trigger new referencing, this error is set
6	#	Error fuel actuator	
	0	Position error	Target position could not be reached within the required tolerance band \rightarrow check to see if actuator is locked or overloaded
	Bit 0 Valency 1	Line interruption	Line interruption detected at actuator's terminals → check wiring (voltage X54 across pin 5 or 6 and pin 2 >0.5 V)
	Bit 3 Valency ≥8	Curve too steep in terms of ramp rate	The slope of the curve may be a maximum position change of 31° between 2 curvepoints in modulating mode
	Bit 4 Valency ≥ 16	Step deviation in comparison with last referencing	Actuator was overloaded or mechanically twisted. 1. Check to see if the actuator is blocked somewhere along its working range. 2. Check to see if the torque is sufficient for the application.

Error code	Diagnostic code	Meaning for the LMV2x/3x system	Remedy
87	#	Error air actuator	
	0	Position error	Target position could not be reached within the required tolerance band \rightarrow check to see if actuator is locked or overloaded
	Bit 0 Valency 1	Line interruption	Line interruption detected at actuator's terminals \rightarrow check wiring (voltage X53 across pin 5 or 6 and pin 2 >0.5 V)
	Bit 3 Valency ≥ 8	Curve too steep in terms of ramp rate	The slope of the curve may be a maximum position change of 31° between 2 curvepoints in modulating mode
	Bit 4 Valency ≥ 16	Sectional deviation in comparison with last referencing	Actuator was overloaded or mechanically twisted. 1. Check to see if the actuator is blocked somewhere along its working range. 2. Check to see if the torque is sufficient for the application.
90	#	Internal error basic unit	
91	#	Internal error basic unit	
93	#	Error flame signal acquisition	
	3	Short-circuit of sensor	Short-circuit at QRB 1. Check wiring. 2. Flame detector possibly fault.
95	#	Error relay supervision	
	3 Ignition transformer 4 Fuel valve 1 5 Fuel valve 2 6 Fuel valve 3	External power supply NO contact	Check wiring
96	#	Error relay supervision	
	3 Ignition transformer 4 Fuel valve 1 5 Fuel valve 2 6 Fuel valve 3	Relay contacts have welded	 Test the contacts: 1. Unit connected to power: Fan output must be dead. 2. Disconnect power: Disconnect fan. No resistive connection between fan output and neutral conductor allowed. If one of the 2 tests fails, release the unit since contact have definitively welded and safety can not longer be ensured.
97	#	Error relay supervision	
	0	Safety relay contacts have welded or external power supply fed to safety relay	 Test the contacts: 1. Unit connected to power: Fan output must be dead. 2. Disconnect power: Disconnect fan. No resistive connection between fan output and neutral conductor allowed. If one of the 2 tests fails, release the unit since contacts have definitively welded and safety can no longer be ensured.

Error code	Diagnostic code	Meaning for the LMV2x/3x system	Remedy
98	#	Error relay supervision	
	2 Safety valve		
	3 Ignition transformer		
	4 Fuel valve 1	Relay does not pull in	Make a reset; if error occurs repeatedly, replace the unit
	5 Fuel valve 2	5.5 St.	6. 0.4 0.62 22
	6 Fuel valve 3		
99	#	Internal error relay control	Make a reset; if error occurs repeatedly, replace the unit
			Make a reset. If error occurs repeatedly, replace the unit
	3	Internal error relay control	Software version V03.10: If error C:99 D:3 occurs during standardization of the VSD, deactivate
			temporarily function Alarm in case of start prevention (parameter number 210 = 0, when using a
			release contact) or interrupt the controller-ON signal
100	#	Internal error relay control	Make a reset; if error occurs repeatedly, replace the unit
105	#	Internal error contact sampling	
	0 Pressure switch-min		
	1 Pressure switch-max / POC		Can be caused by capacitive loads or supply of DC voltage to the mains voltage inputs. The diag-
	2 Fuel selection 0 / Reset		
	3 Air pressure		
	4 Load controller open		
	5 Load controller on / off		
	6 Load controller close	Stuck-At failure	
	7 Safety loop / Burner flange		nostic code indicates the input where the problem occurred
	8 Safety valve		
	9 Ignition transformer		
	10 Fuel valve 1		
	11 Fuel valve 2		
	12 Fuel valve 3		
	13 Fuel selection 1 / Reset		
106	#	Internal error contact request	Make a reset; if error occurs repeatedly, replace the unit
107	#	Internal error contact request	Make a reset; if error occurs repeatedly, replace the unit
108	#	Internal error contact request	Make a reset; if error occurs repeatedly, replace the unit
110	#	Internal error voltage monitor test	Make a reset; if error occurs repeatedly, replace the unit
111	#	Power failure	Mains voltage to low
	-	r ower failure	Exchange ratio diagnostics code \rightarrow voltage value (230 V: 1.683)
112	0	Mains voltage recovery	Error code for triggering a reset on power restoration (no error)
113	#	Internal error mains voltage supervision	Make a reset, if error occurs repeatedly, replace the unit
115	#	Internal error system counter	
116	0	Designed life time exceeded (250'000 startups)	Warning threshold has been reached. The unit should be replaced


Error code	Diagnostic code	Meaning for the LMV2x/3x system	Remedy
117	0	Life time exceeded Operation no longer allowed	Switch-off threshold has been reached
120	0	Interrupt limitation fuel meter input	Too many disturbance pulses at the fuel meters input \rightarrow Improve EMC
121	#	Internal error EEPROM access	Make a reset, repeat last parameterization / check. Restore the parameter set, if error occurs re- peatedly, replace the unit
122	#	Internal error EEPROM access	Make a reset, repeat last parameterization / check. Restore the parameter set, if error occurs re- peatedly, replace the unit
123	#	Internal error EEPROM access	Make a reset, repeat last parameterization / check. Restore the parameter set, if error occurs re- peatedly, replace the unit
124	#	Internal error EEPROM access	Make a reset, repeat last parameterization / check. Restore the parameter set, if error occurs re- peatedly, replace the unit
125	#	Internal error EEPROM read access	Make a reset, repeat last parameterization / check. If error occurs repeatedly, replace the unit
126	#	Internal error EEPROM write access	Make a reset, repeat last parameterization / check. If error occurs repeatedly, replace the unit
127	#	Internal error EEPROM access	Make a reset, repeat last parameterization / check. Restore the parameter set, if error occurs re- peatedly, replace the unit
128	0	Internal error EEPROM access - synchronization during initialization	Make a reset; if error occurs repeatedly, replace the unit
129	#	Internal error EEPROM access – command syn- chronization	Make a reset, repeat last parameterization / check. If error occurs repeatedly, replace the unit
130	#	Internal error EEPROM access - timeout	Make a reset, repeat last parameterization / check. If error occurs repeatedly, replace the unit
131	#	Internal error EEPROM access - page on abort	Make a reset, repeat last parameterization / check. If error occurs repeatedly, replace the unit
132	#	Internal error EEPROM register initialization	Make a reset; if error occurs repeatedly, replace the unit
133	#	Internal error EEPROM access – Request synchro- nization	Make a reset, repeat last parameterization / check. If error occurs repeatedly, replace the unit
134	#	Internal error EEPROM access – Request synchro- nization	Make a reset, repeat last parameterization / check. If error occurs repeatedly, replace the unit
135	#	Internal error EEPROM access – Request synchro- nization	Make a reset, repeat last parameterization / check. If error occurs repeatedly, replace the unit
136	1	Restore started	Restore of a backup has been started (no error)


Error code	Diagnostic code	Meaning for the LMV2x/3x system	Remedy
137	#	Internal error – backup / restore	
	157 (-99)	Restore – ok, but backup < data set of current system	Restore successful, but backup data record is smaller than in the current system
	239 (-17)	Backup – storage of backup in AZL2 faulty	Reset and repeat backup
	240 (-16)	Restore – no backup in AZL2	No backup stored in AZL2
	241 (-15)	Restore – abortion due to unsuitable product no. (ASN)	Backup has an unsuitable product no. (ASN) and must not be restored
	242 (-14)	Backup – backup made is inconsistent	Backup is faulty and cannot be transferred back
	243 (-13)	Backup – data comparison between µCs faulty	Reset and repeat backup
	244 (-12)	Backup data are incompatible	Backup data are incompatible with the current software version, restore not possible
	245 (-11)	Access error to parameter Restore_Complete	Reset and repeat backup
	246 (-10)	Restore – timeout when storing in EEPROM	Reset and repeat backup
	247 (-9)	Data received are inconsistent	Backup data record invalid, restore not possible
	248 (-8)	Restore cannot at present be made	Reset and repeat backup
	249 (-7)	Restore – abortion due to unsuitable burner identifica- tion	Backup has an unsuitable burner identification and must not be transferred to the unit
	250 (-6)	Backup – CRC of one page is not correct	Backup data record invalid, restore not possible
	251 (-5)	Backup – burner identification is not defined	Define burner identification and repeat backup
	252 (-4)	After restore, pages still on ABORT	Reset and repeat backup
	253 (-3)	Restore cannot at present be made	Reset and repeat backup
	254 (-2)	Abortion due to transmission error	Reset and repeat backup
	255 (-1)	Abortion due to timeout during backup / restore	Make a reset, check the connections and repeat backup / restore In case of repeated backup timeout, the AZL2 does not yet support backup functionality
146	#	Timeout building automation interface	Refer to Modbus User Documentation (A7541)
	1	Modbus timeout	
	2	reserved	

Error	Diagnostic code	Meaning for the LMV2x/3x system	Remedy
150	#	TÜV test	
	1 (-1)	Invalid phase	TÜV test may only be started in phase 60 (operation)
	2 (-2)	TÜV test default output too low	TÜV test default output must not be smaller than the lower output limit
	3 (-3)	TÜV test default output too high	TÜV test default output must not be greater than the upper output limit
	4 (-4)	Manual interruption	No error: Manual abortion of TÜV test by user
	5 (-5)	TÜV test timeout	 No loss of flame after shutdown of fuel valves Check to see if there is extraneous light Check wiring to see if there is a short-circuit Check to see if valve is leaking
165	#	Internal error	
166	0	Internal error watchdog reset	
167	#	Manual locking	Unit has been manually locked (no error)
	1	Manual locking by contact	
	2	Manual locking by AZL2	
	3	Manual locking by PC tool	
	8	Manual locking by the AZL2 Timeout / communication breakdown	During a curve adjustment via the AZL2, the timeout for menu operation has elapsed (setting via parameter 127), or communication between the LMV26 and the AZL2 has broken down
	9	Manual locking by the PC tool Communication breakdown	During a curve adjustment via the ACS410, communication between the LMV26 and the ACS410 was interrupted for more than 30 seconds
	33	Manual locking by the PC tool Test of lockout	PC tool made a reset attempt with an error-free system
168	#	Internal error management	Make a reset; if error occurs repeatedly, replace the unit
169	#	Internal error management	Make a reset; if error occurs repeatedly, replace the unit
170	#	Internal error management	Make a reset; if error occurs repeatedly, replace the unit
171	#	Internal error management	Make a reset; if error occurs repeatedly, replace the unit
200 OFF	#	System error-free	No error

Error code	Diagnostic code	Meaning for the LMV2x/3x system	Remedy
201 OFF UPr0 or OFF UPr1	#	Prevention of startup	Start prevention due to unparameterized unit Go to error history, entry 702, for initial cause of the error with shutdown in connection with the first curve settings
	Bit 0 Valency 1	No operating mode selected	
	Bit 1 Valency 23	No fuel train defined	
	Bit 2 Valency 47	No curves defined	
	Bit 3 Valency 815	Standardized speed undefined	
	Bit 4 Valency 1631	Backup / restore was not possible	
202	#	Internal error operating mode selection	Redefine the operating mode (parameter 201)
203	#	Internal error	Redefine the operating mode (parameter 201). Make a reset; if error occurs repeatedly, replace the unit
204	Phase number	Program stop	Program stop is active (no error)
205	#	Internal error	Make a reset; if error occurs repeatedly, replace the unit
206	0	Inadmissible combination of units (basic unit – AZL2)	
207	#	Version compatibility basic unit – AZL2	
	0	Basic unit version too old	
	1	AZL2 version too old	
208	#	Internal error	Make a reset; if error occurs repeatedly, replace the unit
209	#	Internal error	Make a reset; if error occurs repeatedly, replace the unit
210	0	Selected operating mode is not released for the basic unit	Select a released operating mode for the basic unit
240	#	Internal error	Make a reset; if error occurs repeatedly, replace the unit
245	#	Internal error	Make a reset; if error occurs repeatedly, replace the unit
250	#	Internal error	Make a reset; if error occurs repeatedly, replace the unit

WIRING DIAGRAM Wiring connection for LMV20





Air actuator

Fuel actuator

65


Wiring variants for LMV27

ConnectorX75




- 2 Fuel meter input
- 1 Supply fuel meter

ConnectorX5-02



Wiring variants for LMV26

ConnectorX08-04 / X09-04




1 - Fuel1

ConnectorX75




- 2 Fuel meter input
- 1 Supply fuel meter

ConnectorX64



- 5 -Power supply speed sensor
- 4 -Speed sensor input
- 3 PWM (Pulse Width Modulation) speed output
- 2 GND (signal reference)
- 1 -Controller input (4÷20mA)


ConnectorX74



- 5 -Supply
- 4 -Feedback signal
- 3 PWM (Pulse Width Modulation) speed output
- 2 GND (signal reference)
- 1 -External supply 24V DC

Wiring variants for LMV37


ConnectorX75




2 - Fuel meter input

1 - Supply fuel meter


ConnectorX5-02



ConnectorX64



ConnectorX74



- 5 -Power supply speed sensor
- 4 -Speed sensor input
- 3 PWM (Pulse Width Modulation) speed output
- 2 GND (signal reference)
- 1 -Controller input (4÷20mA)
- 5 -Supply
- 4 -Feedback signal
- 3 PWM (Pulse Width Modulation) speed output
- 2 GND (signal reference)
- 1 -External supply 24V DC



C.I.B. UNIGAS S.p.A. Via L.Galvani, 9 - 35011 Campodarsego (PD) - ITALY Tel. +39 049 9200944 - Fax +39 049 9200945/9201269 web site: www.cibunigas.it - e-mail: cibunigas@cibunigas.it

Note: Specifications and and data subject to change. Errors and omissions excepted.



CIB UNIGAS 600V

CONTROLLER



USER'S MANUAL

COD. M12925CA Rel 1.2 08/2014

SOFTWARE VERSION 1.0x T73 code 80379 / Edition 01 - 06/2012

1 · INSTALLATION

· Dimensions and cut-out; panel mounting





70

Panel mounting:

To fix the unit, insert the brackets provided into the seats on either side of the case. To mount two or more units side by side, respect the cut-out dimensions shown in the drawing.

CE MARKING: The instrument conforms to the European Directives 2004/108/CE and 2006/95/CE with reference to the generic standards: EN 61000-6-2 (immunity in industrial environment) EN 61000-6-3 (emission in residential environment) EN 61010-1 (safety).

MAINTENANCE: Repairs must be done only by trained and specialized personnel.

Cut power to the device before accessing internal parts.

Do not clean the case with hydrocarbon-based solvents (Petrol, Trichlorethylene, etc.). Use of these solvents can reduce the mechanical reliability of the device. Use a cloth dampened in ethyl alcohol or water to clean the external plastic case.

SERVICE: GEFRAN has a service department. The warranty excludes defects caused by any use not conforming to these instructions.

EMC conformity has been tested with the following connections

CABLE TYPE	LENGTH
1 mm ²	1 m
1 mm ²	3,5 m
0,8 mm ² compensated	5 m
1 mm ²	3 m
	1 mm ² 1 mm ² 0,8 mm ² compensated

2 · TECHNICAL SPECIFICATIONS

Display	2x4 digit green, high display 10 and 7mm
Keys	4 of mechanical type (Man/Aut, INC, DEC, F)
Accuracy	0.2% f.s. ±1 digit ambient temperature 25°C
Main input (settable digital filter)	TC, RTD, PTC, NTC 60mV,1V Ri≥1MΩ; 5V,10V Ri≥10KΩ; 20mA Ri=50Ω Tempo di campionamento 120 msec.
Type TC Thermocouples (ITS90)	Type TC Thermocouples : J,K,R,S,T (IEC 584-1, CEI EN 60584-1, 60584-2) ; custom linearization is available / types B,E,N,L GOST,U,G,D,C are available by using the custom linearization.
Cold junction error	0,1° / °C
RTD type (scale configurable within indicated range, with or without decimal point) (ITS90)	DIN 43760 (Pt100), JPT100 20Ω
Max line resistance for RTD PTC type / NTC Type	990Ω, 25°C / 1KΩ, 25°C
Safety	detection of short-circuit or opening of probes, LBA alarm
°C / °F selection	configurable from faceplate
Linear scale ranges	-1999 to 9999 with configurable decimal point position
Controls	PID, Self-tuning, on-off
pb - dt - it	0,0999,9 % - 0,0099,99 min - 0,0099,99 min
Action	Heat / Cool
Control outputs	on / off
Maximum power limit heat / cool	0,0100,0 %
Cycle time	0200 sec
Main output type	relay, logic, continuous (010V Rload \ge 250K Ω , 0/420mA Rload \le 500 Ω)
Softstart	0,0500,0 min
Fault power setting	-100,0100,0 %
Automatic blanking	Displays PV value, optional exclusion
Configurable alarms	Up to 3 alarm functions assignable to an output, configurable as: maximum, minimum, symmetrical, absolute/deviation, LBA
Alarm masking	 exclusion during warm up latching reset from faceplate or external contact
Type of relay contact	NO (NC), 5A, 250V/30Vdc cosφ=1
Logic output for static relays	24V ±10% (10V min at 20mA)
Transmitter power supply	15/24Vdc, max 30mA short-circuit protection
Power supply (switching type)	(std) 100 240Vac ±10% (opt.) 1127Vac/dc ±10%; 50/60Hz, 8VA max
Faceplate protection	IP65
Working / Storage temperature range	050°C / -2070°C
Relative humidity	20 85% non-condensing
Environmental conditions of use	for internal use only, altitude up to 2000m
Installation	Panel, plug-in from front
Weight	160g for the complete version



5 • "EASY" PROGRAMMING and CONFIGURATION



• Prot



12

6 • PROGRAMMING and CONFIGURATION



N.B.: Once a particular configuration is entered, all unnecessary parameters are no longer displayed

InFo Display



• CFG

	CFG	Control parameters				
						0.0.1
		Enabling	S.tun	Continuous autotuning	Sel-ftuning	Softstart
0	5.50	self-tuning,	0	NO	NO	NO
		autotuning,	1	YES	NO	NO
		softstart	2	NO	YES	NO
			3	YES	YES	NO
			4	NO	NO	YES
			5	YES	NO	YES
			6	-	-	-
			7			-
			S.tun	Autotuning	Selftuning	Softstart
				one shot		
			8*	WAIT	NO	NO
			9	GO	NO	NO
			10*	WAIT	YES	NO
			11	GO	YES	NO
			12*	WAIT	NO	YES
			13	GO	NO	YES
		*) +16 with passa +32 with passa +64 with passa +128 with passa	age auto age auto	omatic rifle in C omatic rifle in C	GO if PV-SP	> 0,5% > 1% > 2% > 4%
1.2	h.₽b ↓	Proportional heating or hys regulation O	teresis i		9.9% f.s.	
5.83	h. 12	Integral time fo	or heatin	lg 0.00 9	99.99 min	
1.33	h.db	Derivative ti heatin		0.00 9	99.99 min	
	4			_		
100.0	hPH	Maximum power limit for 0.0 100.0%				
	↓ · · · · · · · · · · · · · · · · · · ·					
0.0	hPL	Minimum pov for heati (not available for o cool actio	i ng double he	0.0	100.0%	
	¥		-	Y		







For custom linearization:

0...60 mV

12...60 mV

12...60 mV

0...20 mA 0...20 mA

4...20 mA

4...20 mA

0...10 V

0...10 V

2...10 V

2...10 V 0...5 V

0...5 V 1...5 V 1...5 V

0...1 V

0...1 V

200mv..1V

200mv..1V Cust10 V-20mA

Cust10 V-20mA

Cust 60mV

Cust 60mV

PT100-JPT

PTC

NTC

39

40

41

42

43

44

45

46

47

48

49

50

51 52

53

54

55

56

57

58

59

60

61

62 63

64

- LO signal is generated with variable below Lo.S or at minimum calibration value

Custom scale

-1999/9999

Custom scale

CUSTOM

CUSTOM

CUSTOM

Custom scale

-199.9/999.9

Custom scale

-199.9/999.9 Custom scale

-199.9/999.9

Custom scale

-199.9/999.9

Custom scale

-199.9/999.9

Custom scale

-199.9/999.9

Custom scale -199.9/999.9

Custom scale

-199.9/999.9

Custom scale

-199.9/999.9

Custom scale

-199.9/999.9

Custom scale

-199.9/999.9

Custom scale

CUSTOM

CUSTOM

CUSTOM

- HI signal is generated with variable above Lo.S or at maximum calibration value

• Out



• Prot

12

Pro Protection code Prot Display Modification SP, Hy.P, Hy.n, AL.2, AL.3, PoS, OuP, INF SP, Hy.P , Hy.n, AL.2, AL.3, PoS 0 1 SP, Hy.P, Hy.n, AL.2, AL.3, PoS, OuP, INF SP 2 SP, OuP, INF + 4 to disable InP, Out + 8 to disable CFG + 8 to disable Grd + 16 to disable SW "power-up - power down" + 32 disable manual power latching + 64 to disable manual power modification

+128 enables full configuration

Note: OuP and INF only display configuration extended

• Hrd





• Lin



• U.CAL



7 · CONSENT FOR BURNER AL1



Obtain burner consent by configuring alarm 1 as inverse deviation with positive hysteresis Hy.P and negative hysteresis Hy.n

8 • PRE-HEATING FUNCTION

Enable the pre-heating function by setting parameters GS.0, Ht.0, GS.1 other than zero.

It consists of three phases that are activated sequentially at firing:

- Ramp 0 phase

Enabled by setting GS.0 > 0. Starting from setpoint = PV (initial state), it reaches pre-heating set SP.0 with gradient GS.0 - Maintenance phase

- Enabled by setting Ht.0 > 0. Maintains pre-heating setpoint SP.0 for time Ht.0
- Ramp 1 phase

Enabled by setting GS.1 > 0. Starting from pre-heating setpoint SP.0, it reaches active _SP set with gradient GS.1

In case of selftuning, the pre-heating function is not activated



9 · ADJUSTMENT WITH MOTORIZED VALVE

In an adjustment process the adjustment valve has the function of varying fuel delivery (frequently corresponding to the thermal energy introduced into the process) in relation to the signal coming from the controller.

For this purpose it is provided with an actuator able to modify its opening value, overcoming the resistances produced by the fluid passing inside it.

The adjustment valves vary the delivery in a modulated manner, producing finite variations in the fluid passage inner area corresponding to finite variations of the actuator input signal, coming from the controller. The servomechanism, for example, comprises an electric motor, a reducer and a mechanical transmission system which actions the valve.

Various auxiliary components can be present such as the mechanical and electrical safety end travels, manual actioning systems.



CONTROL EXAMPLE FOR V0 VALVE

The controller determines, on the basis of the dynamics of the process, the control output for the valve corresponding to the opening of the same in such a way so as to maintain the desired value of the process variable.

Characteristic parameters for valves control

- Actuator time (Ac.t) is the time employed by the valve to pass from entirely open to entirely closed (or vice-versa), and can be set with a resolution of one second. It is a mechanical feature of the valve+actuator unit.

NOTE: if the actuator's travel is mechanically limited it is necessary to proportionally reduce the Ac.t value.

- Minimum impulse (t.Lo) expressed as a % of the actuator time (resolution 0.1%).

Represents the minimum change in position corresponding to a minimum change in power supplied by the instrument below which the actuator will not physically respond to the command.

This represents the minimum variation in position due to which the actuator does not physically respond to the command.

The minimum duration of the movement can be set in t.Lo, expressed as a % of actuator time.

- Impulsive intervention threshold (t.Hi) expressed as a % of the actuator time (resolution 0.1%) represents the position displacement (requested position – real position) due to which the manoeuvre request becomes impulsive.

You can choose between 2 types of control:

1) ON time of movement = t.on and OFF time proportional to shift and greater than or equal to t.Lo (we recommend setting t.on = t.Lo) (set t.oF = 0).

2) ON time of movement = t.on and OFF time = t.oF. A value set for t.oF < t.on is forced to t.on. To activate this type, set t.oF <> 0.

The type of movement approach allows fine control of the reverse drive valve (from potentiometer or not), especially useful in cases of high mechanical inertia. Set t.Hi = 0 to exclude modulation in positioning.

This type of modulated approach allows precise control of the feedback actioned valve, by a potentiometer or not, and is especially useful in cases of high mechanical inertia. Setting t.Hi = 0 excludes modulation in positioning.

- Dead zone(dE.b) is a displacement band between the adjustment setpoint and the process variable within which the controller does not supply any command to the valve (Open = OFF; Close = OFF). It is expressed as a percentage of the bottom scale and is positioned below the setpoint. The dead zone is useful in an operative process to avoid straining the actuator with repeated commands and an insignificant effect on the adjustment. Setting dE.b = 0 the dead zone is excluded.



Graph of behavior inside the band with integral time $\neq 0$.

With integral time = 0, movement ON time is always equal to OFF time.

t0 = t.Lo

Valve control modes

With the controller in manual, the setting of parameter At.y ≥ 8 allows direct control of the valve open and close commands through the keyboard Increments and Decrements on the front seats.

V0 - for floating valve without potentiometer

Model V0 have similar behaviour: every manoeuvre request greater than the minimum impulse t.Lo is sent to the actuator by means of the OPEN/CLOSE relays; every action updates the presumed position of the virtual potentiometer calculated on the basis of the actuator travel declared time. In this way there is always a presumed position of the valve which is compared with the position request of the controller.

Having reached a presumed extreme position (entirely open or entirely closed determined by the "virtual potentiometer") the controller provides a command in the same direction, in this way ensuring the real extreme position is reached (minimum command time = t.on).

The actuators are usually protected against the OPEN command in the entirely open position or CLOSE command in the entirely closed position.

V3 - for floating valve, PI control

When the difference between the position calculated by the controller and the only proportional component exceeds the value corresponding to the minimum impulse t.Lo the controller provides an OPEN or CLOSE command of the duration of the minimum impulse itself t.Lo. At each delivery the integral component of the command is set to zero (discharge of the integral).

The frequency and duration of the impulses is correlated to the integral time (h.it or c.it).

Non-movement behavior

t.Hi = 0: with power = 100% or 0.0%, the corresponding open or close outputs always remain enabled (safety status).

Movement behavior

t.Hi <> 0: with position attained corresponding to 100% or 0.0%, the corresponding open or close outputs are switched off.



If t.oF = 0, current function is maintained.

If t.oF \neq 0 movement mode will be as shown on the graph

10 · CONTROL ACTIONS

Proportional Action:

action in which contribution to output is proportional to deviation at input (deviation = difference between controlled variable and setpoint). *Derivative Action*:

action in which contribution to output is proportional to rate of variation input deviation. Integral Action:

Integral Action.

action in which contribution to output is proportional to integral of time of input deviation.

Influence of Proportional, Derivative and Integral actions on response of process under control

* An increase in P.B. reduces oscillations but increases deviation.

* A reduction in P.B. reduces the deviation but provokes oscillations of the controlled variable (the system tends to be unstable if P.B. value is too low).

* An increase in Derivative Action corresponds to an increase in Derivative Time, reduces deviation and prevents oscillation up to a critical value of Derivative Time, beyond which deviation increases and prolonged oscillations occur.

* An increase in Integral Action corresponds to a reduction in Integral Time, and tends to eliminate deviation between the controlled variable and the setpoint when the system is running at rated speed.

If the Integral Time value is too long (Weak integral action), deviation between the controlled variable and the setpoint may persist.

Contact GEFRAN for more information on control actions.

11 • MANUAL TUNING

A) Enter the setpoint at its working value.

B) Set the proportional band at 0.1% (with on-off type setting).

C) Switch to automatic and observe the behavior of the variable. It will be similar to that in the figure:



D) The PID parameters are calculated s follows: Proportional band

Peak P.B.= ----- x 100 (V max - V min)

(V max - V min) is the scale range.

Integral time: It = 1.5 x T

Derivative time: dt = It/4

E) Switch the unit to manual, set the calculated parameters. Return to PID action by setting the appropriate relay output cycle time, and switch back to Automatic. F) If possible, to optimize parameters, change the setpoint and check temporary response. If an oscillation persists, increase the proportional band. If the response is too slow, reduce

it.

12 · SET GRADIENT

SET GRADIENT: if set to ≠0, the setpoint is assumed equal to PV at power-on and auto/man switchover. With gradient set, it reaches the local setpoint. Every variation in setpoint is subject to a gradient.

The set gradient is inhibited at power-on when self-tuning is engaged.

If the set gradient is set to $\neq 0$, it is active even with variations of the local setpoint.

The control setpoint reaches the set value at the speed defined by the gradient.

13 · SOFTWARE ON / OFF SWITCHING FUNCTION

How to switch the unit OFF: hold down the "F" and "Raise" keys simultaneously for 5 seconds to deactivate the unit, which will go to the OFF state while keeping the line supply connected and keeping the process value displayed. The SV display is OFF.

All outputs (alarms and controls) are OFF (logic level 0, relays de-energized) and all unit functions are disabled except the switch-on function and digital communication.

How to switch the unit ON: hold down the "F" key for 5 seconds and the unit will switch OFF to ON. If there is a power failure during the OFF state, the unit will remain in OFF state at the next power-up (ON/OFF state is memorized).

The function is normally enabled, but can be disabled by setting the parameter Prot = Prot +16.

14 · SELF-TUNING

The function works for single output systems (heating or cooling). The self-tuning action calculates optimum control parameter values during process startup. The variable (for example, temperature) must be that assumed at zero power (room temperature).

The controller supplies maximum power until an intermediate value between starting value and setpoint is reached, after which it zeros power.

PID parameters are calculated by measuring overshoot and the time needed to reach peak. When calculations are finished, the system disables automatically and the control proceeds until the setpoint is reached.

How to activate self-tuning:

- A. Activation at power-on
- 1. Set the setpoint to the required value
- 2. Enable selftuning by setting the Stun parameter to 2 (CFG menu)
- 3. Turn off the instrument
- 4. Make sure the temperature is near room temperature
- 5. Turn on the instrument again
- B. Activation from keyboard
- 1. Make sure that key M/A is enabled for Start/Stop selftuning (code but = 6 Hrd menu)
- 2. Bring the temperature near room temperature
- 3. Set the setpoint to the required value
- 4. Press key M/A to activate selftuning (Attention: selftuning interrupts if the key is pressed again)

The procedure runs automatically until finished, when the new PID parameters are stored: proportional band, integral and derivative times calculated for the active action (heating or cooling). In case of double action (heating or cooling), parameters for the opposite action are calculated by maintaining the initial ratio between parameters (ex.: CPb = HPb * K; where K = CPb / HPb when self-tuning starts). When finished, the Stun code is automatically cancelled.

Notes :

-The procedure does not start if the temperature is higher than the setpoint (heating control mode) or if the temperature is lower than the setpoint (cooling control mode). In this case, the Stu code is not cancelled.

-It is advisable to eneable one of the configurable LEDs to signal selftuning status.By setting one of parameters

LED1, LED2, LED3=4 or 20 on the Hrd menu, the respective LED will be on or flashing when selftuning is active.



15 · ACCESSORIES

Interface for instrument configuration



• WARNINGS

WARNING: this symbol indicates danger. It is placed near the power supply circuit and near high-voltage relay contacts.

Read the following warnings before installing, connecting or using the device:

UTPUT 2

UTPUT 3

· follow instructions precisely when connecting the device.

Relay

Relav

· always use cables that are suitable for the voltage and current levels indicated in the technical specifications.

R

R

• the device has no ON/OFF switch: it switches on immediately when power is turned on. For safety reasons, devices permanently connected to the power supply require a twophase disconnecting switch with proper marking. Such switch must be located near the device and must be easily reachable by the user. A single switch can control several units.

• if the device is connected to electrically NON-ISOLATED equipment (e.g. thermocouples), a grounding wire must be applied to assure that this connection is not made directly through the machine structure.

• if the device is used in applications where there is risk of injury to persons and/or damage to machines or materials, it MUST be used with auxiliary alarm units. You should be able to check the correct operation of such units during normal operation of the device.

• before using the device, the user must check that all device parameters are correctly set in order to avoid injury to persons and/or damage to property.

• the device must NOT be used in infiammable or explosive environments. It may be connected to units operating in such environments only by means of suitable interfaces in conformity to local safety regulations.

• the device contains components that are sensitive to static electrical discharges. Therefore, take appropriate precautions when handling electronic circuit boards in order to prevent permanent damage to these components.

Installation: installation category II, pollution level 2, double isolation

The equipment is intended for permanent indoor installations within their own enclosure or panel mounted enclosing the rear housing and exposed terminals on the back.

• only for low power supply: supply from Class 2 or low voltage limited energy source

• power supply lines must be separated from device input and output lines; always check that the supply voltage matches the voltage indicated on the device label.

• install the instrumentation separately from the relays and power switching devices

• do not install high-power remote switches, contactors, relays, thyristor power units (particularly if "phase angle" type), motors, etc... in the same cabinet.

· avoid dust, humidity, corrosive gases and heat sources.

· do not close the ventilation holes; working temperature must be in the range of 0...50°C.

surrounding air: 50°C

• use 60/75°C copper (Cu) conductor only, wire size range 2x No 22 - 14AWG, Solid/Stranded

• use terminal tightening torque 0.5N m

If the device has faston terminals, they must be protected and isolated; if the device has screw terminals, wires should be attached at least in pairs.

• Power: supplied from a disconnecting switch with fuse for the device section; path of wires from switch to devices should be as straight as possible; the same supply should not be used to power relays, contactors, solenoid valves, etc.; if the voltage waveform is strongly distorted by thyristor switching units or by electric motors, it is recommended that an isolation transformer be used only for the devices, connecting the screen to ground; it is important for the electrical system to have a good ground connection; voltage between neutral and ground must not exceed 1V and resistance must be less than 60hm; if the supply voltage is highly variable, use a voltage stabilizer for the device; use line filters in the vicinity of high frequency generators or arc welders; power supply lines must be separated from device input and output lines; always check that the supply voltage matches the voltage indicated on the device label.

• Input and output connections: external connected circuits must have double insulation; to connect analog inputs (TC, RTD) you have to: physically separate input wiring from power supply wiring, from output wiring, and from power connections; use twisted and screened cables, with screen connected to ground at only one point; to connect adjustment and alarm outputs (contactors, solenoid valves, motors, fans, etc.), install RC groups (resistor and capacitor in series) in parallel with inductive loads that work in AC (*Note: all capacitors must conform to VDE standards (class x2) and support at least 220 VAC. Resistors must be at least 2W*); fit a 1N4007 diode in parallel with the coil of inductive loads that operate in DC.

GEFRAN spa will not be held liable for any injury to persons and/or damage to property deriving from tampering, from any incorrect or erroneous use, or from any use not conforming to the device specifications.

Set-up for 600V RRR0-1-T73 regulator

Set up for temperature probe Pt100 (ex Siemens QAE2120 130°C max.)

The regulator comes out of the factory preset with the corresponding values of the Siemens RWF40.000 and RWF50.2x

Verify wiring of the sensor



Regulation of the set-point = 80It can be modified by using arrows "up" and "down". By pushing **F** you go to parameters:

Hy.P	5 (hysteresis positive for output 1, terminals 21-22 (ex Q13-Q14)
Hy.n	-5 hysteresis negative for output ,1 terminals 21-22 (ex Q13-Q14)

Keep pushing F until you see PASS, release F and through the arrows set 99, push F and visualize Pro (protection code) default is 12, through the arrows set 128 and push F, keep it pushed until all parameters InF, CFG, InP, Out, PASS are visualized.

CFG		
S.tun hPb hlt hdt	0	
hPb	1,2	
hlt	5,83	
hdt	1,33	

InP	
tyP	30 (Pt100)
dP_S	1 (decimals num.)
Lo.S	0 (min. sensor scale)
Hi.S	850,0 (max sensor scale)
oFS	0 (offset of input correction)
Lo.L	30,0 (lower set-point range limit)
Hi.L	130,0 (upper set-point range limit)

0
3 (operating mode AL1 =inverse-relative-normal)
2 (AL1)
18 (open)
19 (close)
0
9 (type of servocontrol command)
12 (servocontrol running time: SQN72.4/STA12=12; SQM40.265=30)
2
0.0
2
0.0
0,1 (dead zone in % of end scale)

PAS	99 then push and keep pushed F until visualization of Hrd
Hrd	
CtrL	6 (PID warm)
AL.nr	1
but	1
diSP	0
Ld.1	1
Ld.2	28
Ld.3	20

Keep pushed F until you visualize **PASS**, release F and through the arrows set **99**, push F and visualize **Pro** (protection code) from **128**, through the arrows, bring it back to **12**, and keep F pushed until you come back to set-point value.

Manual operation :

Keep pushed the lower left key for at least 5 sec.

The instrument will enter the "MAN" mode (see also "Ld1" switching on).

Through the arrows, "Open" and "Close" outputs are activated.

To come back to normal working keep the lower left key pushed for at least 5 sec.

Software switch off :

By keeping pushed keys **Arrow up** + **F** for more than 5 sec. the instrument switches off the software, does not command the outputs and visualize only the variable of process measured by the probe. To restore keep pushed **F** for more than 5 sec.

Set up for temperature probe Pt100 for high temperature (350°C max.)

Verify wiring of the sensor



Regulation of the set-point = 80

It can be modified by using arrows "up" and "down".

By pushing F you go to parameters	
Hy.P	10 (hysteresis positive for output 1 terminals 21-22 (ex Q13-Q14)
Hy.n	-5 (hysteresis negative for output 1 terminals 21-22 (ex Q13-Q14)

Keep pushing F until you see PASS, release F and through the arrows set 99, push F and visualize Pro (protection code) default is 12, through the arrows set 128 and push F, keep it pushed until all parameters InF, CFG, InP, Out, PASS are visualized.

CFG S.tun hPb hIt	
S.tun	0
hPb	1,2
hlt	5,83
hdt	1,33

InP	
tyP	30 (Pt100)
dP_S	1 (decimals num.)
Lo.S	0 (min. sensor scale)
Hi.S	850,0 (max sensor scale)
oFS	0 (offset of input correction)
Lo.L	0,0 (lower set-point range limit)
Hi.L	350,0 (upper set-point range limit)

Out	
A1.r	0
A1.t	3 (mode AL1 =inverse-relative-normal)
rL.1	2 (AL1)
rL.2	18 (open)
rL.3	19 (close)
rEL	0
A.ty	9 (type of servocontrol command)
Ac.t	12 (servocontrol running time: SQN72.4/STA12=12; SQM40.265=30)
t_Lo	2
t_Hi	0.0
t.on	2
t.oF	0.0
dE.b	0,1 (dead zone in % of end scale)

PAS	99 then push and keep pushed F until visualization of Hrd
Hrd	
CtrL	6 (PID warm)
AL.nr	1
but	1
diSP	0
Ld.1	1
Ld.2	28
Ld.3	20

Keep pushed F until you visualize PASS, release F and through the arrows set 99, push F and visualize Pro (protection code) from 128, through the arrows, bring it back to 12, and keep F pushed until you come back to set-point value.

Manual operation:

Keep pushed the lower left key for at least 5 sec.

The instrument will enter the "MAN" mode (see also "Ld1" switching on). Through the arrows, "Open" and "Close" outputs are activated.

To come back to normal working keep the lower left key pushed for at least 5 sec.

Software switch off :

By keeping pushed keys Arrow up + F for more than 5 sec. the instrument switches off the software, does not command the outputs and visualize only the variable of process measured by the probe. To restore keep pushed **F** for more than 5 sec.

Set up for pressure transmitter 2 wires signal 4+20mA



With pressure transmitters first we need to enable their power supply: remove the part as shown below, then, on the CPU unit, move the bridge from Pt100 to +Vt



Verify wiring of the sensor

Impostazione set-point

Transmitter	1,6bar	3bar	10bar	16bar	25bar	40bar
Set-point	1bar	1,5bar	6bar	6bar	6bar	6bar

To modify it directly use "up" and "down" arrows.

By pushing F you go to parameter:						
Transmitter	1,6bar	3bar	10bar	16bar	25bar	40bar
Hy.P	0,2bar	0,5bar	0,5bar	0,8bar	1,25bar	2bar
Hy.n	0bar	0bar	0bar	0bar	0bar	0bar

Keep pushing **F** until you see **PASS**, release **F** and through the arrows set **99**, push **F** and visualize **Pro** (protection code) default is **12**, through the arrows set **128** and push **F**, keep it pushed until all parameters **InF**, **CFG**, **InP**, **Out**, **PASS** are visualized.

CFG S.tun	
S.tun	0
hPb	5
hPb hIt hdt	1,33
hdt	0,33

InP			
tyP	44 (4÷20mA)		
dP_S	2 (decimals num.)		

Transmitter	1,6bar	3bar	10bar	16bar	25bar	40bar		
Lo.S	0,00	0,00	0,00	0,00	0,00	0,00	min. sensor scale	
Hi.S	1,60	3,00	10,00	16,00	25,00	40,00	max sensor scale	
oFS	0	0	0	0	0	0	offset of input correction	
Lo.L	0,00	0,00	0,00	0,00	0,00	0,00	lower set-point setting	
Hi.L	1,60	3,00	10,00	16,00	25,00	40,00	upper set-point setting	

Out	
A1.r	0
A1.t	3 (mode AL1 =inverse-relative-normal)
rL.1	2 (AL1)
rL.2	18 (open)
rL.3	19 (close)
rEL	0
A.ty	9 (type of servocontrol command)
Ac.t	12 (servocontrol running time: SQN72.4/STA12=12; SQM40.265=30)
t_Lo	2
t_Hi	0.0
t.on	2
t.oF	0.0
dE.b	0,1 (dead zone in % of end scale)

PAS	99 then push and keep pushed F until visualization of Hrd			
Hrd				
CtrL	6 (PID warm)			
AL.nr	1			
but	1			
diSP	0			
Ld.1	1			
Ld.2	28			
Ld.3	20			

Keep pushed F until you visualize **PASS**, release F and through the arrows set **99**, push F and visualize **Pro** (protection code) from **128**, through the arrows, bring it back to **12**, and keep F pushed until you come back to set-point value.

Manual operation:

Keep pushed the lower left key for at least 5 sec.

The instrument will enter the "MAN" mode (see also "Ld1" switching on).

Through the arrows, "Open" and "Close" outputs are activated.

To come back to normal working keep the lower left key pushed for at least 5 sec.

Software switch off :

By keeping pushed keys **Arrow up** + **F** for more than 5 sec. the instrument switches off the software, does not command the outputs and visualize only the variable of process measured by the probe. To restore keep pushed **F** for more than 5 sec.

Verify wiring of the sensor



Regulation of the set-point = 80

It can be modified by using arrows "up" and "down".

By pushing F you go to parameters:	
Hy.P	10 (hysteresis positive for output 1 terminals 21-22 (ex Q13-Q14)
Hy.n	-5 (hysteresis negative for output 1 terminals 21-22 (ex Q13-Q14)

Keep pushing F until you see **PASS**, release F and through the arrows set **99**, push F and visualize **Pro** (protection code) default is **12**, through the arrows set **128** and push F, keep it pushed until all parameters **InF**, **CFG**, **InP**, **Out**, **PASS** are visualized.

CFG		
S.tun hPb	0	
hPb	1,2	
hlt	5,83	
hdt	1,33	

InP		
tyP	2 (thermocouple K 0÷1300°C) / 0 (thermocouple J 0÷1000°C)	
dP_S Lo.S	0 (no decimal) / 1 (1 decimal)	
Lo.S	0 (min. sensor scale)	
Hi.S	1300 (max sensor scale for tc K) / 1000 (max sensor scale for tc J)	
oFS	0 (offset of input correction)	
Lo.L	0 (lower set-point range limit)	
Hi.L	1300 (upper set-point range limit) per tc K / 1000 for tc J	

Out		
A1.r	0	
A1.t	3 (mode AL1 =inverse-relative-normal)	
rL.1	2 (AL1)	
rL.2	18 (open)	
rL.3	19 (close)	
rEL	0	
A.ty	9 (type of servocontrol command)	
Ac.t	12 (servocontrol running time: SQN72.4/STA12=12; SQM40.265=30)	
t_Lo	2	
t_Hi	0.0	
t.on	2	
t.oF	0.0	
dE.b	0,1 (dead zone in % of end scale)	

PAS	99 then push and keep pushed F until visualization of Hrd		
Hrd			
CtrL	6 (PID warm)		
AL.nr	1		
but	1		
diSP	0		
Ld.1	1		
Ld.2	28		
Ld.3	20		

Keep pushed F until you visualize **PASS**, release F and through the arrows set **99**, push F and visualize **Pro** (protection code) from **128**, through the arrows, bring it back to **12**, and keep F pushed until you come back to set-point value.

Manual operation:

Keep pushed the lower left key for at least 5 sec. The instrument will enter the "MAN" mode (see also "Ld1" switching on). Through the arrows, "Open" and "Close" outputs are activated. To come back to normal working keep the lower left key pushed for at least 5 sec.

Software switch off :

By keeping pushed keys **Arrow up** + **F** for more than 5 sec. the instrument switches off the software, does not command the outputs and visualize only the variable of process measured by the probe. To restore keep pushed **F** for more than 5 sec.


RWF50.2x & RWF50.3x




User manual


M12922CB Rel.1.0 05/2024

DEVICE INSTALLATION Install the device using the relevant tools as shown in the figure. To wire the device and sensors, follow the instructions on the burner wiring diagram.






FRONT PANEL



NAVIGATION MENU



RWF5 is preset good for 90% of applications. However, you can set or edit parameters as follow:

Set-point: set or modification:

When the burner is in stand-by, (safety loop open, that is terminals 3-4/T1-T2 on the 7 pole plug open) push the **Enter** button: on the lower display (green) **Opr** appears; push **Enter** again and in the same display **SP1** appears. Push **Enter** again and the lower display (green **SP1**) flashes. Using the **up and down arrows** change the set-point on the upper display (red).Push **Enter** to confirm and push **ESC** more times to get the home position.

PID parameters set and modifications (see table below):

- Push Enter button, on the green display **Opr** appears; using the **down arrow**, scroll until group **PArA** is reached and push Enter.
- on the green display Pb1 e appears and on the red one the set parameter.
- Push is sequence the down or up arrow the menu is scrolled.
- Push Enter to select and the arrows to choose the desired value. Enter to confirm.

Parameter	Display	Range	Factory setting	Remarks
Proportional band	PB.1	1 9999 digit	10	Typical value for temperature
Derivative action	dt	0 9999 sec.	80	Typical value for temperature
Integral action	rt	0 9999 sec.	350	Typical value for temperature
Dead band (*)	db	0 999,9 digit	1	Typical value
Servocontrol running time	tt	10 3000 sec.	15	Set servocontrol running time
Switch-on differential (*)	HYS1	0,01999 digit	-5	Value under setpoint below which the burner switches back on (1N-1P closes)
Switch-off differential 2° stage (*)	HYS2	0,0 HYS3	3	(enable only with parameter bin1 = 4)
Upper switch-off differential (*)	HYS3	0,0… 9999 digit	5	Value over setpoint above which the burner switches off (1N-1P opens)
Switch-on differential on cooling controller (*)	HYS4	0,0 9999 digit	5	Do not used (enable only with parameter CACt = 0)
Switch-off differential 2° stage on cooling controller (*)	HYS5	HYS60,0 digit	5	Do not used (enable only with parameters CACt = 0 and bin1 = 4)
Upper switch-off differential on cooling controller (*)	HYS6	0,01999 digit	5	Do not used (enable only with parameter CACt = 0)
Delay modulation	q	0,0 999,9 digit	0	Do not alter

(*)Parameters affected by setting of decimal place (**ConF > dISP** parameter **dECP**)

Setting the kind of sensor to be connected to the device:

- push the Enter button: on the lower display (green) **Opr** appears. Using the **up and down arrows** find **ConF.** Push Enter to confirm.
- Now on the green display the group InP appears. Push Enter and InP1 is displaied. Enter to confirm.
- You are inside InP1; the green display shows Sen1 (sensor type), while the red display shows the chosen sensor code
- Push Enter to enter the Sen1 parameter, then choose the desired sensor using the arrows. Push Enter to confirm and ESC to escape.
- Once selected the sensor, you can modify all the other parameters using **up and down arrows** according to the tables here below.

Parameter	Value	Description
SEn1	1	Pt100 3 fili
type of sensor for	2	Pt100 2 fili
analog input 1	3	Pt1000 3 fili
	4	Pt1000 2 fili
	5	Ni1000 3 fili
	6	Ni1000 2 fili
	7	0 ÷ 135 ohm
	15	0 ÷ 20mA
	16	4 ÷ 20mA
	17	0 ÷ 10V
	18	0 ÷ 5V
	19	1 ÷ 5V
OFF1		Using the measured value correction (offset), a measured
sensor offset	-1999 0 +9999	value can be corrected to a certain degree, either up or down
SCL1		In the case of a measuring transducer with standard signal, the
scale low level		physical signal is assigned a display value here
	-1999 0 +9999	(for input ohm, mA, V)
SCH1		In the case of a measuring transducer with standard signal, the
scale high level		physical signal is assigned a display value here
	-1999 100 +9999	(for input ohm, mA, V)
dF1		Is used to adapt the digital 2nd order input filter
digital filter	0 0,6 100	(time in s; 0 s = filter off)
Unit	1	1 = degrees Celsius
temperature unit	2	2 = degrees Fahrenheit

ConF > InP >InP1

(**bold** = factory settings)

Remark:

RWF50.2 e RWF50.3 cannot be connected to thermocouples.

If thermocouples have to be connected, convert the signal to a 4-20 mA one and set the RWF accordingly.

ConF > Cntr

Parameter	Value	Description
CtYP	1	1 = 3-position controller (open-stop-close only RWF50.2)
controller type	2	2 = continuative action controller (only RWF50.3)
CACt	1	1 = heating controller
control action	0	0 = cooling controller
SPL		
least value of the		set-point limitation prevents entry of values outside the defined
set-point range	-1999 0 +9999	range
SPH		
maximum value of the		set-point limitation prevents entry of values outside the defined
set-point range	-1999 100 +9999	range
oLLo		
set-point limitation		
start, operation limit		
low	-1999 +9999	lower working range limit
oLHi		
set-point limitation		
end, operation limit		
high	-1999 +9999	upper working range limit

(**bold** = factory settings)

ConF > rAFC

Activation boiler shock te RWF50 can activate the th		only on sites where the set-point is lower than 250°C and according
to rAL parameter.		
Parameter	Value	Description
FnCT		Choose type of range degrees/time
function	0	0 = deactivated
	1	1 = Kelvin degrees/minute
	2	2 = Kelvin degrees/hour
rASL		Slope of thermal shock protection (only with functions 1 and 2)
ramp rate	0,0 999,9	
toLP tolerance band ramp	0 9999	width of tolerance band (in K) about the set-point 0 = tolerance band inactive 40 40 TRE6416/0911
rAL ramp limit	0 250	Ramp limit. When this value is lower than the temperature set- point, the RWF controls the output increasing the temp set point step by step according to rASL. If this is over the temp set point, the control is performed in cooling.

(**bold** = factory settings)

ConF > OutP (parameter under group only for RWF50.3)

Parameter	Value	Description
FnCt		1 = analog input 1 doubling with possibility to convert
tipo di controllo	1	(depending on par SiGn)
-	4	4 = modulation controller
SiGn		physical output signal (terminals A+, A-)
type of output signal	0	0 = 0÷20mA
	1	1 = 4÷20mA
	2	2 = 0÷10V
rOut		
Value when out of		
input range	0 101	signal (in percent) when measurement range is crossed
oPnt		value range of the output variable is assigned to a physical
zero point		output signal Per default, the setting corresponds to 0100%
		angular positioning for the controller outputs (terminals A+, A-)
	-1999 0 +9999	(effective only with FnCt = 1)
End		value range of the output variable is assigned to a physical
End value		output signal Per default, the setting corresponds to 0100%
		angular positioning for the controller outputs (terminals A+, A-)
	-1999 100 +9999	(effective only with FnCt = 1)

(**bold** = factory settings)

ConF > binF

Parameter	Value	Description
bin1		0 = without function
digital inputs		1 = set-point changeover (SP1 / SP2)
(terminals DG - D1)		2 = set-point shift (Opr > dSP parameter = value of set-point
	0	modify)
	1	4 = changeover of operating mode
	2	open – modulating operation;
	4	close – 2 stage operation.

(**bold** = factory settings)

ConF > dISP

Parameter	Value	Description
diSU		display value for upper display:
upper display	0	0 = display power-off
(red)	1	1 = analog input value
	4	4 = Controller's angular positioning
	6	6 = set-point value
	7	7 = end value with thermal shock protection
diSL		display value for lower display:
lower display	0	0 = display power-off
(green)	1	1 = analog input value
	4	4 = Controller's angular positioning
	6	6 = set-point value
	7	7 = end value with thermal shock protection
tout		time (s) on completion of which the controller returns
timeout	0 180 250	automatically to the basic display, if no button is pressed
dECP	0	0 = no decimal place
decimal point	1	1 = one decimal place
	2	2 = two decimal places
CodE	0	0 = no lockout
level lockout	1	1 = configuration level lockout (ConF)
	2	2 = Parameter and configuration level lockout (PArA & ConF)
	3	3 = keyboard lockout


(**bold** = factory settings)

Manual control :


- in order to manual change the burner load, while firing keep pushing the **ESC** button for more than 5 s; on the lower green display **Hand** appears.
- using the UP and DOWN arrows, the load varies.
- Keep pushing the ESC button for getting the normal operation again.
- NB: every ime the device shuts the burner down (start led switched off contact 1N-1P open), the manual control is not active.

Device self-setting (auto-tuning):

If the burner in the steady state does not respond properly to heat generator requests, you can activate the Device's self-setting function, which recalculates PID values for its operation, deciding which are most suitable for the specific kind of request




Display of software version :



The software version is shown by pushing **Enter + UP arrow** on the upper display

Electric connection :



Matches terminals between RWF50.2 and RWF40.0x0

, ка	к2 Ø	кз Ø	1N Ø	SIE 1P Ø	MENS L1 Ø	RWF N ∅	50.2		G- Ø	ն+ Ø	13 Ø	12 Ø	11 Ø	
_ Q ⊘ ∅	Y1	Y2	Q13	SIEM Q14	IENS L1 Ø	RWF4 ⊘	0.0×0 Te	U1	G- Ø	G+ Ø	M1	l1 Ø	G1+ ⊘	

Parameters summarising for RWF50.2x:

Navigation menù			Con ⁻ Inp	f			Conf					F	PArA		Opr
			Inp1			Cr	ntr	diSP							
Types of probe	SEn1	OFF1	SCL	SCH	Unit	SPL	SPH	dECP	Pb. 1	dt	rt	tt	HYS1 (*)	HYS3 (*)	SP1 (*)
Siemens QAE2120	6	0	needless	needless	1	30	95	1	10	80	350	(#)	-5	5	0° 08
Siemens QAM2120	6	0	needless	needless	1	0	80	1	10	80	350	(#)	-2.5	2.5	40°C
Pt1000 (130°C max.)	4	0	needless	needless	1	30	95	1	10	80	350	(#)	-5	5	80°C
Pt1000 (350°C max.)	4	0	needless	needless	1	0	350	1	10	80	350	(#)	-5	10	80°C
Pt100 (130°C max.)	1	0	needless	needless	1	0	95	1	10	80	350	(#)	-5	5	80°C
Pt100 (350°C max)	1	0	needless	needless	1	0	350	1	10	80	350	(#)	-5	10	80°C
Sonda 4÷20mA / 0÷1,6bar	16	0	0	160	needless	0	160	0	5	20	80	(#)	0	20	100 kPa
Sonda 4÷20mA / 0÷10bar	16	0	0	1000	needless	0	1000	0	5	20	80	(#)	0	50	600 kPa
Sonda 4÷20mA / 0÷16bar	16	0	0	1600	needless	0	1600	0	5	20	80	(#)	0	80	600 kPa
Sonda 4÷20mA / 0÷25bar	16	0	0	2500	needless	0	2500	0	5	20	80	(#)	0	125	600 kPa
Sonda 4÷20mA / 0÷40bar	16	0	0	4000	needless	0	4000	0	5	20	80	(#)	0	200	600 kPa
Sonda 4÷20mA / 0÷60PSI	16	0	0	600	needless	0	600	0	5	20	80	(#)	0	30	300 (30PSI)
Sonda 4÷20mA / 0÷200PSI	16	0	0	2000	needless	0	2000	0	5	20	80	(#)	0	75	600 (60PSI)
Sonda 4÷20mA / 0÷300PSI	16	0	0	3000	needless	0	3000	0	5	20	80	(#)	0	120	600 (60PSI)
Siemens QBE2002 P4	17	0	0	400	needless	0	400	0	5	20	80	(#)	0	20	200 kPa
Siemens QBE2002 P10	17	0	0	1000	needless	0	1000	0	5	20	80	(#)	0	50	600 kPa
Siemens QBE2002 P16	17	0	0	1600	needless	0	1600	0	5	20	80	(#)	0	80	600 kPa
Siemens QBE2002 P25	17	0	0	2500	needless	0	2500	0	5	20	80	(#)	0	125	600 kPa
Siemens QBE2002 P40	17	0	0	4000	needless	0	4000	0	5	20	80	(#)	0	200	600 kPa
Segnale 0÷10V	17	0	to be fixed	to be fixed	needless	to be fixed	to be fixed	to be fixed	5	20	80	(#)	to be fixed	to be fixed	to be fixed
Segnale 4÷20mA	16	0	to be fixed	to be fixed	needless	to be fixed	to be fixed	to be fixed	5	20	80	(#)	to be fixed	to be fixed	to be fixed

NOTE : (#) tt - Types of probe

SQL33 ; STM30; SQM10; SQM40; SQM50; SQM54 = <u>30</u> (second) - STA12B3.41; SQN30.251; SQN72.4A4A20 = <u>12</u> (second)

(*) These values are factory set - values **MUST BE** set during operation at the plant based on the real working temperature/pressure value.

WARNING: With pressure probes the parameters SP1, SCH, SCL, HYS1, HYS3 must be selected, and visualized in kPa (kilo Pascal). (1bar = 100.000Pa = 100kPa).

TABLE OF PARAMETERS TO BE MODIFIED FOR CALIBRATIONS RWF50.3x/RWF55.xx (CONTINUOUS OUTPUT 4÷20mA) INSTEAD OF 3 POINTS

Navigation menù			Conf OutP		
Parameter	FnCt	SiGn	rOut	0Pnt	End
	4	1 (4÷20mA)	0	0	100

NOTE : (#) tt - servocontrol travel time SQL33 ; STM30; SQM10; SQM40; SQM50; SQM54 = 30 (second) STA12B3.41; SQN30.251; SQN72.4A4A20 = 12 (second) (*) Factory-set values, these values must be varied according to the actual working temperature/pressure of the system.

WARNING : With pressure probes in bar, parameters SP1, SCH, SCL, HYS1, HYS3 must be set, and displayed in kPa (kilo Pascal); 1bar = 100,000Pa = 100kPa. With pressure probes in PSI the parameters SP1, SCH, SCL, HYS1, HYS3 must be set, and displayed in PSI x10 (example : 150PSI > display 1500).

APPENDIX: PROBES CONNECTION

To assure the utmost comfort, the control system needs reliable information, which can be obtained provided the sensors have been installed correctly. Sensors measure and transmit all variations encountered at their location.

Measurement is taken based on design features (time constant) and according to specific operating conditions. With wiring run in raceways, the sheath (or pipe) containing the wires must be plugged at the sensor's terminal board so that currents of air cannot affect the sensor's measurements.

Ambient probes (or ambient thermostats)

Installation

The sensors (or room thermostats) must be located in


reference rooms in a position where they can take real temperature measurements without being affected by foreign factors.


ioreign lactors.



It's good to be admired ...even better to be effective

Heating systems: the room sensor must not be installed in rooms with heating units complete with thermostatic valves. Avoid all sources of heat foreign to the system.






Outside probes (weather) Installation

In heating or air-conditioning systems featuring adjustment in response to outside temperature, the sensor's positioning is of paramount importance.



General rule: on the outer wall of the building where the living rooms are, never on the south-facing wall or in a position where they will be affected by morning sun. If in any doubt, place them on the north or north-east façade.

Positions to be avoided




Avoid installing near windows, vents, outside the boiler room, on chimney breasts or where they are protected by balconies, cantilever roofs.

The sensor must not be painted (measurement error).

Location

On an inner wall on the other side of the room to heating unitsheight above floor 1.5 m, at least 1.5 m away from external sources of heat (or cold).



Installation position to be avoided

near shelving or alcoves and recesses, near doors or win-dows, inside outer walls exposed to solar radiation or currents of cold air, on inner walls with heating system pipes, domestic hot water pipes, or cooling system pipes running through them.

Duct or pipe sensors


Installing temperature sensors

For measuring outlet air:


- after delivery fan or
- after coil to be controlled, at a distance of at least 0,5 m

For measuring room temperature:

• before return air intake fan and near room's return airintake. For measuring saturation temperature: after mist eliminator.




Bend 0.4m sensor by hand (never use tools) as illustrated.



Use whole cross-section of duct, min. distance from walls 50 mm, radius of curvature 10 mm for 2m or 6m sensors.


Installing combined humidity sensors

As max. humidity limit sensor on outlet (steam humidifiers).



Installing pressure sensors

- A installation on ducts carrying fluids at max. temperature 80°C
- B installation on ducts at temperature over 80°C and for refrigerants
- C installation on ducts at high temperatures:
 - increase length of siphon
 - place sensor at side to prevent it being hit by hot air coming from the pipe.



Installing differential pressure sensors for water


- Installation with casing facing down not allowed.-With temperature over 80°C, siphons are needed.
- To avoid damaging the sensor, you must comply with the following instructions

when installing:


- make sure pressure difference is not greater than thevalue permitted by the sensor
- when there are high static pressures, make sure you insert shutoff valves A-B-C.

Putting into operation

Start disable 1=open C1=open C 2=open A2=close B 3=open B3=close A 4= close C




Immersion or strap-on sensors



Placing the probes (QAD22.../QAE21.../QAP21.../RCA...)


With pumps on outlet


with 3 ways valves / with 4 ways valves



With pumps on return

with 3 ways valves / with 4 ways valves





Immersion probes installation

Sensors must be installed on the stretch of pipe in which fluid circulates all the time.

The rigid stem (sensing element doing the measuring) must be inserted by at least 75mm and must face the direction of flow.

Recommended locations: on a bend or on a straight stretch of pipe but tilted by 45° and against the flow of fluid.

Protect them to prevent water from infiltrating (dripping gates, condensation from pipes etc.)

Installing QAD2.. strap-on sensors

Make sure fluid is circulating in the chosen location.

Eliminate insulation and paintwork (including rust inhibitor) on a min. 100mm length of pipe.

Sensors come with straps for pipes up to 100 mm in diameter

Strap-on or immersion sensors? QAD2.. strap-on sensors

Advantages :

- 10 sec. time constant
- Installed with system running (no plumbing work)
- Installation can be changed easily if it proves incorrect.

Limits:

- Suitable for pipe diameters max. 100 mm
- Can be affected by currents of air etc.

QAE2... immersion sensors


Advantages:

- Measure "mean" fluid temperature
- No external influence on measurement such as: currents of air, nearby pipes etc.


Limits:

- Time constant with sheath: 20 sec.
- Hard to change installation position if it proves incorrect.


Installing differential pressure probes for air




A - Control a filter (clogging)



B - Control a fan (upstream/downstream)




C - Measurement of difference in pressure between two ducts




D - Measurement of difference in pressure between two rooms or of inside of duct and outside

Basic principles

Measuring static pressure(i.e. pressure exerted by air on pipe walls)




Measuring dinamic pressure



Key

- y Kg/m³, specific weight of air m/s, air speed
- g 9.81 m/s² gravity acceleration
- Pd mm C.A., dynamic pressure

Measuring total pressure



Spare parts

Description	Code
Modulator RWF50.2 (uscita a 3 punti - apri, fermo, chiudi) 2570148	2570148
Modulator RWF50.3 (uscita continua 0÷20mA, 4÷20mA, 0÷10V) 2570149	2570149
Temperature probe Siemens QAE2120.010A (30÷130°C) 2560101	2560101
Temperature probe Siemens QAM2120.040 (-15÷+50°C) 2560135	2560135
Thermoresistor Pt1000 ø6mm L100mm (30÷130°C) 2560188	2560188
Thermoresistor Pt1000 ø10mm L200mm (0÷350°C) 2560103	2560103
Thermoresistor Pt100 ø10mm L200mm (0÷350°C) 2560145	2560145
Thermoresistor Pt100 ø8mm L85mm (0÷120°C) 25601C3	25601C3
Pressure probe Siemens QBE2 P4 (0÷4bar) 2560159	2560159
Pressure probe Siemens QBE2 P10 (0÷10bar / signal 0÷10V) 2560160	2560160
Pressure probe Siemens QBE2 P16 (0÷16bar / signal 0÷10V) 2560167	2560167
Pressure probe Siemens QBE2 P25 (0÷25bar / signal 0÷10V) 2560161	2560161
Pressure probe Siemens QBE2 P40 (0÷40bar / signal 0÷10V) 2560162	2560162
Pressure probe Danfoss MBS 3200 P 1,6 (0÷1,6bar / signal 4÷20mA) 2560189	2560189
Pressure probe Danfoss MBS 3200 P 10 (0÷10bar / signal 4÷20mA) 2560190	2560190
Pressure probe Danfoss MBS 3200 P 16 (0÷16bar / signal 4÷20mA) 2560191	2560191
Pressure probe Danfoss MBS 3200 P 25 (0+25bar / signal 4+20mA) 2560192	2560192
Pressure probe Danfoss MBS 3200 P 40 (0÷40bar / signal 4÷20mA) 2560193	2560193
Pressure probe Siemens 7MF1565-3BB00-1AA1 (0÷1,6bar / signal 4÷20mA) 25601A3	25601A3
Pressure probe Siemens 7MF1565-3CA00-1AA1 (0÷10bar / signal 4÷20mA) 25601A4	25601A4
Sonda di pressione Siemens 7MF1565-3CB00-1AA1 (0÷16bar / signal 25601A5	25601A5
Pressure probe Siemens 7MF1565-3CD00-1AA1 (0÷25bar / signal 4÷20mA) 25601A6	25601A6
Pressure probe Siemens 7MF1565-3CE00-1AA1 (0÷40bar / signal 4÷20mA) 25601A7	25601A7
Pressure probe Gefran E3E B1V6 MV (0÷1,6bar / segnale 4÷20mA) 25601C4	25601C4
Pressure probe Danfoss E3E B01D MV (0÷10bar / segnale 4÷20mA) 25601C5	25601C5
Pressure probe Danfoss E3E B16U MV (0÷16bar / segnale 4÷20mA) 25601C6	25601C6
Pressure probe Danfoss E3E B25U MV (0÷25bar / segnale 4÷20mA) 25601C7	25601C7
Pressure probe Danfoss E3E B04D MV (0÷40bar / segnale 4÷20mA)) 25601C8	25601C8
Pressure probe Siemens 7MF1567-4CD00-1EA1 (0-300PSI 1/4NPT 4-20mA)	25601G0
Pressure probe Siemens 7MF1567-4BF00-1EA1 (0-60PSI 1/4NPT 4-20mA)	25601G1
Pressure probe Siemens 7MF1567-4CB00-1EA1 (0-200PSI 1/4NPT 4-20mA)	25601G2

Note: Specifications and data subject to change. Errors and omissions excepted.

KM3 Modulator

USER MANUAL

M12927CA Rel.1.0 10/2020

MOUNTING



DISPLAY AND KEYS



	Operator Mode	Editing Mode
	Access to: - Operator Commands (Timer, Setpoint selection) - Parameters - Configuration	Confirm and go to Next parameter
	Access to: - Operator additional information (Output value, running time)	Increase the displayed value or select the next element of the parameters list
	Access to: - Set Point	Decrease the displayed value or select the previous element
P	Programmable key: Start the programmed function (Autotune, Auto/Man, Timer)	Exit from Operator commands/Parameter setting/Configuration

CONNECTIONS DIAGRAM



Probe connection:

- PT1000/NTC/PTC: between terminal 3 and 2
- PT 100: between terminal 3 and 2 with terminal 1
- **Passive pressure probe** 0/4-20 mA: between terminal 4 (+) e 1 (-) Note: out4 must be activated (IO4F must be setted to ON)
- **Powered pressure probe** 0/4-20 mA between terminal 4 (power supply), 2 (negative) e 1 (positive) Note: set IO4F to ON to activate Out4

Power supply connection:

- Neutral wire: terminal 9
- Phase: terminal 10 (100...240 Vac)
- Close terminals 15-16 to switch to the set point 2

Output connection:

- Channel 1: terminal 7 and 8 (burner on off)
- Channel 2: terminal 11 and 12 (servomotor opens)
- Channel 3: terminal 13 and 14 (servomotor closes)

SETPOINT AND HYSTERESIS CONFIGURATION (SP, AL1, HAL1 parameters)

Push the 🛃 button to enter into the setpoint configuration:



To return to normal mode, press the 😨 key for 3 seconds or wait the 10s timeout

Operation example



LIMITED ACCESS LEVEL

Proceed as follows to change some parameters that are not visible in standard user mode:



Param	Description	Values	Default
SEnS	Input type	Pt1 = RTD Pt100 Pt10 = RTD Pt1000 0.20 = 020mA 4.20 = 420mA Pressure probe 0.10 = 010V 2.10 = 210V crAL= Thermocouple K	Depends on the probe
SP	Set point 1	SPLL SPLH	
AL1	AL1 threshold	AL1L AL1H (E.U.)	
HAL1	AL1 hysteresis	1 9999 (E.U.)	
Pb	Proportional band	1 9999 (E.U.)	
ti	Integral time	0 (oFF) 9999 (s)	
td	Derivative time	0 (oFF) 9999 (s)	See page 7
Str.t	Servomotor stroke time	51000 seconds	
db.S	Servomotor dead band	0100%	
SPLL	Minimum set point value	-1999 SPHL	
SPHL	Maximum set point value	SPLL 9999	
dp	Decimal point position	0 3	
SP 2	Set point 2	SPLLSPLH	60
A.SP	Selection of the active set point	"SP" " nSP"	SP

To exit the parameter setting procedure press the 😨 key (for 3 s) or wait until the timeout expiration (about 30 seconds)

Parameter Serie dp SSC FSC Initial Initial Parameter Strict SPLL SPLL </th <th>Parameter Group</th> <th>inP</th> <th></th> <th></th> <th></th> <th></th> <th></th> <th>AL1</th> <th></th> <th>Бñ Б</th> <th></th> <th></th> <th></th> <th></th> <th>SP</th> <th></th> <th></th>	Parameter Group	inP						AL1		Бñ Б					SP		
Image: blackImage: black<	Parameter	Sens	dp	SSC	FSc	unit	104.F	AL1	HAL1	Рb	ti	td	Str.t	db.S	SPLL	SPHL	SP
Dec Scale Scale Off On p i d servo Band SP SP SP Point Min Max °C on 5 10 10 10 10 Min Min Min Max 1 1 m °C on 5 10 10 350 1 * 5 30 95 1 1 1 10 10 10 10 350 1 * 5 0 95 95 1 1 10 10 10 10 350 1 * 5 0 95 95 1 0 100 10 10 10 350 1 * 5 0 95 95 95 95 95 95 95 95 95 95 95 95 95 95 95 95 95 95							(**)	(***)	(***)	(***)	(***)	(***)					(***)
PointMinMaxMoMinMaxMoMinMaxMoMinMax11 \circ \circ on510103501 \ast 5309511 \circ \circ on1010103501 \ast 530951 \circ \circ on510103501 \ast 530951 \circ \circ on510103501 \ast 503501 \circ \circ on1010103501 \ast 503501 \circ \circ on2025103501 \ast 503500 \circ 0 \circ	Probes		Dec	Scale	Scale			Off	On	٩		σ	servo	Band	SP	SP	Set
			Point	Min	Max								time s	Mo.	Min	Мах	point
	Pt1000 (130°C max)	Pt10	1			ů	on	5	10	10	350	1	*	5	30	95	80
	Pt1000 (350°C max)	PT10	1			°	on	10	10	10	350	1	*	5	0	350	80
	Pt100 (130°C max)	PT1	1			ပ	uo	5	10	10	350	1	*	5	0	95	80
	Pt100 (350°C max)	Pt1	1			°	on	10	10	10	350	1	*	5	0	350	80
	Pt100 (0+100°C 4+20mA)	4.20	1	0	100		on	5	10	10	350	1	*	5	0	95	80
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	Thermocouple K (1200°C max)	crAL	0			°	on	20	25	10	350	1	*	5	0	1200	80
	Thermocouple J (1000°C max)	ſ	0			°	on	20	25	10	350	1	*	5	0	1000	80
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	4-20mA / 0-1,6barPressure probe	4.20	0	0	160		on	20	20	5	120	1	*	5	0	160	100
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	4-20mA / 0-10bar Pressure probe	4.20	0	0	1000		on	50	50	5	120	٢	*	5	0	1000	600
0 0 2500 on 125 120 1 * 5 0 2500 0 0 4000 on 200 200 5 120 1 * 5 0 2500 0 0 4000 0 200 200 5 120 1 * 5 0 4000 0 0 125 12 1 * 5 0 2500	4-20mA / 0-16bar Pressure probe	4.20	0	0	1600		uo	80	80	5	120	1	*	5	0	1600	600
0 0 4000 on 200 5 120 1 * 5 0 4000 0 0 2500 0 125 125 5 120 1 * 5 0 4000	4-20mA / 0-25bar Pressure probe	4.20	0	0	2500		on	125	125	5	120	1	*	5	0	2500	600
0 0 2500 0 125 125 5 120 1 * 5 0 2500	4-20mA / 0-40bar Pressure probe	4.20	0	0	4000		uo	200	200	5	120	-	*	5	0	4000	600
	QBE2002 / 0-25bar Pressure probe	0.10	0	0	2500		on	125	125	5	120	-	*	5	0	2500	600

7

Probe parameters configuration MODULATORE ASCON KM3

Note:

(*) Str.t - Servomotor stroke time SQL33; STM30; SQM10; SQM40; SQM50; SQM54 = 30 (Seconds) STA12B3.41; SQN30.251; SQN72.4A4A20 = 12 (Seconds)

(**) Out 4 ... on Display led °4 must be switched on, otherwise change the io4.F parameter value from "on" to "out4", confirm the value, quit the configuration mode then change again the io4.F parameter value from "out4" to "on".

(***) Factory settings. These values must be adapted to machine conditions

N.B. For pressure probe, SP, SPHL, SPLL parameters values are expressed in Kpa (1 bar = 100 Kpa).

CONFIGURATION

How to access configuration level

The configuration parameters are collected in various groups. Every group defines all parameters related with a specific function (e.g.: control, alarms, output functions).

- 1. Push the 🛃 button for more than 5 seconds. The upper display will show PASS while the lower display will show 0.
- Using \triangle and ∇ buttons set the programmed password. 2.

According to the entered password, it is possible to see a part of the parameters listed in the "configuration parameters" section.

- a. Enter "30" as password to view all the configuration parameters
- b. Enter "20" as password to view the parameters of the "limited access level". At this point, only the parameters with attribute Liv = A or Liv = O will be editable. Leave the password blank to edit "user level" parameters, that are identified by attribute Liv = O
- C.
- 3. Push the 🛃 button. If the password is correct the display will show the acronym of the first parameter group preceded by the symbol: [¬]. In other words the upper display will show: [¬] inP (group of the **Input parameters**).

The instrument is in configuration mode. To press 😨 for more than 5 seconds, the instrument will return to the "standard display.

Keyboard functions during parameter changing:

	Operator Mode
	When the upper display is showing a group and the lower display is blank, this key allows to enter in the selected group. When the upper display is showing a parameter and the lower display is showing its value, this key allows to store the selected value for the current parameter and access the next parameter within the same group.
$\mathbf{\Delta}$	Allows to increase the value of the selected parameter.
	Allows to decrease the value of the selected parameter.
Ģ	Short presses allow you to exit the current group of parameters and select a new group. A long press terminates the configuration procedure (the instrument returns to the normal display).
€ + +	These two keys allow to return to the previous group. Proceed as follows: Push the 😨 button and maintaining the pressure, then push the 🛁; release both the buttons.

Configuration Parameters

inP	GRO	UP - inpu	it confiuration		
Liv	N°	Param	Description	Values	Default
A	1	SEnS	Input type	Pt1 = RTD Pt100 Pt10 = RTD Pt1000 0.20 = 020mA 4.20 = 420mA Pressure probe 0.10 = 010V 2.10 = 210V crAL= Thermocouple K	Depends on the probe
A	2	dp	Decimal point position	0 3	See page 7
A	3	SSc	Initial scale read-out for linear inputs (avaiable only if SEnS parameter is not equal to Pt1, Pt10, crAL values)	-1999 9999	0
С	4	FSc	Full scale read-out for linear input inputs (avaiable only if SEnS parameter is not equal to Pt1, Pt10, crAL values)	-1999 9999	Depends on the probe
С	5	unit	Unit of measure (present only in the case of temperature probe)	°C/°F	°C
С	6	Fil	Digital filter on the measured value	0 (= OFF) 20.0 s	1.0
С	7	inE	Selection of the Sensor Out of Range type that will enable the safety output value	or = Over range ou = Under range our = over e under range	or

С	8	oPE	Safety output value	-100 100	0
С	9	io4.F	I/O4 function selection	on = Out4 will be ever ON (used as a transmitter power supply) ,out4 = Uscita 4 (Used as digital output 4), dG2c = Digital input 2 for contact closure, dG2U = Digital input 2 driven by 12 24 VDC	on
C	10	diF1	Digital input 1 function	oFF = Not used, 1 = Alarm reset, 2 = Alarm acknowledge (ACK), 3 = Hold of the measured value, 4 = Stand by mode, 5 = Manual mode, 6 = HEAt with SP1 and CooL with SP2, 7 = Timer RUN/Hold/Reset, 8 = Timer Run, 9 = Timer Reset, 10 = Timer Run/Hold, 11 = Timer Run/Reset, with lock, 13 = Program Start, 14 = Program Reset, 15 = Program Run/Hold, 16 = Program Run/Hold, 17 = Program Run/Hold, 17 = Program Run/Hold, 18 = Sequential SP selection, 19 = SP1 - SP2 selection, 20 = SP1 SP4 binary selection, 21 = Digital inputs in parallel	19
С	12	di.A	Digital Inputs Action (DI2 only if configured)	0 = DI1 direct action, DI2 direct action 1 = DI1 reverse action, DI2 direct action 2 = DI1 direct action, DI2 reverse action 3 = DI1 reverse action, DI2 reverse action	0

Out	GRO	UP- Outp	out parameters		
Liv	N°	Param	Description	Values	Default
С	14	o1F	Out 1 function	AL = Alarm output	AL
С	15	o1AL	Initial scale value of the analog retransmission	-1999 Ao1H	1
С	18	o1Ac	Out 1 action	dir = Direct action rEU = Reverse action dir.r = Direct with reversed LED ReU.r = Reverse with reversed LED	rEUr.r
С	19	o2F	Out 2 function	H.rEG = Heating output	H.rEG
С	21	o2Ac	Out 2 action	dir = Direct action rEU = Reverse action dir.r = Direct with reversed LED ReU.r = Reverse with reversed LED	dir
С	22	o3F	Out 3 function	H.rEG = Heating output	H.rEG
С	24	o3Ac	Out 3 action	dir = Direct action rEU = Reverse action dir.r = Direct with reversed LED ReU.r = Reverse with reversed LED	dir

Liv	N°	Param	Descrizione	Values	Default
С	28	AL1t	Tipo allarme AL1	nonE = Alarm not used LoAb = Absolute low alarm HiAb = Absolute high alarm LHAo = Windows alarm in alarm outside the windows LHAI = Windows alarm in alarm inside the	HidE

				windows SE.br = Sensor Break LodE = Deviation low alarm (relative) HidE = Deviation high alarm (relative) LHdo = Relative band alarm in alarm out of the band LHdi = Relative band alarm in alarm inside the	
С	29	Ab1	Alarm 1 function	band 0 15 +1 = Not active at power up +2 = Latched alarm (manual reset) +4 = Acknowledgeable alarm +8 = Relative alarm not active at set point change	0
С	30	AL1L	For High and low alarms, it is the low limit of the AL1 threshold; For band alarm, it is low alarm threshold	-1999 AL1H (E.U.)	-199.9
С	31	AL1H	For High and low alarms, it is the high limit of the AL1 threshold; For band alarm, it is high alarm threshold	AL1L 9999 (E.U.)	999.9
0	32	AL1	AL1 threshold	AL1L AL1H (E.U.)	See page 7
0	33	HAL1	AL1 hysteresis	1 9999 (E.U.)	See page 7
С	34	AL1d	AL1 delay	0 (oFF) 9999 (s)	oFF
С	35	AL10	Alarm 1 enabling during Stand-by mode and out of range conditions	 0 = Alarm 1 disabled during Stand by and out of range 1 = Alarm 1 enabled in stand by mode 2 = Alarm 1 enabled in out of range condition 3 = Alarm 1 enabled in stand by mode and in overrange condition 	1

GRI	GRUPPO AL2 - parametri allarme 2					
Liv	N°	Param	Description	Values	Default	
С	36	AL2t	Alarm 2 type	nonE = Alarm not used LoAb = Absolute low alarm HiAb = Absolute high alarm LHAo = Windows alarm in alarm outside the windows LHAI = Windows alarm in alarm inside the windows SE.br = Sensor Break LodE = Deviation low alarm (relative) HidE = Deviation high alarm (relative) LHdo = Relative band alarm in alarm out of the band LHdi = Relative band alarm in alarm inside the band	SE.br	
С	37	Ab2	Alarm 2 function	0 15 +1 = Not active at power up +2 = Latched alarm (manual reset) +4 = Acknowledgeable alarm +8 = Relative alarm not active at set point change	0	
С	42	AL2d	AL2 hysteresis	0 (oFF) 9999 (s)	oFF	
С	43	AL2o	Alarm 2 enabling during Stand-by mode and out of range conditions	 0 = Alarm 2 disabled during Stand by and out of range 1 = Alarm 2 enabled in stand by mode 2 = Alarm 2 enabled in out of range condition 3 = Alarm 2 enabled in stand by mode and in overrange condition 	0	

AL3 Group - alarm 3 parameters					
Liv	N°	Param	Description	Values	Default
	44	AL3t	Alarm 3 type	nonE = Alarm not used LoAb = Absolute low alarm HiAb = Absolute high alarm LHAo = Windows alarm in alarm outside the windows LHAI = Windows alarm in alarm inside the windows SE.br = Sensor Break LodE = Deviation low alarm (relative) HidE = Deviation high alarm (relative) LHdo = Relative band alarm in alarm out of the band LHdi = Relative band alarm in alarm inside the band	nonE

LbA	LbA Group - Loop break alarm					
Liv	N°	Param	Descrizione	Values	Default	
С	52	LbAt	LBA time	Da 0 (oFF) a 9999 (s)	oFF	

Liv	N°	Param	Description	Values	Default
С	56	cont	Control type	Pid = PID (heat and/or) On.FA = ON/OFF asymmetric hysteresis On.FS = ON/OFF symmetric hysteresis nr = Heat/Cool ON/OFF control with neutral zone 3Pt = Servomotor control (available only when Output 2 and Output 3 have been ordered as "M")	3pt
С	57	Auto	Autotuning selection	 -4 = Oscillating auto-tune with automaticrestart at power up and after all point change -3 = Oscillating auto-tune with manual start -2 = Oscillating -tune with auto-matic start at the first power up only -1 = Oscillating auto-tune with auto-matic restart at every power up 0 = Not used 1 = Fast auto tuning with automatic restart at every power up 2 = Fast auto-tune with manual start 4 = FAST auto-tune with automatic restart at power up only 3 = FAST auto-tune with automatic restart at power up and after set point change 5 = Evo-tune with automatic start the first power up 6 = Evo-tune with automatic start the first power up 7 = Evo-tune with automatic restart at power up and after a set point change 	7
С	58	tunE	Manual start of the Autotuning	oFF = Not active on = Active	oFF

С	59	SELF	Self tuning enabling	no = The instrument does not perform the self- tuning YES = The instrument is performing the self- tuning	No
A	62	Pb	Proportional band	1 9999 (E.U.)	See page 7
A	63	ti	Integral time	0 (oFF) 9999 (s)	See page 7
A	64	td	Derivative time	0 (oFF) 9999 (s)	See page 7
С	65	Fuoc	Fuzzy overshoot control	0.00 2.00	1
С	69	rS	Manual reset (Integral pre-load)	-100.0 +100.0 (%)	0.0
A	70	Str.t	Servomotor stroke time	51000 seconds	See page 7
А	71	db.S	Servomotor dead band	0100%	5
С	72	od	Delay at power up	0.00 (oFF) 99.59 (hh.mm)	oFF

SP	SP Group - Set point parameters					
Liv	N°	Param	Description	Values	Default	
С	76	nSP	Number of used set points	1 4	2	
A	77	SPLL	Minimum set point value	-1999 SPHL	See page 7	
A	78	SPHL	Maximum set point value	SPLL 9999	See page 7	
0	79	SP	Set point 1	SPLL SPLH	See page 7	
С	80	SP 2	Set point 2	SPLL SPLH	60	
	83	A.SP	Selection of the active set point	"SP" " nSP"	SP	
С	84	SP.rt	Remote set point type	RSP = The value coming from serial link is used as remote set point trin = The value will be added to the local set point selected by A.SP and the sum becomes the operative set point PErc = The value will be scaled on the input range and this value will be used as remote SP	trin	
С	85	SPLr	Local/remote set point selection	Loc = Local rEn = Remote	Loc	
С	86	SP.u	Rate of rise for POSITIVE set point change (ramp UP)	0.01 99.99 (inF) Eng. units per minute	inF	
С	87	SP.d	Rate of rise for NEGATIVE set point change (ramp DOWN)	0.01 99.99 (inF) Eng. units per minute	inF	

PAn	PAn Group - Operator HMI				
Liv	N°	Param	Description	Values	Default
С	118	PAS2	Level 2 password (limited access level)	oFF (Level 2 not protected by password) 1 200	20
С	119	PAS3	Level 3 password (complete configuration level)	3 300	30
С	120	PAS4	Password livello (livello configurazione a codice)	201 400	300
С	121	uSrb	button function during RUN TIME	nonE = No function tunE = Auto-tune/self-tune enabling. A single press (longer than 1 second) starts the auto-tune oPLo = Manual mode. The first pressure puts the instrument in manual mode (OPLO) while a second one puts the instrument in Auto mode	tunE

C	122	diSP	Display management	AAc = Alarm reset ASi = Alarm acknowledge chSP = Sequential set point selection St.by = Stand by mode. The first press puts the instrument in stand by mode while a second one puts the instrument in Auto mode. Str.t = Timer run/hold/reset P.run = Program run P.rES = Program reset P.r.H.r = Program run/hold/reset Spo = Operative set point	SPo
С	123	di.cL	Display colour	 0 = The display colour is used to show the actual deviation (PV - SP) 1 = Display red (fix) 2 = Display green (fix) 3 = Display orange (fix) 	2
	125	diS.t	Display Timeout	oFF (display always ON) 0.1 99.59 (mm.ss)	oFF
С	126	fiLd	Filter on the displayed value	oFF (filter disabled) From 0.0 (oFF) to 20.0 (E.U.)	oFF
С	128	dSPu	Instrument status at power ON	AS.Pr = Starts in the same way it was prior to the power down Auto = Starts in Auto mode oP.0 = Starts in manual mode with a power output equal to zero St.bY = Starts in stand-by mode	Auto
С	129	oPr.E	Operative modes enabling	ALL = All modes will be selectable by the next parameter Au.oP = Auto and manual (OPLO) mode only will be selectable by the next parameter Au.Sb = Auto and Stand-by modes only will be selectable by the next parameter	ALL
С	130	oPEr	Operative mode selection	If oPr.E = ALL: - Auto = Auto mode - oPLo = Manual mode - St.bY = Stand by mode If oPr.E = Au.oP: - Auto = Auto mode - oPLo = Manual mode If oPr.E = Au.Sb: - Auto = Auto mode - St.bY = Stand by mode	Auto

Liv	N°	Param	Description	Values	Default
С	131	Add	Instrument address	oFF 1 254	1
С	132	bAud	baud rate	1200 = 1200 baud 2400 = 2400 baud 9600 = 9600 baud 19.2 = 19200 baud 38.4 = 38400 baud	9600
С	133	trSP	Selection of the value to be retransmitted (Master)	nonE = Retransmission not used (the instrument is a slave) rSP = The instrument becomes a Master and retransmits the operative set point PErc = The instrument become a Master and it retransmits the power output	nonE

Liv	N°	Param	Description	Values	Default
2	134	Co.tY	Count type	oFF = Not used	oFF
				1 = Instantaneous power (kW)	
				2 = Power consumption (kW/h)	
				3 = Energy used during program execution. This	
				measure starts from	
				zero when a program runs end stops at the end	
				of the program. A	
				new program execution will reset the value	
				4 = Total worked days: number of hours the	
				instrument is turned ON	
				divided by 24.	
				5 = Total worked hours: number of hours the	
				instrument is turned ON.	
				6 = Total worked days with threshold: number of	
				hours the instrument is	
				turned ON divided by 24, the controller is forced	
				in stand-by when	
				Co.ty value reaches the threshold set in [137]	
				h.Job.	
				7 = Total worked hours with threshold: number of	
				hours the instrument	
				is turned ON, the controller is forced in stand-by	
				when Co.ty value	
				reaches the threshold set in [137] h.Job.	
				8 = Totalizer of control relay worked days:	
				number of hours the control	
				relay has been in ON condition, divided by 24.	
				9 = Totalizer of control relay worked hours:	
				number of hours the control	
				relay has been in ON condition.	
				10 = Totalizer of control relay worked days with	
				threshold: number of	
				hours the control relay has been in ON condition	
				divided by 24,	
				the controller is forced in stand-by when Co.ty	
				value reaches the	
				threshold set in [137] h.Job.	
				11 = Totalizer of control relay worked hours with	
				threshold: number of	
				hours the control relay has been in ON condition,	
				the controller is	
				forced in stand-by when Co.ty value reaches the	
				threshold set in	
		L		[137] h.Job.	<u> </u>
2	138	t.Job	Worked time (not resettable)	0 9999 days	0

cAL	cAL Group - User calibration group							
Liv	iv N° Param Description Values							
С	139	AL.P	Adjust Low Point	From -1999 to (AH.P - 10) in engineering units	0			
С	140	AL.o	Adjust Low Offset	-300 +300 (E.U.)	0			
С	141	AH.P	Adjust High Point	From (AL.P + 10) to 9999 engineering units	999.9			
С	142	AH.o	Adjust High Offset	-300 +300	0			

OPERATIVE MODES

When the instrument is powered, it starts immediately to work according to the parameters values loaded in its memory. The instrument behaviour and its performance are governed by the value of the stored parameters.

At power ON the instrument can start in one of the following mode depending on its configuration:

Automatic Mode In Automatic mode the instrument drives automatically the control output according to the parameter value set and the set point/measured value.

Manual Mode (OPLO): In Manual mode the the upper display shows the measured value while the lower display shows the power output [preceded by H (for heating) or C (for cooling)], MAN is lit and the instrument allows you to set manually the control output power. No Automatic action will be made.

Stand by Mode (St.bY): In stand-by mode the instrument operates as an indicator. It will show on the upper display the measured value and on the lower display the set point alternately to the "St.bY" messages and forces the control outputs to zero.

We define all the above described conditions as "Standard Display".

As we have seen, it is always possible to modify the value assigned to a parameter independently from the operative modes selected.

AUTOMATIC MODE

Keyboard function when the instrument is in Auto mode:

	Modo Operatore
ſ	Allows entry into parameter modification procedures
	Allows you to start the "Direct set point modification" function (see below).
	Allows you to display the "additional informations" (see below).
C	Performs the action programmed by [121] uSrb (Debutton function during RUN TIME) parameter

Additional information

This instrument is able to show you some additional informations that can help you to manage your system. The additional informations are related to how the instrument is programmed, hence in many cases, only part of this information is available.

- 1. When the instrument is showing the "standard display" push 🛆 button. The lower display will show H or c followed by a number. This value is the current power output applied to the process. The H show you that the action is a Heating action while the "c" show you that the action is a Cooling action
- 2. Push button again. When the programmer is running the lower display will show the segment currently performed and the Event status as shown below:

where the first character can be r for a ramp or S for a soak, the next digit show the number of the segment (e.g. S3 means Soak number 3) and the twoless significant digits (LSD) show you the status of the two event (the LSD is the Event 2)..

- 3. Push button again. When the programmer is running the lower display will show the theoretical remaining time to the end of the program preceded by a "P" letter:
 - P843
- 4. Push 🛆 button again. When the wattmeter function is running the lower display will show U followed by the measured energy..
- 5. Push button. When the "Worked time count" is running the lower display will show "d" for days or "h" for hours followed by the measured time.
- 6. Push 🛆 button. The instrument returns to the "standard display".

Note: The additional information visualization is subject to a time out. If no button is pressed for more than 10 second the instrument comes automatically back to the Standard display..

Direct set point modification

This function allows to modify rapidly the set point value selected by [83] A.SP (selection of the active Set point) or to the set point of the segment group (of the programmer) currently in progress.

- 1. Push **V** button. The upper display shows the acronym of the selected set point (e.g. SP2) and the lower display will show its value.
- 2. By \triangle and ∇ buttons, assign to this parameter the desired value
- 3. Do not push any button for more than 5 second or push the 🛃 button. In both cases the instrument memorize the new value and come back to the "standard display".

Manual mode

This operative mode allows you to deactivate automatic control and manually program the percentage power output to the process. When the instrument is in manual mode, the upper display shows the measured value while the lower display shows the power output [preceded by H (for heating action) or C (for cooling action)] The MAN LED is lit. When manual control is selected, the instrument will start to operate with the same power output as the last one supplied by automatic mode and can be modified using the \triangle and ∇ buttons.

In case of ON/OFF control, 0% corresponds to the deactivated output while any value different from 0 corresponds to the activated output. As in the case of visualization, the programmable values range from H100 (100% output power with reverse action) to C100 (100% output power with direct action).

Notes:

- During manual mode, the alarms are operative.
- If you set manual modes during program execution, the program will be frozen and it will restart when the instrument will come back to Auto mode.
- If you set manual modes during self-tune execution, the self- tune function will be aborted.
- During manual mode, all functions not related with the control (wattmeter, independent timer, "worked time", etc) continue to operate normally..

STAND-BY MODE

This operative mode also deactivates the automatic control but forces the control output to zero. In this mode the instrument operates as an indicator. When the instrument is in stand by mode the upper display will show the measured value while the lower display will show alternately the set point and the message "St.bY".

Notes:

- During stand by mode, the relative alarms are disabled while the absolute alarms are operative or not according to the ALxo (Alarm x enabling during Stand-by mode) parameter setting.
- If you set stand by mode during program execution, the program will be aborted.
- If you set stand by mode during self-tune execution, the self- tune function will be aborted.
- During stand by mode, all functions not related with the control (wattmeter, independent timer, "worked time", etc) continue to operate normally.
- When the instrument is swapped from stand by to auto modes, the instrument will start automatically the alarm masking, the soft start functions and the auto-tune (if programmed).

AUTOTUNE (EVOTUNE)

Evotune is a fast and fully automatic procedure that can be started in any condition, regardless the deviation from SP. The controller selects automatically the best tune method and computes the optimum PID parameters. To activate Evotune press 😨 button for 3 seconds.

ERROR MESSAGES

The upper display shows the OVER-RANGE and UNDERRANGE conditions with the following indications:

Over-range:

Under-range

The sensor break will be signalled as an out of range:

Note: When an over-range or an under-range is detected, the alarms operate as in presence of the maximum or the minimum measurable value respectively.

To check the out of span Error condition, proceed as follows:

- 1. Check the input signal source and the connecting line.
- 2. Make sure that the input signal is in accordance with the instrument configuration. Otherwise, modify the input configuration.
- 3. If no error is detected, send the instrument to your supplier to be checked.

List of possible errors

ErAT Fast Auto-tune cannot start. The measure value is tooclose to the set point. Push the button in order to delete the error message.

ouLd Overload on the out 4. The messages shows that a short circuit is present on the Out 4 when it is used as output or as a transmitter power suply. When the short circuit disappears the output restart to operate..

NoAt Auto-tune not finished within 12 hours.

ErEP Possible problem of the instrument memory. The messages disappears automatically. When the error continues, send the instrument to your supplier.

RonE Possible problem of the firmware memory. When this error is detected, send the instrument to your supplier.

Errt Possible problem of the calibration memory. When this error is detected, send the instrument to your supplier.

FACTORY RESET

Sometime, e.g. when you re-configure an instrument previously used for other works or from other people or when you have made too many errors during configuration and you decided to re-configure the instrument, it is possible to restore the factory configuration. This action allows to put the instrument in a defined condition (the same it was at the first power ON).

The default data are those typical values loaded in the instrument prior to ship it from factory. To load the factory default parameter set, proceed as follows:

- 1. Press the 🖵 button for more than 5 seconds. The upper display will show PASS while the lower display shows 0;
- 2. Using \triangle and ∇ buttons set the value -481;
- 3. Push 🗖 button;
- 4. The instrument will turn OFF all LEDs for a few seconds, then the upper display will show dFLt (default) and then all LEDs are turned ON for 2 seconds. At this point the instrument restarts as for a new power ON.

The procedure is complete.


Note: The complete list of the default parameters is available in Chapter "Configuration".

USER MANUAL OF MULTI-THERMOSTAT MCX06C

MCX06C is a multi-thermostat with four 100k NTC inputs. It can control up to 4 temperatures showing them (not more than 2 at the same time) on a couple of displays. It is used to check and adjust oil heater temperatures.


User interface:

Device:



Note :

In normal operation, the display A shows the oil tank resistor temperature (probe Pb1). In normal operation, the display B shows the oil output temperature (probe Pb3).



Connections from terminal side:

Probe connection:

input Al1 = probe Pb1 = set-point "tr" = oil heater temperature probe;

input AI2 = probe Pb2 = set-point "tCI" = plant consent temperature probe (when installed); input AI3 = probe Pb3 = set-point "OIL" = oil heater output temperature probe (PID regulation);

input AI4 = probe Pb4 = set-point "tcn" = oil heater consent temperature probe.

Menu:

To enter the menu below, keep pushing ENTER for more than 3 s.

Menu code	Sub-menu code	Function	Notes			
Prb		Probes values	You can see in sequence the 4 probe values (UP and DOWN keys): the probe code is on display A (Pb1,, Pb4) and the probe value is on display B (not fitted or out of work probes show "").			
Log		Login	It defines the access level to menu and parameters (password)			
	PAS	Password	Password input			
Par		Parameters menu	Access to parameters (you have to login first)			
	CnF	Configuration menu	Parameter configuration			
	rEG	Regulation menu	Set to set-point, probe, thresholds etc.			
ALA		Alarm menu	Access to alarm management			
	Act	Active alarms	Show the active alarms			
	rES	Reset alarms & Warning	Reset of the manual reset alarms and warning			
Loc		Lock/Unlock functions	Not used			
InF	rEL	Software version	Installed software version			
tUN		Autotuning	Activation On, deactivation ESC PID parameter autotuning			

Alarms & Warning:

When the red triangle on the top left lights, one or more alarms are activated.

When the red key on the left lights, the output N05-C5 is active and the relay **KTRS** switches the resistors OFF. Check the reason, correct the failure and, as soon as the temperature is lower than **trS**, reset it through **ALA/rES**. In order to show active alarms and warnings, select the relevant menu through **ALA/Act**.and, using the **UP** and **DOWN** buttons, scroll the lines.

In order to perform the manual reset, select ALA/rES.

Code	Description	Sourse	Active simbol	Reset type
trS	High temperature resistors alarm	probe Pb4 > value trS	red key	Manual
EP1	Probe Pb1 fault	Probe Pb1 fault	red triangle	Automatic
EP2	Probe Pb2 fault	Probe Pb2 fault	red triangle	Automatic
EP3	Probe Pb3 fault	Probe Pb3 fault	red triangle	Automatic
EP4	Probe Pb4 fault	Probe Pb4 fault	red triangle	Automatic

Set point adjustment:

All the parameters inside the Par menu are locked by a password.

The user can modify only set points (menu rEG), without using any passwords.

The oil viscosity at the nozzle, should be about 1,5°E, which guarantees correct and safe functioning of the burner. The temperature values in the table, guarantee the respect of that parameter and are valid when the pre heating tank is installed on the burner. For different configurations, please refer to the chapter "Recommendations to design heavy oil feeding plants" in the burner manual.

Here below recommended set points:

		_		Oil vis	cosity at 50 ℃	•		n in the	
M	enu pa	ath				burner model			
				Р	N	E	D	Н	
				89 cSt	< 50 cSt	> 50 cSt	> 110 cSt	> 400 cSt	
						< 110 cSt	< 400 cSt	< 4000 cSt	
				12 °E	<7€	> 7 E	> 15 ℃	> 50 ℃	
						< 15 ℃	< 50 ℃	< 530 €	
Par									
rEG	Pb1	tr	Oil heater temperature probe	parameter not visible					
	Pb2	tCI	Plant consent temperature probe (when installed)	20 °C	70 ℃	70 ℃	70 °C		
	Pb3	Oil	oil heater output temperature probe (PID regulation);	60-70 ℃	110-120 ℃	120-130 ℃	130-140 ℃	140-150 °C	
		SP0	Set-point oil heater with oil pump stopped (stand-by)	45 ℃	120 °C	130 °C	140 °C	150 °C	
	Pb4	tcn	Oil heater consent temperature probe	40 °C	100 °C	100 ℃	110 °C	120 °C	
		trS	Safety temperature tank resistors (manual reset)	120 °C	190-200 ℃	190-200 ℃	190-200 ℃	190-200 °C	

The above temperature values are suggested and refer to a plant designed according to the prescriptions in the burner user manual. The suggested values can change in reference to the fuel oil specifications.

MANUALE USER SUPPORT

MULTI-THERMOSTAT MCX06C

MCX06C is a multi-thermostat with four 100k NTC inputs. It can control up to 4 temperatures showing them (not more than 2 at the same time) on a couple of displays.

It is used to check and adjust oil heater temperatures. it works as follows:

as soon as the burner control gives the GO to the digital 1 input (terminals DI1-COM), the adjustment program runs (the relevant LED is ON). Reading the outlet temperature through the probe **Pb3** (terminals AI3-COM), a PID signal is produced. This signal becomes the set-point for the electric resistors. The electric resistors temperature is read through the probe **Pb1** (terminals AI1-COM) so that a second PID signal is produced. This second PID drives a couple of SCR by means of 0-10 V impulses in order to control the electric resistors temperature.

When the burner is in stand-by, resistor set-point is kept at the temperature set in parameter "p30" (see parameter group REG).


Probe **Pb4** (terminals Al4-COM) controls the inner heater temperature. As soon the relevant set-point is got, it drives the output number 4 (terminals C4-NO4) linked to the relais KTCN. This allows the oil pump to start and also the burner control proceeds with its cycle.

When set-point **trS** is got to, output number 5 is ON (terminals C5-NO5) linked to the relais KTRS. It switches the resistors off and activates an alarm on the device.

Probe **Pb2** (terminals AI2-COM), when fitted, drives output number 2 (terminals C2-NO2) linked to the relais KTCI. This allows the burner control to proceed with ignition.


See below the set-point recommended figures.

User interface:



Note :

In normal operation, the display A shows the oil tank resistor temperature (probe Pb1). In normal operation, the display B shows the oil output temperature (probe Pb3).





Probe connection:


input AI1 = probe Pb1 = set-point "tr" = oil heater temperature probe;

input **AI2** = probe **Pb2** = set-point "**tCI**" = plant consent temperature probe (when installed); input **AI3** = probe **Pb3** = set-point "**OIL**" = oil heater output temperature probe (PID regulation);

input **AI4** = probe **Pb4** = set-point **Ch2** = oil heater consent temperature probe (r







(tCl - Pb2 probe only for mechanical atomizing burners)

Menu :

To enter the menu below, keep pushing **ENTER** for more than 3 s.

Menu code	Sub-menu code	Function	Notes
Prb		Probes values	You can see in sequence the 4 probe values (UP and DOWN keys): the probe code is on display A (Pb1,, Pb4) and the probe value is on display B (not fitted or out of work probes show "").
Log		Login	It defines the access level to menu and parameters (password)
	PAS	Password	Password input
Par		Parameters menu	Access to parameters (you have to login first)
	CnF	Configuration menu	Parameter configuration
	rEG	Regulation menu	Set to set-point, probe, thresholds etc.
ALA		Alarm menu	Access to alarm management
	Act	Active alarms	Show the active alarms
	rES	Reset alarms	Reset of the manual reset alarms
Loc		Lock/Unlock functions	Not used
InF	rEL	Software version	Installed software version
tUN		Autotuning	Activation On, deactivation ESC PID parameter autotuning

Login:

All the parameters inside the **Par** menu are locked by a password.

Without password, only set-points can be modified.

To login, on the log menu, press **ENTER** for more than 3 s. Input your password (level 2 or 3) inside **PAS** With password for level 3 all the data can be set.

submenu CnF - configuration parameters group :

Menu	Parameter	Description	Additional description	Min	Max	Default	U.M.	Visibility condition	Password level	Modbus index
CnF		CONFIGURATION							0	
Al1		Analog Input 1							1	
			This parameter enables or disables the						1	
	A1P	Probe 1 Presence	probe	0	1	1			2	1
	A1C	Calibration Probe 1	Don't modify it	-20,0	20,0	0,0	°C	A1P >0	3	2
Al2	AIC	Analog Input 2	Bont modify it	-20,0	20,0	0,0	- C		1	2
AIZ		Analog Input 2	This parameter enables or disables the						1	-
	A2P	Probe 2 Presence	probe	0	1	1			2	3
	A2P A2C	Calibration Probe 2	Don't modify it	-20,0	20,0	0,0	°C	A2P >0	3	4
AI3	AZC	Analog Input 3		-20,0	20,0	0,0	C	AZF 20	1	4
AIS		Analog Input 5	This parameter enables or disables the						1	
	A 2 D	Probe 3 Presence		0	4	4			0	
	A3P	-	probe		999,9	1		A3P >2	2	5
	A3L	Min. Value conversion Al3	Don't modify it	-999,9		0,0		A3P >2 A3P >2	3	6
	A3H	Max. Value conversion Al3	Don't modify it	-999,9	999,9	30,0			3	/
	A3C	Calibration Probe 3	Don't modify it	-20,0	20,0	0,0	°C	A3P >0	3	8
Al4		Analog Input 4							1	
			This parameter enables or disables the							
	A4P	Probe 4 Presence	probe	0	4	1			2	9
	A4L	Min. Value conversion Al4	Don't modify it	-999,9	999,9	0,0		A4P >2	3	10
	A4H	Max. Value conversion Al4	Don't modify it	-999,9	999,9	30,0		A4P >2	3	11
	A4C	Calibration Probe 4	Don't modify it	-20,0	20,0	0,0	°C	A4P >0	3	12
dl		Digital input							1	
	dl1	Input 1 polarity (Pump)	Change type of digital input (NC o NO)	0	1	1			3	13
	dl2	Alarm polarity from input 2	Change type of digital input (NC o NO)	0	2	2			2	14
	dl3	Alarm polarity from input 3	Change type of digital input (NC o NO)	0	2	2			2	15
	dl4	Alarm polarity from input 4	Change type of digital input (NC o NO)	0	2	2			2	16
	dl5	Alarm polarity from input 5	Change type of digital input (NC o NO)	0	2	2			2	17
	dl6	Alarm polarity from input 6	Change type of digital input (NC o NO)	0	2	2			2	18
		Digital output								
dl		Alarm and Warning							1	
	dO5	Polarity output Warning	Change type of digital input (NC o NO)	0	1	0			3	19
	dO6	Polarity output Alarm	Change type of digital input (NC o NO)	0	1	0			3	20
SIC		Safety probe							1	
			Probe which also activates the relay							
	SIp	Selection of safety probe	Warning (ns. KTRS)	0	4	4			3	21
SyS		Syistem							0	
,			Probe temperature or set-point to be		1			1		
	dSA	display A output	displayed in the left display	0	8	1			3	22
			Probe temperature or set-point to be							
	dSb	display B output	displayed in the right display	0	8	3			3	23
PAS		Password							1	-
	PL1	Password level 1		0	9999	0			1	32
	PL2	Password level 2		0	9999				2	33
	PL3	Password level 3		0	9999				3	34

Menu	Parameter	Description	Additional description	Min	Мах	Default	U.M.	Visibility condition	Level	Modbus index
tUN	1 arameter	Autotuning		IVIIII	IVIAA	Delault	0.141.	condition	3	Index
ton	tU1	Output temperature hysteresis	Don't modify it	0	50,0	0,5	3°		3	35
	tU2	Startup number	Don't modify it	0	5	2	- U		3	36
	tU3	Measurement cycles number	Don't modify it	1	4	2			3	37
		Max. differential command	Don't modify it							
	tU4	exit		0,01	10,00	10,00	V		3	38
	tU5	Differential reduction exit command (%)	Don't modify it	0	100	15			3	39
		Calculating mode: 0= Symmetrical; 1=Asymmetrical;	Don't modify it							
	tU6	2=Simple		0	2	2			3	40
	tU7	Enabling	Don't modify it	0	1	1			3	41

Submenu **REG – regulation parameters group :**

Menu	Parameter	Description	Additional description	Min	Max	Default	U.M.	Visibility condition	Level	Modbus index
REG		REGULATION							0	
Pb1		Probe 1							0	
	rES	Set-point Probe 1 (Tank resistor)	Don't modify it	-50,0	200,0	0,0	°C		3	42
	AL1	Probe 1 - Low Temperature Alarm Threshold	Don't modify it	-50,0	200,0	-50,0	°C		3	43
	AH1	Probe 1 - High Temperature Alarm Threshold	Don't modify it	-50,0	200,0	200,0	°C		3	44
	d01	Probe 1 differential		0,0	20,0	3,0	0°C		3	45
Pb2		Probe 2							0	
	tCI	Set-point Probe 2 (Plant Consent)	Plant consent according to table "Set point adjustment"	-50,0	200,0	120,0	°C		0	46
	AL2	Probe 2 - Low Temperature Alarm Threshold	Don't modify it	-50,0	200,0	-50,0	°C		2	47
	AH2	Probe 2 - High Temperature Alarm Threshold	Don't modify it	-50,0	200,0	200,0	°C		2	48
	d02	Probe 2 differential		0,0	20,0	3,0	°C		2	49
Pb3		Probe 3							0	
	rE3	Type of regulation of probe 3 (Oil tank exit)	Type of regulation 0= thermostat; 1= PID (don't modify)	0	1	1			3	50
	OIL	Set-point Probe 3 (Oil tank exit)	Nozzle oil temperature according to the table "Set point adjustment"	-50,0	200,0	130,0	°C		0	51
	AL3	Probe 3 - Low Temperature Alarm Threshold (Oil tank exit)	Don't modify it	-50,0	200,0	-50,0	°C		2	52
	AH3	Probe 3 - High Temperature Alarm Threshold (Oil tank exit)	Don't modify it	-50,0	200,0	200,0	°C		2	53
	Pb3	Proportional band for PID Probe 3 (Oil tank exit)	Proportional band for first PID regulation	0,0	200,0	60,0			3	54
	db3	Dead Zone for PID Probe 3 (Oil tank exit)	Dead zone for first PID regulation	0,0	20,0	0,0	°C	rE3 =1	3	55
	rt3	Integral Time (Ti) for PID Probe 3 (Oil tank exit)	Integral time for first PID regulation	0,0	1000,0	120,0	s	rE3 =1	3	56
	dt3	DerivativeTime (Td) for PID Probe 3 (Oil tank exit)	Derivative time for first PID regulation $(\sim \frac{1}{4} \text{ di rt3})$	0,0	300,0	30,0	s	rE3 =1	3	57
	db3	Dead Zone for PID Probe 3 (Oil tank exit)	Dead zone for first PID regulation	0,0	20,0	0,0	°C	rE3 =1	3	55

Menu	Parameter	Description	Additional description	Min	Max	Default	U.M.	Visibility condition	Level	Modbus index
		Overshooting for Integral action	Don't modify it							
	pi1	(Oil tank exit)		100	1000	200		rE3 =1	3	58
		Derivative action enabling	Don't modify it							
	pi2	(Oil tank exit)		0	1	1		rE3 =1	3	59
		Filtering factor for derivative action	Don't modify it							
	pi3	(Oil tank exit)		1	100	20		rE3 =1	3	60
	pi4	Duty cicle PWM for output DO3 and/or AO1 (0-10V)	Don't modify it	1	300	5	s	rE3 =1	3	61
		Output selection DO3 and/or AO1	Digital selection output for control							
	SL3	(0-10V)	thyristors; Don't modify it	0	2	AO1			3	62
		Proportional band for PID Probe 1	Proportional band for second PID							
	p21	(Tank resistor)	regulation	0,0	200,0	50,0		rE3 =1	3	63
		Dead Zone for PID Probe 1	Dead zone for second PID regulation							
	p22	(Tank resistor)		0,0	20,0	0,0	°C	rE3 =1	3	64
		Integral Time (Ti) for PID Probe 1	Integral time for second PID regulation							
	p23	(Tank resistor)		0,0	1000,0	110,0	S	rE3 =1	3	65
		DerivativeTime (Td) for PID Probe 1	Derivative time for second PID regulation							
	p24	(Tank resistor)		0,0	300,0	23,0	S	rE3 =1	3	66
		Overshooting for Integral action	Don't modify it							
	p25	(Tank resistor)		100	1000	200		rE3 =1	3	67
		Derivative action enabling	Don't modify it	0					0	00
	p26	(Tank resistor)	Death as a life it	0	1	1		rE3 =1	3	68
	- 07	Filtering factor for derivative action	Don't modify it	4	100	20			2	<u> </u>
	p27	(Tank resistor)		1	100	20		rE3 =1	3	69
	p28	Min Output PID Probe 3 (Oil tank exit)	Minimum value tank resistor set-point (delta of 100°C above p29)	0,0	1000.0	80,0	°C	rE3 =1	3	70
	p20	Max Output PID Probe 3	Maximum valuetank resistor set-point	0,0	1000,0	80,0	C	1E3 - 1	3	70
	p29	(Oil tank exit)		0.0	1000,0	180.0	°C	rE3 =1	3	71
	p29	Set-point Tank Resistor with oil	Set-point of maintaining resistance during	0,0	1000,0	100,0		123 - 1	3	/ 1
	SP0	pump stops (stand by)	stand by "Set point adjustment"	-50.0	200.0	140.0	°C	rE3 =1	0	72
Pb4	010	Probe 4		00,0	200,0	140,0			0	12
1.01		Setpoint Probe 4	Oil consent according table "Set point							
	tcn	(Oil consent)	adjustment"	-50,0	200,0	110.0	°C		0	73
	AL4	Low Threshold Probe 4		-50.0	200,0	-50,0	°C		2	74
		Probe 4 - High Temperature Alarm	Tank resistor safety temperature according	20,0	200,0	00,0	-		_	
		Threshold	table "Set point adjustment"							
	trS	(Safety Thermostat)	,	-50,0	200,0	190,0	°C		0	75
	d04	Probe 4 differential		0,0	20.0	3,0	°C		2	76

Alarms & Warning:

When the red triangle on the top left lights, one or more alarms are activated.

When the red key on the left lights, the output N05-C5 is active and the relay KTRS switches the resistors OFF. Check the reason, correct the failure and, as soon as the temperature is lower than trS, reset it through ALA/rES. In order to show active alarms and warnings, select the relevant menu through ALA/Act.and, using the UP and **DOWN** buttons, scroll the lines.

In order to perform the manual reset, select ALA/rES.

Code	Description	Sourse	Active simbol	Reset type
trS	High temperature resistors alarm	probe Pb4 > value trS	red key	Manual
EP1	Probe Pb1 fault	Probe Pb1 fault	red triangle	Automatic
EP2	Probe Pb2 fault	Probe Pb2 fault	red triangle	Automatic
EP3	Probe Pb3 fault	Probe Pb3 fault	red triangle	Automatic
EP4	Probe Pb4 fault	Probe Pb4 fault	red triangle	Automatic

Set point adjustment:

All the parameters inside the Par menu are locked by a password. The user can modify only set points, without using any passwords.

The oil viscosity at the nozzle, should be about 1,5°E, which guarantees correct and safe functioning of the burner. The temperature values in the table, guarantee the respect of that parameter and are valid when the pre heating tank is installed on the burner. For different configurations , please refer to the chapter "Recommendations to design heavy oil feeding plants" on the burner manual

Here below recommended set points:

Menu path				Oil viscosity at 50 °C according to the letter shown in the burner model					
	•			P N E D H					
				89 cSt	< 50 cSt	> 50 cSt < 110 cSt	> 110 cSt < 400 cSt	> 400 cSt < 4000 cSt	
				12 °E	< 7°E	> 7 °E < 15 °E	> 15 °E < 50 °E	> 50 °E < 530 °E	
Par									
rEG	Pb1	tr	Oil heater temperature probe	parameter not visible					
	Pb2	tCl	Plant consent temperature probe (when installed)	20 °C	70 °C	70 °C	70 °C		
	Pb3	Oil	oil heater output temperature probe (PID regulation);	60-70 °C	110-120 °C	120-130 °C	130-140 °C	140-150 °C	
		SP0	Set-point oil heater with oil pump stopped (stand-by)	45 °C	120 °C	130 °C	140 °C	150 °C	
	Pb4	tcn	Oil heater consent temperature probe	40 °C	100 °C	100 °C	110 °C	120 °C	
		trS	Safety temperature tank resistors (manual reset)	120 °C	190-200 °C	190-200 °C	190-200 °C	190-200 °C	

The above temperature values are suggested and refer to a plant designed according to the prescriptions in the burner user manual.

The suggested values can change in reference to the fuel oil specifications.